

## Bernecker & Rainer

Garanti: 12 ay  
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Bernecker & Rainer** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Bernecker & Rainer Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*



rn	Aıklama
<a href="#">5p5000:V1144</a>	CONTROLLER SYSTEM PROVIT IPC5000 PENTIUM 2SLOT
<a href="#">060002095-01</a>	PC BOARD
<a href="#">5pc720.1214-00</a>	OPERATOR INTERFACE 24VDC 12.1INCH IP65
<a href="#">Brarcif-0t</a>	EEPROM/RAM MODULE
<a href="#">Ecpsa2-0</a>	POSITIONING MODULE 20KHZ 2AXIS
<a href="#">If686</a>	INTERFACE MODULE 1POWERLINK
<a href="#">8msa3x.E0-31</a>	SERVO MOTOR 1.82-2.10AMP 330V
<a href="#">5c2002.04</a>	OPERATOR INTERFACE 9IN SCREEN
<a href="#">8b0c0320hw00.000-1</a>	ACOPOS MULTI C0320 SERVO DRIVE POWER SUPPLY
<a href="#">3ip151.60-2</a>	OUTPUT MODULE DIGITAL
<a href="#">0ps120.1</a>	POWER SUPPLY INPUT115/230VAC 10/5A OUTPUT24VDC 20A
<a href="#">8bvi0220hwds0001</a>	MODULE

<a href="#">8lsa46.Mob60</a>	SERVO MOTOR
<a href="#">8lsa65eb030d1001</a>	SERVO MOTOR
<a href="#">Nt40</a>	POWER SUPPLY MODULE 24VDC 50W
<a href="#">8msa4le347</a>	SERVO MOTOR
<a href="#">8lsa25.R0060d000-0</a>	SERVO MOTOR 0.82AMP 400VAC 6000RPM
<a href="#">8bvi0110hws00001</a>	INVERTER
<a href="#">4pp015.0420-36</a>	OPERATOR INTERFACE 153X120MM 16KEY 300KB SRAM
<a href="#">Sp62cfs-06</a>	AUTOMATION PC
<a href="#">8v1640-001-2</a>	SERVO DRIVE 64AMP 32KW 400-480V
<a href="#">7xx408.50-1</a>	I/O MODULE REMOTE DIGITAL 16PT 24VDC
<a href="#">8lsa45.E2045d200-0</a>	SERVO MOTOR
<a href="#">8v1090.001-2</a>	SERVO DRIVE 3X400/480V 8.8AMP 4KW 50/60HZ
<a href="#">3if789.9</a>	MODULE
<a href="#">3cp360.60-2</a>	CPU MODULE CP360 32MB DRAM 512KB SRAM
<a href="#">Mca12c-0</a>	OUTPUT MODULE DIGITAL
<a href="#">Pp40</a>	PROCESSOR MULTI PARALLEL TYPE A
<a href="#">8v1320.001-2</a>	SERVO DRIVE
<a href="#">3if786.9</a>	INTERFACE MODULE FOR ETHERNET AND RS232 INTERFACE
<a href="#">8msa3x.R0-66</a>	SERVO MOTOR 2.90AMP 3NM 4500RPM 330V
<a href="#">3ip161.60-1</a>	I/O PROCESSOR 12IN/OUT 24VDC
<a href="#">Hcmgc1-0</a>	GRAPHIC CONTROLLER MAESTRO
<a href="#">5c200122</a>	PROCESSOR 32MB 24V
<a href="#">5c5601.11</a>	INDUSTRIAL PC CONTROLLER SYSTEM PROVIT 5600
<a href="#">8msa4l.R0-B4</a>	SERVO MOTOR 4.8AMP 7.5NM 3000RPM 330V
<a href="#">8bvi0055hwd0000</a>	SERVO
<a href="#">4d1164.00-090</a>	MODULE PANELWARE GRAPHIC DISPLAY 16X40 128X240 PIX
<a href="#">8lsa56.R0030d200-0</a>	SERVO MOTOR 9.8AMP 400VAC 3000RPM
<a href="#">8v1010.00-2</a>	SERVO DRIVE AXIS .45KW 3X400-480VAC
<a href="#">X67bcd321l12</a>	CONTROLLER
<a href="#">5ap920.1214-01</a>	TOUCHSCREEN AUTOMATION PANEL 12.1IN 24VDC

<a href="#">8lsa74d0030d0000</a>	SERVO MOTOR
<a href="#">8v1045.00-1</a>	SERVO DRIVE ACOPOS 1045 4.4AMP 2KW 3X400-480V
<a href="#">5ap920.1505-01</a>	OPERATOR INTERFACE PANEL 15INCH 24VDC
<a href="#">8jsa73.Eb024d000-0</a>	SERVO MOTOR
<a href="#">Ecnt43-0</a>	POWER SUPPLY MODULE 10AMP 24VDC NT43
<a href="#">8lva23.R0030d200-0</a>	SERVO MOTOR 24VDC
<a href="#">4pp451.0571-75</a>	POWER PANEL 5.7IN QVGA TFT COLOR DISPLAY
<a href="#">X67um4389</a>	MODULE
<a href="#">8ac140.61-3</a>	ACOPOS PLUG-IN MODULE DOUBLE WIDTH 24VDC 500MA
<a href="#">3me960.90-1</a>	MEMORY MODULE 64KB SRAM 256KB FLASH PROM
<a href="#">7cx436.50-1</a>	REMOTE INPUT/OUTPUT MODULE 24VDC
<a href="#">Hcmc01-0</a>	PLC MODULE MAESTRO
<a href="#">Z081</a>	TIMER MODULE MULTI ANALOG 8 CHANNEL
<a href="#">5d5200.29</a>	OPERATOR INTERFACE POWER PANEL 10 10-1/2IN
<a href="#">5ap980.1505-K11</a>	OPERATOR INTERFACE 15INCH TOUCH SCREEN COLOR
<a href="#">5d5201.11</a>	DISPLAY PANEL 12INCH
<a href="#">5pp1201043k03</a>	SCREEN
<a href="#">Ecpe82-13</a>	INPUT MODULE ANALOG
<a href="#">8lse84.E1015d000-0</a>	SERVO MOTOR
<a href="#">8lsa44.R0030d100-0</a>	SERVO MOTOR 4.6/6NM 3000RPM 400V 2.8/3.7AMP
<a href="#">4pp320.1043-31</a>	POWER PANEL 10.4 TOUCHSCREEN
<a href="#">8msa3l.E1-31</a>	SERVO MOTOR
<a href="#">8msa5le1d4001</a>	SERVO MOTOR
<a href="#">8lsa46.R0030d200-0</a>	SERVO MOTOR
<a href="#">8v1045.001-2</a>	SERVO DRIVE IP 3X400-800V 4.4AMP 2KW LINE FILTER
<a href="#">2cp104.60-1</a>	CPU INTERFACE 128 + 256 KB SRAM 1
<a href="#">X20if10611</a>	UNIT
<a href="#">3if787.9</a>	INTERFACE MODULE APCI 1POWERLINK
<a href="#">0902988635</a>	MODULE
<a href="#">5d5211.03</a>	OPERATOR TOUCH-SCREEN PROVIT 5000 12.1IN COLOUR
<a href="#">8lsa57.E3030d004-1</a>	SERVO MOTOR

<a href="#">8bvi0220hws00001</a>	INVERTER
<a href="#">8bvi0440hcs0.000-1</a>	INVERTER MODULE VAC 44AMP 480VAC 500HZ
<a href="#">8msa4m.R0-30</a>	SERVO MOTOR 3000RPM 5.3NM 330V 3PHASE
<a href="#">X20sl8000</a>	CONTROLLER STANDARAD
<a href="#">4pp480104375</a>	POWER PANEL
<a href="#">8lsa46.R0045d200-0 Obsolete</a>	
<a href="#">7cp472.60-1</a>	CPU MODULE RS232 256KB 24VDC 11W
<a href="#">2ex100.50-1</a>	I/O MASTER MODULE RS485 INTERFACE
<a href="#">8lsa43.R0030d100-0</a>	SERVO MOTOR 3.1/4NM 3000RPM 400V 1.9/2.5AMP
<a href="#">7cp774.60-1</a>	CPU 100KB SRAM 512KB 100/240V INTERFACE CP774
<a href="#">8msa5xe3d5001</a>	MOTOR
<a href="#">8msa4m.E1-30</a>	SERVO MOTOR SYNCHRONOUS
<a href="#">4pp0650571p74</a>	TOUCH SCREEN
<a href="#">5pc820.1505-00</a>	PANEL PC 15IN XGA COLOR TFT DISPLAY W/TOUCH SCREEN
<a href="#">Mdc41.0</a>	CENTRAL PROCESSING UNIT
<a href="#">8bvi0055hwd0.000-1</a>	DRIVE ACUPUS MULTI I0055D
<a href="#">9a0100.11</a>	POWER SUPPLY 24VDC SERIAL INTERFACE
<a href="#">Hcmcp2-0</a>	OUTPUT MODULE MAESTRO MCP2
<a href="#">8lsa57.Eb022d004-1</a>	SERVO MOTOR
<a href="#">5d2200.07</a>	TOUCH SCREEN 10.4INCH COLOR TFT PROVIT 2000
<a href="#">8v128m.00-2</a>	SERVO DRIVE
<a href="#">4d1167.00-490</a>	OPERATOR INTERFACE PANELWARE 16X40CHAR 47KEY IP65
<a href="#">8lsa46.R0045c200-0</a>	SERVO MOTOR 9.2AMP 10NM 4500RPM 400V
<a href="#">Provit600-4</a>	OPERATOR INTERFACE CRT 120/240VAC 50/60HZ 60W
<a href="#">4pp420.0571-B5</a>	POWER PANEL
<a href="#">8v1180.001-2</a>	SERVO DRIVE 9KW 400-480V 19AMP
<a href="#">8msa4x.R0-30</a>	SERVO MOTOR
<a href="#">4pp320.0571-01</a>	HMI-POWER PANEL 300-TFG
<a href="#">X20cp1583</a>	BUS CONTROLLER
<a href="#">5pc720.1505-02</a>	OPERATOR INTERFACE 10AMP 24VDC

<a href="#">2ex200501</a>	MODULE
<a href="#">8lsa25r0060d200</a>	MOTOR
<a href="#">5pp5wpp500260se</a>	POWER PANEL
<a href="#">8ys-K0055r0.005-0</a>	SERVO MOTOR 4.04AMP 640VDC 3.77NM IP65
<a href="#">Brrt28</a>	OPERATOR INTERFACE KEYPAD 24VDC
<a href="#">5pp320.0571-39</a>	TOUCHSCREEN PANEL COLOR 5.7 INCH 24VDC 256MB SDRAM
<a href="#">5ap9201505k54</a>	PANEL
<a href="#">8lsa34.R0030d100-0</a>	SERVO MOTOR 1.4/1.5NM 3000RPM 400V .96/1.03AMP
<a href="#">X20xm0985</a>	MODULE
<a href="#">3ao350.6</a>	OUTPUT MODULE 8POINT ANALOG
<a href="#">8msc-4x.R0-D3</a>	SERVO MOTOR
<a href="#">8lsa46r0030d000</a>	MOTOR
<a href="#">8lta92.D0003f000-0</a>	SERVO MOTOR 27NM
<a href="#">Pc-Provit-Gps1</a>	COMPUTER INDUSTRIAL 300CELERON 128RAM WINDOWS 95
<a href="#">8bvi0110hwd0.000-E</a>	DRIVE
<a href="#">8msc4x.R0-K4</a>	SERVO MOTOR 14.69AMP 230-330VAC 6000RPM
<a href="#">Cp40</a>	PROCESSOR MODULE CP40
<a href="#">Brrt36-1</a>	CONTROL PANEL MODULE
<a href="#">7ex484.50-1</a>	BUS CONTROLLER MODULE POWERLINK 24VDC
<a href="#">Ecpp60-1</a>	PROCESSOR MODULE
<a href="#">8lsa45.E0022d200-0</a>	SERVO MOTOR 3.2/3.6A 400V 2200RPM 8NM IP64
<a href="#">8msa5l.R0-B5</a>	SERVO MOTOR 6POLE 9.17AMP 13.5NM 3000RPM
<a href="#">Brrtm4-0</a>	CONTROL BOARD
<a href="#">8lsa46.R0045c000-0</a>	SERVO MOTOR 9.2AMP 400VAC 4500RPM
<a href="#">5pc7201043-01</a>	PANEL PC 720 10.4IN TOUCH SCREEN 2 PCI SLOT
<a href="#">4pp4501043k01</a>	CONTROL PANEL
<a href="#">Pa81</a>	OUTPUT MODULE MULTI ANALOG 8POINT +/- 10 V, 11
<a href="#">7cp476.60-1</a>	PLC PROCESSOR 24VDC
<a href="#">Ecpp60-01</a>	PROCESSOR PARALLEL TYPE B PP60
<a href="#">5p62slimppc01</a>	PC

<a href="#">Bv1090002</a>	SERVO DRIVE
<a href="#">X20-Cp-1584</a>	CPU INTERFACE EXPANSION
<a href="#">8bvf0440h000.001-2</a>	POWER SUPPLY 480VAC
<a href="#">8214794.18</a>	BOARD
<a href="#">4c2000.01-110</a>	PANEL CONTROLLER 256KB SRAM 256KB FLASH PROM 24VDC
<a href="#">Provit5000</a>	PC
<a href="#">5ap981150501</a>	PANEL
<a href="#">4pp280104375</a>	POWER PANEL
<a href="#">X20-Cp1483</a>	CPU TYPE X20 X86 100 MHZ INTEL 32MB DRAM 128KBSRAM
<a href="#">4pp451.0571-45</a>	POWER PANEL 400
<a href="#">X20bc8084</a>	CONTROLLER
<a href="#">4pp0650351x74</a>	MONITOR
<a href="#">3ip350.60-1</a>	I/O PROCESSOR PROGRAMMABLE 850KB SRAM
<a href="#">8lsc5cd0022d0050</a>	SERVO MOTOR
<a href="#">5p5000-V1021</a>	CONTROLLER SYSTEM PROVIT IPC5000 PENTIUM 2SLOT
<a href="#">Hcmaestro-A</a>	IND.COMPUTER OS-9/68000 PROCESSOR 12.5MHZ DMA CONT
<a href="#">R911311062</a>	CONVERTER
<a href="#">4pp420.1043-75</a>	OPERATOR INTERFACE 10.4INCH
<a href="#">8msa4l.E2-W 1</a>	SERVO MOTOR 5.5AMP 3PHASE
<a href="#">8v1090.00-1</a>	SERVO DRIVE ACOPOS 1090 8.8AMP 4KW 400-480V
<a href="#">8bvi0330hwss0001</a>	MODULE
<a href="#">8b0c0320hw00.00a-1</a>	MODULE
<a href="#">8lsa57eb030c1003</a>	MOTOR
<a href="#">5pp32015053b</a>	PART
<a href="#">3di450.6</a>	INPUT MODULE DIGITAL 16POINT 24VDC
<a href="#">4pp420.1505-75</a>	POWER PANEL PP420 15IN XGA COLOR TFT DISPLAY W/TS
<a href="#">4pp450.1043-K04</a>	OPERATOR INTERFACE
<a href="#">4pp420.0571-K04</a>	OPERATOR INTERFACE
<a href="#">5ap920-1043-K02</a>	10.4 VGA DISPLAY 2XUSB 24VDC
<a href="#">3if797.9</a>	INTERFACE MODULE FOR FLEX IQ X2X LINK MASTER
<a href="#">4pp0450571042</a>	TOUCH SCREEN

<a href="#">8lsa35eb030d200</a>	SERVO MOTOR
<a href="#">X20-Cp-1585</a>	CPU INTERFACE EXPANSION 10AMP 24VDC
<a href="#">1a43001en401</a>	SOFTWARE
<a href="#">5pc720.1505-K02</a>	PANEL PC 15INCH TFT W/TOUCH SCREEN 3.8AMP 24VDC
<a href="#">Eccp600</a>	CPU BOARD MODULE
<a href="#">M2ntcp64-0</a>	CPU POWER SUPPLY MODULE 24VDC
<a href="#">8lsa45.E0030d100-0</a>	SERVO MOTOR
<a href="#">3ai4756</a>	MODULE
<a href="#">3cp380601</a>	CPU
<a href="#">5ap933240c00</a>	DISPLAY
<a href="#">X20cp3584</a>	X20 CPU, ATOM 0.6 GHZ, 256 MB DDR2 RAM, 1 MB SRAM
<a href="#">8jsa73.R0024d000-0</a>	SERVO MOTOR
<a href="#">8lva33.R0021d000-0</a>	MOTOR 2100RP 7-9AMP 57V
<a href="#">4pp420-1043-K12</a>	POWER PANEL 400
<a href="#">8lsa75e1030d200</a>	SERVO MOTOR
<a href="#">Brks02-0</a>	PLC MODULE MICROCONTROL 110/220VAC
<a href="#">5pp320.1043-39</a>	POWER TOUCH PANEL 10.4INCH VGA COLOR TFT 256MB
<a href="#">8msa5le1d4</a>	SERVO MOTOR
<a href="#">5pp380.1043-K01</a>	POWER PANEL 24VDC 0.4-1.8AMP 10.4IN VGA
<a href="#">Ecpp02-0</a>	PUI MODULE
<a href="#">X20mm4456</a>	PWM MOTOR BRIDGE MODULE
<a href="#">8v1640.13-2</a>	SERVO DRIVE 100AMP 480VAC 32KW
<a href="#">8msa3le3i6</a>	MOTOR
<a href="#">5s050002u</a>	KEY
<a href="#">5c4000.04</a>	OPERATOR INTERFACE PROVIT 4000
<a href="#">4pp420.1043-K40 Rev.F0</a>	POWER PANEL
<a href="#">3cb260.60-1</a>	CPU MODULE 4MB 850KB CP260
<a href="#">7cm471.70-1</a>	I/O MODULE DIGITAL 1-2AMP IN 24VDC 5MA OUT 24VDC
<a href="#">X20-Cp-1483-1</a>	CPU MODULE 100MHZ 64MB DRAM
<a href="#">8v1090-001-1</a>	SERVO DRIVE 8.8AMP 4KW 400-480V

<a href="#">Eccp80-12-A1</a>	PLC MODULE MULTICONTROL
<a href="#">7ex481.50-1</a>	BUS CONTROLLER MODULE 24VDC
<a href="#">4d1166.00-590</a>	OPERATOR INTERFACE DISPLAY PANEL PANELWARE
<a href="#">5c5001.12</a>	CONTROLLER SYSTEM PROVIT IPC5000 PENTIUM 2SLOT
<a href="#">3ex450.66-2</a>	PROFIBUS DP MASTER BUS CONTROL MODULE
<a href="#">4pp420104385</a>	DISPLAY
<a href="#">3ps475.9</a>	POWER SUPPLY MODULE SYTEM 2005
<a href="#">Brrtvfd42-0</a>	OPERATOR CONTROL PANEL