

## Code

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in **info@yursat.com.tr** e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Code** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Code T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunulmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



| ¼r¼n                                   | A¼ıklama  |
|--|---|
| <a href="#">Cr921-Pku-Cd7</a>          |   |
| <a href="#">Cr6022-C501-P2</a>         | CODE, CR6000 DPM SCANNER, DARK GRAY,RS232, 8 FT COILED RS232 CABLE, EU POWER SUPPLY                 |
| <a href="#">Cra-Us4</a>                |   |
| <a href="#">Cr2512g-Hx-Bx-Rx-Cx-F1</a> |   |
| <a href="#">Cr3012g-Bh1-Rx-C3-F1</a>   | CODECR3BAR CODE READER1950 MAH BATTERY HANDLENO RADIO8FT COILED RS232 CABLE INCLUDEDUS POWER SUPPLY |
| <a href="#">Cr1411-Pku</a>             |   |
| <a href="#">Cr2611-C65-Pkxxx</a>       |   |
| <a href="#">Cr2611-C65-Pkcmu</a>       |   |
| <a href="#">Cr2512g-Pk1-Fips-F1</a>    | CODE, CR2500 KIT, FIPS, BATTERY, SINGLE-BAY CHARGER, US POWER SUPPLY, USB CABLE, M2 MODEM           |
| <a href="#">Cr3512g-Hx-B0-Rx-Cx-F1</a> |   |

|  |   |
|--|---|
| <a href="#">Cr2512g-Pk2-Fips-F1</a>    | CODE, CR2500 KIT, FIPS, BH1 HANDLE, ECS-H CHARGER W/ BASE, US POWER SUPPLY, 6FT STRAIGHT USB CABLE, M2 MODEM                                    |
| <a href="#">Cr1421-Mag-C514</a>        |   |
| <a href="#">Cr3512g-F1-C155</a>        |   |
| <a href="#">Cr2ag-H2</a>               |   |
| <a href="#">Bthdg-M3-R0-Cx</a>         |   |
| <a href="#">Cra-Avdk1</a>              |   |
| <a href="#">Cr2ag-B0</a>               |   |
| <a href="#">Cr3622-Dpmcmu</a>          | CODE, CR3600 DPM, SCANNER, HANDLE, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH EMBEDDED MODEM, USB CHARGE CABLE                        |
| <a href="#">Cr2612-Mag-Pkcxu</a>       | CODE, CR2600, SCANNER, HANDLE, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH USB CHARGE CABLE, EXTERNAL M3 MODEM WITH USB COMM CABLE |
| <a href="#">Cr3512g-Hx-B0-Rx-C0</a>    |   |
| <a href="#">Cr2012g-H2-Cx-F1</a>       |   |
| <a href="#">Cr3512g-Bh2-Rx-C0-F1</a>   |   |
| <a href="#">Cr5020-C500-C147</a>       |   |
| <a href="#">Cr1421-Cx-F1</a>           |   |
| <a href="#">Sp-Prem-Crfd</a>           |   |
| <a href="#">Cr921-Pkr-F0</a>           |   |
| <a href="#">Cr1411-Pkr3-F1</a>         |   |
| <a href="#">Cr1200g-C30-F1</a>         |   |
| <a href="#">Cr1210g-C20-F1</a>         |   |
| <a href="#">Cr3512g-Hx-B0-Rx-C0-F1</a> |   |
| <a href="#">Cr2321-Pkcxu</a>           |   |
| <a href="#">Cra-A120</a>               |   |
| <a href="#">Cr1411-Pku-F1-C65</a>      |   |
| <a href="#">Cra-A111</a>               |   |
| <a href="#">Cr2321-Pkcye</a>           |   |
| <a href="#">Cr1011-Pku8</a>            |   |
| <a href="#">Cra-A152</a>               |   |

|   |  |
|---|--|
| <a href="#">Cra-C500</a>                  |  |
| <a href="#">Cr3512g-C155-F1</a>           |  |
| <a href="#">Cr1200g-C20-F1</a>            |  |
| <a href="#">Cr3312g-Bh1-R0-Cx-F1</a>      | CODE CORPCR3BAR CODE READER1950 MAH BATTERY<br>HANDLEBLUETOOTH RADIONO CABLE   |
| <a href="#">Cr5020-C502-P1</a>            |  |
| <a href="#">Cr4405-Pkc1a</a>              |  |
| <a href="#">Cr2ag-Bh2</a>                 |  |
| <a href="#">Cr3621-Pkcxa</a>              |  |
| <a href="#">Cr1021-Pku</a>                |  |
| <a href="#">Cr1200g-C0-F1-C86</a>         |  |
| <a href="#">Cr2611-Mag-Pkcxa</a>          | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS,<br>BATTERY, CHARGING STATION WITH US POWER SUPPLY,<br>EXTERNAL M3 MODEM WITH USB COMM CABLE     |
| <a href="#">Cr4405-Pkc1k</a>              |  |
| <a href="#">Cr1411-Pkr2</a>               |  |
| <a href="#">Cra-Mb1</a>                   |  |
| <a href="#">Cr3622-Pkcxe</a>              | CODE, CR3600, SCANNER, HANDLE, DARK GRAY,<br>BLUETOOTH, BATTERY, CHARGING STATION WITH EURO<br>POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE         |
| <a href="#">Cr1411-C500-C65-F1</a>        |  |
| <a href="#">Cr2ag-C8</a>                  |  |
| <a href="#">Cr2512g-Bh1-R0-C20-C65-F1</a> |  |
| <a href="#">Xml-Hr1</a>                   |  |
| <a href="#">Cra-Ca2</a>                   |  |
| <a href="#">Cr2612-Pkcmu</a>              |  |
| <a href="#">Cr2612-Mag-Pkcxe</a>          | CODE, CR2600, SCANNER, HANDLE, LIGHT GRAY, BT, MAG<br>LENS, BATTERY, CHARGING STATION WITH EURO POWER<br>SUPPLY, EXTERNAL M3 MODEM WITH USB COMM CABLE |
| <a href="#">Cr1011-Pkr</a>                |  |
| <a href="#">Cr3621-Dpmcxu</a>             | CODE, CR3600 DPM, SCANNER, PALM, DARK GRAY,<br>BLUETOOTH, BATTERY, CHARGING STATION WITH USB<br>CHARGE CABLE, EXTERNAL M3 MODEM, USB COMM CABLE        |
| <a href="#">Cra-Wmb1</a>                  |  |
| <a href="#">Cr1021-C500-C132</a>          |  |

|  |  |
|--|--|
| <a href="#">Cra-A107</a>               |  |
| <a href="#">Cra-A104</a>               |  |
| <a href="#">Cr2ag-Cv5</a>              |  |
| <a href="#">Cr2012g-Hx-B0-Rx-Cx-F1</a> |  |
| <a href="#">Cra-C31</a>                |  |
| <a href="#">Cr2612-Pkcxa</a>           |  |
| <a href="#">Cr1421-Mag-Pkr</a>         |  |
| <a href="#">Cra-C503</a>               |  |
| <a href="#">Bthdg-M2-R0-C0</a>         |  |
| <a href="#">Cr1200ag-S1</a>            |  |
| <a href="#">Cr2512g-Hx-B2-Rx-C0-F1</a> |  |
| <a href="#">Cr2012g-H2-C0-F1</a>       |  |
| <a href="#">Cr3512g-Bh1-Rx-Cx-F1</a>   |  |
| <a href="#">Cr25ag-Cv3</a>             |  |
| <a href="#">Cr1411-C503</a>            |  |
| <a href="#">Cra-A182</a>               |  |
| <a href="#">Cra-P4</a>                 |  |
| <a href="#">Cr2ag-C20</a>              |  |
| <a href="#">Cr1411-Pkr</a>             |  |
| <a href="#">Cr1021-C503-F1</a>         |  |
| <a href="#">Cr2612-C65-Pkcxe</a>       |  |
| <a href="#">Cra-Sl1g</a>               |  |
| <a href="#">Cr3512g-H2-C20-C177-F1</a> |  |
| <a href="#">Cr2ag-P21</a>              |  |
| <a href="#">Cr3012g-Hx-B2-R0-Cx-F1</a> | CODE CORPCR3BAR CODE READERNO HANDLE1950 MAH BATTERYBLUETOOTH RADIONO CABLE                                |
| <a href="#">Cr3012g-Bh1-R0-C3-F1</a>   | CODECR3BAR CODE READER1950 MAH BATTERY HANDLEBLUETOOTH RADIO8FT COILED RS232 CABLE INCLUDEDUS POWER SUPPLY |
| <a href="#">Cr1421-Pkrs</a>            |  |
| <a href="#">Cr2612-C65-Pkcmu</a>       |  |
| <a href="#">Cr3621-Dpmxxx</a>          |  |

|   |   |
|---|---|
| <a href="#">Cra-41-B1</a>               |   |
| <a href="#">Cr1210g-C3-F1</a>           |   |
| <a href="#">Cr2012-Hx-B0-Rx-C3-F1</a>   |   |
| <a href="#">Cr2ag-C11</a>               |   |
| <a href="#">Cr1011-Pkr2</a>             |   |
| <a href="#">Cr1411-C500-F1-C65</a>      |   |
| <a href="#">Cr3512g-Hx-Bx-R0-Cx-F1</a>  |   |
| <a href="#">Bthdg-B1</a>                |   |
| <a href="#">Cr2612-C65-Pkxxx</a>        |   |
| <a href="#">Cr2012g-Hx-B2-Rx-C12-F1</a> |   |
| <a href="#">Cra-C509</a>                |   |
| <a href="#">Cr921-C500-C159</a>         |   |
| <a href="#">Cr3512g-Bh1-R0-C0-F1</a>    |   |
| <a href="#">Cra-A105</a>                |   |
| <a href="#">Cr3012g-Bh1-Rx-C12-F1</a>   |   |
| <a href="#">Cr2512g-Bh1-R0-C20-F1</a>   |   |
| <a href="#">Cr2611-Pkcxa</a>            |   |
| <a href="#">Cr1421-Pkr3-F1</a>          |   |
| <a href="#">Cr1421-C500</a>             |   |
| <a href="#">Cr2612-Mag-Pkxxx</a>        | CODE, CR2600, SCANNER, HANDLE, LIGHT GRAY, BT, MAG LENS, BATTERY    |
| <a href="#">Cra-T500</a>                |   |
| <a href="#">Cr2321-Pkcyu</a>            |   |
| <a href="#">Cra-Mb5-X10</a>             |   |
| <a href="#">Cr2612-Pkxxx</a>            |   |
| <a href="#">Cra-B4</a>                  |   |
| <a href="#">Cra-A122</a>                |   |
| <a href="#">Xml-Ctrm</a>                |   |
| <a href="#">Cr6022-Pku</a>              | CODE, CR6000 DPM SCANNER, DARK GRAY, 6 FT STRAIGHT USB CABLE, STAND |
| <a href="#">Cr1021-Mag-Cx</a>           |   |

|  |  |
|--|--|
| <a href="#">Cr1011-C500-F1</a>         |  |
| <a href="#">Cr1011-Pkr3</a>            |  |
| <a href="#">Cr1421-Pku8-C65-F1</a>     |  |
| <a href="#">Cr1421-Pkr2-F1</a>         |  |
| <a href="#">Cr1011-C503-F1</a>         |  |
| <a href="#">Cr2512g-Hx-B0-Rx-Cx-F1</a> |  |
| <a href="#">Cr1421-Pku</a>             |  |
| <a href="#">Cr5025-C502-P1</a>         |  |
| <a href="#">Cr2611-Mag-Pkcy</a>        | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH US POWER SUPPLY                                |
| <a href="#">Cr921-Pku</a>              |  |
| <a href="#">Cr3512g-H2-C0-F1</a>       |  |
| <a href="#">Cr1011-C501-F1</a>         |  |
| <a href="#">Cr3012g-Bh2-Rx-C0-F1</a>   | CODECR3BAR CODE READER3900 MAH BATTERY HANDLENO RADIO6FT STRAIGHT USB CABLE INCLUDED   |
| <a href="#">Cr1021-Mag-Pkr2</a>        |  |
| <a href="#">Cr3622-Pkcxb</a>           |  |
| <a href="#">Cr1210g-C1-F1</a>          |  |
| <a href="#">Cr3622-C146-Pkcmu</a>      | CODE, CR3600, BARCODE READER, DARK GRAY, BT, BATTERY, CHARGING STATION WITH EMBEDDED MODEM AND USB CABLE, CUSTOM FOR MA STATE POLICE |
| <a href="#">Sp-Prem-M</a>              |  |
| <a href="#">Cr4405-Pkc2a</a>           | CODE, CR4405, IPHONE 5 SLED BAR CODE READER, LIGHT GRAY, BATTERY, CHARGING STATION, SPARE BATTERY, USB CABLE, 2 AMP US POWER SUPPLY  |
| <a href="#">Cr2321-Pkpmu</a>           |  |
| <a href="#">Cr2ag-A32</a>              |  |
| <a href="#">Cr2012g-Bh1-Rx-Cx-F1</a>   |  |
| <a href="#">Cra-A101</a>               |  |
| <a href="#">Cra-Mb4</a>                |  |
| <a href="#">Cr3012g-Bh2-R0-C0-F1</a>   | CODECR3BAR CODE READER3900 MAH BATTERY HANDLEBLUETOOTH RADIO6FT STRAIGHT USB CABLE INCLUDED  |
| <a href="#">Cr2512g-Bh1-Rx-Cx-F1</a>   |  |

|   |   |
|---|---|
| <a href="#">Cr1011-Cx-F1</a>              |   |
| <a href="#">Cra-U10</a>                   |   |
| <a href="#">Cr2ag-Ca1</a>                 |   |
| <a href="#">Cr1421-Pku-F1-C65</a>         |   |
| <a href="#">Cr1011-C508-F1</a>            |   |
| <a href="#">Cr2012g-Bh1-Rx-C0-F1</a>      |   |
| <a href="#">Cp3500-Bh2-C0-Js-A52-C150</a> |   |
| <a href="#">Cr1021-C507</a>               |   |
| <a href="#">Cra-A149</a>                  |   |
| <a href="#">Cr2512g-Bh2-R0-Cx-F1</a>      |   |
| <a href="#">Cr2612-C65-Pkcxu</a>          |   |
| <a href="#">Cr4405-Pkc1e</a>              |   |
| <a href="#">Cr3512h-Hx-B2-Rx-C0-F1</a>    | CODE CORPCR3500BAR CODE READERNO HANDLE1950 MAH<br>BATTERY6FT USB CABLE |
| <a href="#">Cra-C502</a>                  |   |
| <a href="#">Cr1021-C508-F1</a>            |   |
| <a href="#">Cra-A153</a>                  |   |
| <a href="#">Cra-A147</a>                  |   |
| <a href="#">Bthdg-M3-R2-C0</a>            |   |
| <a href="#">Cr3012g-Bh2-Rx-Cx-F1</a>      | CODE CORPCR3BAR CODE READER3900 MAH BATTERY<br>HANDLENO RADIONO CABLE   |
| <a href="#">Cr2512g-H2-R0-C0-F1</a>       |   |
| <a href="#">Xml-Cd-05</a>                 |   |
| <a href="#">Cr2611-C65-Pkcxu</a>          |   |
| <a href="#">Cr2ag-P1</a>                  |   |
| <a href="#">Cra-P23</a>                   |   |
| <a href="#">Cr1421-C501</a>               |   |
| <a href="#">Cr921-Pkrs-Cd5</a>            |   |
| <a href="#">Cr3512g-Hx-B2-Rx-C0-F1</a>    |   |
| <a href="#">Cr2512g-H2-C20-F1</a>         |   |
| <a href="#">Cr8011-Dk0</a>                |   |
| <a href="#">Cr1021-C500-C149</a>          |   |

|   |  |
|---|--|
| <a href="#">Cr4100-Rbw-Qw-F1</a>            | CODE, CR4100, WIFI, BT2.0, QWERTY, WHITE, CRADLE, CHARGER, USB CABLE, STYLUS, WM6.5  |
| <a href="#">Cr3012g-H2-Cx-F1</a>            |  |
| <a href="#">Cr1011-C501</a>                 |  |
| <a href="#">Cr1021-Mag-C501</a>             |  |
| <a href="#">Cr1021-Pkr2</a>                 |  |
| <a href="#">Cra-41-A2w</a>                  |  |
| <a href="#">Cr1021-Pkr3</a>                 |  |
| <a href="#">Xml-Cd-07</a>                   |  |
| <a href="#">Cr1428-C500</a>                 |  |
| <a href="#">Sp-Plus-Cr2</a>                 |  |
| <a href="#">Cr3012g-Bh1-Rx-C0-F1</a>        | CODECR3BAR CODE READER1950 MAH BATTERY HANDLENO RADIO6FT STRAIGHT USB CABLE INCLUDED   |
| <a href="#">Cr4405-Pkc1u</a>                |  |
| <a href="#">Cr3512g-Hx-Bx-Rx-Cx-F1</a>      |  |
| <a href="#">Cr921-Pku-Cd7-C252</a>          |  |
| <a href="#">Cr1011-C508</a>                 |  |
| <a href="#">Cr2512g-Hx-B2-R0-Cx-Fips-F1</a> |  |
| <a href="#">Cr1411-C501-F1</a>              |  |
| <a href="#">Bhtdg-M3-R2-C0</a>              |  |
| <a href="#">Cr3621-Dpmcxe</a>               | CODE, CR3600 DPM, SCANNER, PALM, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH EURO POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE |
| <a href="#">Sp-Plus-Cr3</a>                 |  |
| <a href="#">Cr4405-Pkxxx</a>                |  |
| <a href="#">Cra-41-E1</a>                   |  |
| <a href="#">Cr1210g-Cx-F1</a>               |  |
| <a href="#">Cr2ag-B2</a>                    |  |
| <a href="#">Cr2ag-Bh5</a>                   |  |
| <a href="#">Cr1210g-Pkr-F1</a>              |  |
| <a href="#">Cr1021-Pku8</a>                 |  |
| <a href="#">Cr1021-Mag-Pku8</a>             |  |



|  |  |
|--|--|
| <a href="#">Cr2321-Pkcmu</a>           |  |
| <a href="#">Cra-C508</a>               |  |
| <a href="#">Cr1021-C500-F1</a>         |  |
| <a href="#">Cr2012g-H2-C12-F1</a>      |  |
| <a href="#">Cr2512g-Pkwb202100130</a>  | CODE, CR2500, BAR CODE READER, KIT, PALM STYLE, BLUETOOTH RADIO, BATTERY, SINGLE BAY CHARGER, 6 FT. STRAIGHT USB CABLE, US POWER SUPPLY, M3 MODEM      |
| <a href="#">Cr2611-C138-Pkcmu</a>      |  |
| <a href="#">Cra-C5</a>                 |  |
| <a href="#">Cr1210g-Pku-F1</a>         |  |
| <a href="#">Cr1411-Pkr3</a>            |  |
| <a href="#">Cr2ag-A42</a>              |  |
| <a href="#">Cr1210g-C0-F1</a>          |  |
| <a href="#">Cr2611-Pkcya</a>           |  |
| <a href="#">Cra-A115</a>               |  |
| <a href="#">Cr2611-C65-Pkcxe</a>       |  |
| <a href="#">Cr2512g-Pkwbh16100130</a>  | CODECR2500BAR CODE READERKIT1950 MAH BATTERY HANDLEECS-H CHARGER W/BASE6 FT. STRAIGHT USB CABLEUS POWER SUPPLYM3 MODEM                                 |
| <a href="#">Cr3312g-Hx-B2-Rx-C0-F1</a> |  |
| <a href="#">Cr-Mobi-R</a>              |  |
| <a href="#">Cra-Us3</a>                |  |
| <a href="#">Cra-A119</a>               |  |
| <a href="#">Cr2512g-Pkwbh18100130</a>  | CODE, CR2500, BAR CODE READER, KIT, BLUETOOTH RADIO, 1950 MAH BATTERY HANDLE, ECS-H CHARGER W/BASE, 6 FT. STRAIGHT USB CABLE, US POWER SUPPLY, M3 MODE |
| <a href="#">Cr2512g-Bh2-R0-C0-F1</a>   |  |
| <a href="#">Cr3621-Pkcmu</a>           |  |
| <a href="#">Cr2012g-Hx-B2-R0-C0-F1</a> |  |
| <a href="#">Cr5020-C503</a>            |  |
| <a href="#">Bthdg-M3-R0-C0</a>         |  |
| <a href="#">Cr4405-Pkxxu</a>           |  |
| <a href="#">Cr2012g-Hx-B0-R0-Cx-F1</a> |  |
|  |  |

|   |  |
|---|--|
| <a href="#">Cr3012g-Hx-Bx-R0-Cx-F1</a>    |  |
| <a href="#">Cr2ag-A21</a>                 |  |
| <a href="#">Cr3500g-Bh5-C0-Js-A92</a>     |  |
| <a href="#">Cr1421-Mag-C501</a>           |  |
| <a href="#">Cr921-Pku-C216</a>            |  |
| <a href="#">Cr1421-Mag-Pkr2</a>           |  |
| <a href="#">Cr1421-C508-F1</a>            |  |
| <a href="#">Cr1200g-C12-F1</a>            |  |
| <a href="#">Cr921-Pku8</a>                |  |
| <a href="#">Sp-Plus-M</a>                 |  |
| <a href="#">Cr3312g-Bh2-Rx-C0-F1</a>      |  |
| <a href="#">Cr1411-C514</a>               |  |
| <a href="#">Cr2612-C65-Pkcxa</a>          |  |
| <a href="#">Cr1021-Pkr</a>                |  |
| <a href="#">Cr3ag-S1</a>                  |  |
| <a href="#">Cr6022-Pkr4</a>               | CODE, CR6000 DPM SCANNER, DARK GRAY, 8 FT COILED RS232 CABLE, STAND, UK POWER SUPPLY   |
| <a href="#">Cr2ag-C3</a>                  |  |
| <a href="#">Cra-C501</a>                  |  |
| <a href="#">Cr3012g-Bh2-R0-C1-F1</a>      | CODECR3BAR CODE READER3900 MAH BATTERY HANDLEBLUETOOTH RADIO8FT COILED RS232 CABLE INCLUDED  |
| <a href="#">Cr2ag-Ha1</a>                 |  |
| <a href="#">Cr3622-Dpmcxe</a>             | CODE, CR3600 DPM, SCANNER, HANDLE, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH EURO POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE |
| <a href="#">Cr2611-C65-Pkpmu</a>          |  |
| <a href="#">Cr3512g-Bh1-R0-Cx-Fips-F1</a> | CODE, CR3500, BAR CODE READER, FIPS, BATTERY HANDLE, WIRELESS  |
| <a href="#">Cr1200g-C1-F1</a>             |  |
| <a href="#">Cr3012gh2-C0-F1</a>           |  |
| <a href="#">Cr3621-Dpmcmu</a>             | CODE, CR3600 DPM, SCANNER, PALM, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH EMBEDDED MODEM, USB CHARGE CABLE                       |
| <a href="#">Cr1021-C509</a>               |  |

|  |   |
|--|---|
| <a href="#">Cr1021-C503-C151</a>           |   |
| <a href="#">Cra-C507</a>                   |   |
| <a href="#">Cr1011-Pkr3-F1</a>             |   |
| <a href="#">Cr1421-C500-F1</a>             |   |
| <a href="#">Cr2012g-H2-B0-Rx-C3-F1</a>     |   |
| <a href="#">Cra-A82</a>                    |   |
| <a href="#">Cr1411-Pku8-C65-F1</a>         |   |
| <a href="#">Cr921-C508</a>                 |   |
| <a href="#">Cr1421-Pku-C65-F6</a>          |   |
| <a href="#">Cra-C35</a>                    |   |
| <a href="#">Cr2ag-C30</a>                  |   |
| <a href="#">Cr3012g-H2-R0-Cx-F1</a>        |   |
| <a href="#">Cr2512g-Hx-B2-R0-Cx-C65-F1</a> |   |
| <a href="#">Cr3621-Pkcxe</a>               | CODE, CR3600, SCANNER, PALM, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH EURO POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE        |
| <a href="#">Cr1411-C514-F1</a>             |   |
| <a href="#">Cr1011-Pku-F1</a>              |   |
| <a href="#">Cr1421-Pku8</a>                |   |
| <a href="#">Cr1021-Mag-Pku</a>             |   |
| <a href="#">Cr1021-Mag-C503</a>            |   |
| <a href="#">Cr3012g-Bh2-R0-Cx-F1</a>       | CODE CORPCR3BAR CODE READER3900 MAH BATTERY HANDLEBLUETOOTH RADIONO CABLE   |
| <a href="#">Cr2611-Mag-Pkcxu</a>           | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH USB CHARGE CABLE, EXTERNAL M3 MODEM WITH USB COMM CABLE |
| <a href="#">Cr3012g-Hx-B0-Rx-Cx-F1</a>     |   |
| <a href="#">Cr2512g-Bh2-Rx-C0-F1</a>       |   |
| <a href="#">Cr3512g-Hx-B2-Rx-Cx-F1</a>     |   |
| <a href="#">Cr1011-C500</a>                |   |
| <a href="#">Cr1411-C500</a>                |   |
| <a href="#">Cra-A171</a>                   |   |
|  | CODECR3BAR CODE READER1950 MAH BATTERY  |

|  |  |
|--|--|
| <a href="#">Cr3012g-Bh1-R0-C1-F1</a>       | HANDLEBLUETOOTH RADIO8FT COILED RS232 CABLE INCLUDED |
| <a href="#">Cp3500-Bh5-C0-Js-A92-C302</a>  |  |
| <a href="#">Sp-Plus-Crfd</a>               |  |
| <a href="#">Sp-Plus-Cr1</a>                |  |
| <a href="#">Cr1421-C508</a>                |  |
| <a href="#">Cr1200g-Pkr-F1</a>             |  |
| <a href="#">Cr3621-Pkcxu</a>               |  |
| <a href="#">Cr1011-Pku</a>                 |  |
| <a href="#">Xml-Cd-06</a>                  |  |
| <a href="#">Cr1411-C514-C72</a>            |  |
| <a href="#">Cr2ag-C12</a>                  |  |
| <a href="#">Cr2512g-Hx-B0-R0-Cx-F1</a>     |  |
| <a href="#">Cr1200g-C3-F1</a>              |  |
| <a href="#">Cr2ag-A12</a>                  |  |
| <a href="#">Cr2ag-C7</a>                   |  |
| <a href="#">Cr3012g-Hx-B2-Rx-C0-F1</a>     |  |
| <a href="#">Cr2ag-A2</a>                   |  |
| <a href="#">Cr3622-C310-Pkcxb</a>          |  |
| <a href="#">Cra-A100</a>                   |  |
| <a href="#">Cr1021-Cx</a>                  |  |
| <a href="#">Cra-C514</a>                   |  |
| <a href="#">Cr2012g-Hx-Bx-R0-Cx-F1</a>     |  |
| <a href="#">Cr3512g-H2-Cx-F1</a>           |  |
| <a href="#">Cr25c65-Hx-Bx-R0-Ha5-Cx-F1</a> |  |
| <a href="#">Cr3012g-Hx-Bx-Rx-Cx-F1</a>     |  |
| <a href="#">Cr1411-Cx</a>                  |  |
| <a href="#">Cr2012g-H2-C20-F1</a>          |  |
| <a href="#">Cr1021-Bt-T500-P4</a>          |  |
| <a href="#">Cr921-Pkr</a>                  |  |
|  | CODECR3BAR CODE READER3900 MAH BATTERY HANDLENO      |

|  |   |
|--|---|
| <a href="#">Cr3012g-Bh2-Rx-C1-F1</a>   | RADIO8FT COILED RS232 CABLE INCLUDED  |
| <a href="#">Cr2611-C138-Pkpmu</a>      |   |
| <a href="#">Cr6022-C501-P3</a>         | CODE, CR6000 DPM SCANNER, DARK GRAY,RS232, 8 FT COILED RS232 CABLE, UK POWER SUPPLY   |
| <a href="#">Cr2012g-Hx-B0-Rx-C0-F1</a> |   |
| <a href="#">Cr2512gbh1r0cxc65</a>      |   |
| <a href="#">Cra-A62</a>                |   |
| <a href="#">Cr3512g-Bh5-F1-C301</a>    |   |
| <a href="#">Cr4405-Pkc2u</a>           | CODE, CR4405, IPHONE 5 SLED BAR CODE READER, LIGHT GRAY, BATTERY, CHARGING STATION, SPARE BATTERY, USB CABLE, CORTEX DECODER            |
| <a href="#">Cr2ag-Cv1</a>              |   |
| <a href="#">Cr1421-Pku-C65-F1</a>      |   |
| <a href="#">Cr2ag-S2</a>               |   |
| <a href="#">Cr3622-Pkcxu</a>           | CODE, CR3600, SCANNER, HANDLE, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH USB CHARGE CABLE, EXTERNAL M3 MODEM, USB COMM CABLE |
| <a href="#">Cr1411-Cx-F1</a>           |   |
| <a href="#">Cr921-Pku-C148</a>         |   |
| <a href="#">Cr2611-Pkcxu</a>           |   |
| <a href="#">Cr2611-Pkcmu</a>           |   |
| <a href="#">Cr3012g-Bh1-Rx-Cx-F1</a>   | CODE CORPCR3BAR CODE READER1950 MAH BATTERY HANDLENO RADIONO CABLE  |
| <a href="#">Cr3012g-Bh2-Rx-C3-F1</a>   | CODECR3BAR CODE READER3900 MAH BATTERY HANDLENO RADIO8FT COILED RS232 CABLE INCLUDEDUS POWER SUPPLY                                     |
| <a href="#">Cr2611-Pkxxx</a>           |   |
| <a href="#">Xml-Hr2</a>                |   |
| <a href="#">Cr2512g-Pkwbh14100130</a>  | CODE, CR2500 BAR CODE READER, BLUETOOTH, BATTERY HANDLE, ECS-H WITH BASE, 6 FT STRAIGHT USB CABLE, US POWER SUPPLY, M3 MODEM            |
| <a href="#">Cra-41-A2g</a>             |   |
| <a href="#">Cr1021-C503</a>            |   |
| <a href="#">Cr3622-Pkxxx</a>           |   |
| <a href="#">Cra-C7</a>                 |   |

|  |  |
|--|--|
| <a href="#">Cr2ag-Cv3</a>              |  |
| <a href="#">Cr1421-Cx</a>              |  |
| <a href="#">Cr1021-Mag-Pkr3</a>        |  |
| <a href="#">Cr3ag-Cv2</a>              |  |
| <a href="#">Cr2ag-P2</a>               |  |
| <a href="#">Cr2512g-H2-C30-F1</a>      |  |
| <a href="#">Cra-C34</a>                |  |
| <a href="#">Cr921-Pkr3-F0</a>          |  |
| <a href="#">Cr921-Pku-C222</a>         |  |
| <a href="#">Cr1411-C508-F1-C65</a>     |  |
| <a href="#">Cra-A118</a>               |  |
| <a href="#">Cr1411-C508-F1</a>         |  |
| <a href="#">Cr1411-Pkr-F1</a>          |  |
| <a href="#">Cr1411-C508-C65-F1</a>     |  |
| <a href="#">Cr2512g-H2-Cx-F1</a>       |  |
| <a href="#">Cr2012g-Hx-B0-Rx-C3-F1</a> |  |
| <a href="#">Cr3012g-Bh2-R0-C12-F1</a>  |  |
| <a href="#">Cr1021-Pku8-F1</a>         |  |
| <a href="#">Cra-A180</a>               |  |
| <a href="#">Cra-Us2</a>                |  |
| <a href="#">Cr3622-Pkcmu</a>           |  |
| <a href="#">Cr2012g-Bh2-R0-C0-F1</a>   |  |
| <a href="#">Cr1421-Pkr3</a>            |  |
| <a href="#">Cr3621-Dpmcxa</a>          | CODE, CR3600 DPM, SCANNER, PALM, DARK GRAY,<br>BLUETOOTH, BATTERY, CHARGING STATION WITH US<br>POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE |
| <a href="#">Cr3622-C309-Pkcxb</a>      |  |
| <a href="#">Cr1421-Mag-C503</a>        |  |
| <a href="#">Cr2012g-Hx-B2-Rx-C1-F1</a> |  |
| <a href="#">Cr8012-Dk2-F0</a>          |  |
| <a href="#">Cr1411-C508</a>            |  |

|   |   |
|---|---|
| <a href="#">Cr3012g-Bh1-R0-C0-F1</a>      | CODECR3BAR CODE READER1950 MAH BATTERY<br>HANDLEBLUETOOTH RADIO6FT STRAIGHT USB CABLE<br>INCLUDED               |
| <a href="#">Cr3012g-Bh1-Rx-C1-F1</a>      | CODECR3BAR CODE READER1950 MAH BATTERY HANDLENO<br>RADIO8FT COILED RS232 CALBE INCLUDED                         |
| <a href="#">Xml-Er3</a>                   |   |
| <a href="#">Bthdg-M3-R0-C20</a>           |   |
| <a href="#">Cr2ag-A41</a>                 |   |
| <a href="#">Cr3621-Pkcxb</a>              |   |
| <a href="#">Cr2ag-A11</a>                 |   |
| <a href="#">Cr25c65-Bh1-R0-Ha5-C20-F1</a> |   |
| <a href="#">Cr2ag-Cv6</a>                 |   |
| <a href="#">Cr2012g-Hx-B0-Rx-C12-F1</a>   |   |
| <a href="#">Cr1411-Pkr2-F1</a>            |   |
| <a href="#">Cr3512g-Pk2-Fips-F1</a>       | CODE, CR3500 KIT, FIPS, BH1 HANDLE, ECS-H CHARGER, US<br>POWER SUPPLY, 6FT STRAIGHT USB CABLE, M2 MODEM         |
| <a href="#">Sp-Prem-Cr1</a>               |   |
| <a href="#">Cr2012g-H2-C3-F1</a>          |   |
| <a href="#">Cr1021-Pku-F1</a>             |   |
| <a href="#">Cra-A117</a>                  |   |
| <a href="#">Cra-Mb5</a>                   |   |
| <a href="#">Cra-A181</a>                  |   |
| <a href="#">Cr3312g-Bh2-R0-C0-F1</a>      |   |
| <a href="#">Cr3312g-Bh2-R0-Cx-F1</a>      |   |
| <a href="#">Cr1421-Mag-C508</a>           |   |
| <a href="#">Cr4100-Rbw-Qw-F1-Openbox</a>  | OPEN-BOX, SOLD AS IS, CODE, CR4100, WIFI, BT2.0,<br>QWERTY, WHITE, CRADLE, CHARGER, USB CABLE, STYLUS,<br>WM6.5 |
| <a href="#">Cr1021-Cx-F1</a>              |   |
| <a href="#">Cr1411-Pku-C65</a>            |   |
| <a href="#">Cr921-Pkr2</a>                |   |
| <a href="#">Cr1421-Pkr</a>                |   |
| <a href="#">Cr1011-Cx</a>                 |   |
| <a href="#">Cr2012g-Bh2-R0-Cx-F1</a>      |   |

|  |  |
|--|--|
| <a href="#">Cr1021-Mag-Pkr</a>         |  |
| <a href="#">Xml-Cd-09</a>              |  |
| <a href="#">Cr3622-Dpmcxa</a>          | CODE, CR3600 DPM, SCANNER, HANDLE, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH US POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE   |
| <a href="#">Cra-41-A1w</a>             |  |
| <a href="#">Cr2611-C65-Pkcxa</a>       |  |
| <a href="#">Cr1411-C501</a>            |  |
| <a href="#">Cr8012-L00-Mt2-D1-C800</a> |  |
| <a href="#">Cr2012g-Hx-B0-Rx-C1-F1</a> |  |
| <a href="#">Cr3512g-Pk1-Fips-F1</a>    | CODE, CR3500 KIT, FIPS, BATTERY, SINGLE BAY CHARGER, US POWER SUPPLY, 6FT STRAIGHT USB CABLE, M2 MODEM                                       |
| <a href="#">Cr921-C500</a>             |  |
| <a href="#">Cr3012g-Bh1-R0-Cx-F1</a>   | CODE CORPCR3BAR CODE READER1950 MAH BATTERY HANDLEBLUETOOTH RADIONO CABLE  |
| <a href="#">Cr2611-Mag-Pkcmu</a>       | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH US POWER SUPPLY, EXTERNAL M3 MODEM WITH USB COMM CABLE |
| <a href="#">Cra-A126</a>               |  |
| <a href="#">Cr1021-C500</a>            |  |
| <a href="#">Cr2012g-Hx-B2-Rx-C0-F1</a> |  |
| <a href="#">Cr1421-C503-F1</a>         |  |
| <a href="#">Cr3512g-Bh2-R0-Cx-F1</a>   | CODE, CR3500, BAR CODE READER, 3900 MAH BATTERY HANDLE, BLUETOOTH RADIO, NO CABLE  |
| <a href="#">Cr2ag-C1</a>               |  |
| <a href="#">Cr5020-C500-DI</a>         |  |
| <a href="#">Cr5020-Bt-T500-P4</a>      |  |
| <a href="#">Sp-Prem-Cr3</a>            |  |
| <a href="#">Cr2012g-H2-C1-F1</a>       |  |
| <a href="#">Cr5020-Cx</a>              |  |
| <a href="#">Cr2012g-Hx-B2-Rx-C3-F1</a> |  |
| <a href="#">Cra-A145</a>               |  |
| <a href="#">Cr3512g-Bh2-R0-C0-F1</a>   | CODE, CR3500, BAR CODE READER, 3900 MAH BATTERY HANDLE, BLUETOOTH RADIO, 6FT STRAIGHT USB CABLE  |



| INCLUDED                                    |  |
|---|--|
| <a href="#">Bthdg-M2-R0-C0-Fips</a>         |  |
| <a href="#">Cr5020-C500</a>                 |  |
| <a href="#">Cr3512g-Bh2-F1-C301</a>         |  |
| <a href="#">Cr1421-Mag-Pku</a>              |  |
| <a href="#">Cr1021-C501</a>                 |  |
| <a href="#">Cr2512g-H2-C0-F1</a>            |  |
| <a href="#">Cr3512g-Hx-B2-R0-Cx-Fips-F1</a> | CODE, CR3500, BAR CODE READER, FIPS, 1950 MAH BATTERY                                  |
| <a href="#">Cr2512g-Hx-B0-Rx-C0-F1</a>      |  |
| <a href="#">Cr1021-Pkr2-F1</a>              |  |
| <a href="#">Cra-B5</a>                      |  |
| <a href="#">Cr1021-Mag-C507</a>             |  |
| <a href="#">Cra-41-P1-Us</a>                |  |
| <a href="#">Bthdg-M3-R0-C3</a>              |  |
| <a href="#">Cr1210g-C30-F1</a>              |  |
| <a href="#">Cr1421-C501-F1</a>              |  |
| <a href="#">Cra-T500-P4</a>                 |  |
| <a href="#">Cr1021-Mag-C500</a>             |  |
| <a href="#">Cr3512g-Bh2-C301-F1</a>         |  |
| <a href="#">Cra-W11b</a>                    |  |
| <a href="#">Cr1411-C500-F1</a>              |  |
| <a href="#">Cr1421-C508-C65</a>             |  |
| <a href="#">Cr2ag-C0</a>                    |  |
| <a href="#">Cr1411-Pku8</a>                 |  |
| <a href="#">Cr5025-C500</a>                 |  |
| <a href="#">Cr1421-Pkr-F1</a>               |  |
| <a href="#">Bthdg-M3-R0-C0-C65</a>          |  |
| <a href="#">Cr6022-C503</a>                 | CODE, CR6000 DPM SCANNER, DARK GRAY,RS232, 8 FT<br>COILED RS232 CABLE, US POWER SUPPLY |
| <a href="#">Cra-A116</a>                    |  |
| <a href="#">Cr3621-Pkxxx</a>                |  |
|   |  |

|  |  |
|--|--|
| <a href="#">Cr6022-Pkr</a>             | CODE, CR6000 DPM SCANNER, DARK GRAY, 8 FT COILED RS232 CABLE, STAND, US POWER SUPPLY   |
| <a href="#">Bthdg-M2-R0-C3</a>         |  |
| <a href="#">Cr1021-C501-F1</a>         |  |
| <a href="#">Cr2ag-A22</a>              |  |
| <a href="#">Cr2612-Pkcxu</a>           |  |
| <a href="#">Cr1021-C508</a>            |  |
| <a href="#">Bthdg-M3-R0-C1</a>         |  |
| <a href="#">Cr1011-Pkr2-F1</a>         |  |
| <a href="#">Cr2611-Mag-Pkcxu</a>       | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH EURO POWER SUPPLY, EXTERNAL M3 MODEM WITH USB COMM CABLE |
| <a href="#">Xml-5013</a>               |  |
| <a href="#">Cr1011-C503</a>            |  |
| <a href="#">Cr3312g-Hx-Bx-R0-Cx-F1</a> |  |
| <a href="#">Cra-41-P1-Jp</a>           |  |
| <a href="#">Cr1428-C500-C199</a>       |  |
| <a href="#">Cr921-Bt-T500-P4</a>       |  |
| <a href="#">Cra-C516</a>               |  |
| <a href="#">Cr1421-Pkr2</a>            |  |
| <a href="#">Cr8011-L00-Mt1-C800</a>    |  |
| <a href="#">Cr2611-Mag-Pkpmu</a>       | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS, BATTERY, MOUNTABLE PALM CHARGING STATION WITH EMBEDDED MODEM, USB CHARGE CABLE          |
| <a href="#">Cra-Us1</a>                |  |
| <a href="#">Cr2012g-Bh1-R0-Cx-F1</a>   |  |
| <a href="#">Cr2ag-C4</a>               |  |
| <a href="#">Cr1421-C503</a>            |  |
| <a href="#">Cr1021-Pkr-F1</a>          |  |
| <a href="#">Cra-A114</a>               |  |
| <a href="#">Cr6022-Cx</a>              |  |
| <a href="#">Xml-Er1</a>                |  |
| <a href="#">Cr4100-Rbw-Qg-F1</a>       | CODE, CR4100, WIFI, BT2.0, QWERTY, DARK GRAY, CRADLE, CHARGER, USB CABLE, STYLUS, WM6.5  |

|   |  |
|---|--|
| <a href="#">Cr1421-Mag-Pku8</a>             |  |
| <a href="#">Cr1421-C508-C65-F1</a>          |  |
| <a href="#">Cr1021-Mag-C509</a>             |  |
| <a href="#">Cra-A81</a>                     |  |
| <a href="#">Cr1411-Pku-F1</a>               |  |
| <a href="#">Cra-C511</a>                    |  |
| <a href="#">Cra-A146</a>                    |  |
| <a href="#">Cra-P21</a>                     |  |
| <a href="#">Cr2512g-Bh1-R0-C0-F1</a>        |  |
| <a href="#">Cr2012g-H2-B0-Rx-C0-F1</a>      |  |
| <a href="#">Cr4100-Rbwh-Qg-F1</a>           | CODE, CR4100, HSDPA, WIFI, BT2.0, QWERTY, DARK GRAY, CRADLE, CHARGER, USB CABLE, STYLUS, WM6.5                   |
| <a href="#">Cr1411-C514-C65</a>             |  |
| <a href="#">Cra-41-P1-Eu</a>                |  |
| <a href="#">Cr3012g-Bh2-Rx-C12-F1</a>       |  |
| <a href="#">Cr2512g-Hx-Bx-R0-Cx-Fips-F1</a> |  |
| <a href="#">Cr2321-Pkxxx</a>                |  |
| <a href="#">Cr1411-C500-C65</a>             |  |
| <a href="#">Cr-Mobi-M</a>                   |  |
| <a href="#">Cra-A150</a>                    |  |
| <a href="#">Cra-B6</a>                      |  |
| <a href="#">Cr1411-Pku8-F1</a>              |  |
| <a href="#">Cr3512g-Hx-B2-R0-C0-F1</a>      |  |
| <a href="#">Cr2512g-Hx-B2-R0-C0-F1</a>      |  |
| <a href="#">Cr2512g-Bh1-Rx-C0-F1</a>        |  |
| <a href="#">Cr3012g-Bh2-R0-C3-F1</a>        | CODECR3BAR CODE READER3900 MAH BATTERY<br>HANDLEBLUETOOTH RADIO8FT COILED RS232 CABLE<br>INCLUDEDUS POWER SUPPLY |
| <a href="#">Cr921-Pkr2-F0</a>               |  |
| <a href="#">Cr1021-C500-C135</a>            |  |
| <a href="#">Cr2611-Pkpmu</a>                |  |
|   | CODE, CR6000 DPM SCANNER, DARK GRAY, 6 FT STRAIGHT   |

|  |  |
|--|--|
| <a href="#">Cr6022-C500</a>                | USB CABLE  |
| <a href="#">Sp-Prem-Cr2</a>                |  |
| <a href="#">Cr3012g-Hx-B2-R0-C0-F1</a>     | CODECR3BAR CODE READERNO HANDLE1950 MAH BATTERYBLUETOOTH RADIO6FT STRAIGHT USB CABLE INCLUDED  |
| <a href="#">Cr1421-Pku8-C65</a>            |  |
| <a href="#">Cr3512g-Bh1-R0-Cx-F1</a>       |  |
| <a href="#">Cr2012g-Bh1-R0-C0-F1</a>       |  |
| <a href="#">Cra-41-A1g</a>                 |  |
| <a href="#">Cr1200g-C0-F1</a>              |  |
| <a href="#">Cr1011-Pkr-F1</a>              |  |
| <a href="#">Cr1421-Pku-F1</a>              |  |
| <a href="#">Cr2321-Pkcya</a>               |  |
| <a href="#">Cr3012g-Bh1-R0-C12-F1</a>      |  |
| <a href="#">Cr1200g-Pku-F1</a>             |  |
| <a href="#">Xml-Er2</a>                    |  |
| <a href="#">Cr2612-Mag-Pkcx</a>            | CODE, CR2600, SCANNER, HANDLE, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION WITH US POWER SUPPLY, EXTERNAL M3 MODEM WITH USB COMM CABLE         |
| <a href="#">Cr3512g-Bh5-C0-Js-A52-A304</a> | CODE, CR3500, BAR CODE READER, AGE VERIFICATION, CHARGER/MAGSTRIPE, 6 FT STRAIGHT USB CABLE, DL PARSING, PROTECTIVE CASE/HOLSTER, STATE OF UTAH SPECIF |
| <a href="#">Cr3012g-Hx-B0-Rx-C0-F1</a>     |  |
| <a href="#">Xml-Cd-08</a>                  |  |
| <a href="#">Cra-41-Cc1</a>                 |  |
| <a href="#">Cr8012-L00-Mt1-C800</a>        |  |
| <a href="#">Cr3012g-Hx-B2-Rx-Cx-F1</a>     |  |
| <a href="#">Cra-A121</a>                   |  |
| <a href="#">Cr921-Pkr3</a>                 |  |
| <a href="#">Cr1200g-Cx-F1</a>              |  |
| <a href="#">Cr3622-Dpmcxu</a>              | CODE, CR3600 DPM, SCANNER, HANDLE, DARK GRAY, BLUETOOTH, BATTERY, CHARGING STATION WITH USB CHARGE CABLE, EXTERNAL M3 MODEM, USB COMM CABLE            |
| <a href="#">Cr2611-Mag-Pkxxx</a>           | CODE, CR2600, SCANNER, PALM, LIGHT GRAY, BT, MAG LENS,   |

| BATTERY                                   |  |
|---|--|
| <a href="#">Cr3622-Dpmxxx</a>             |  |
| <a href="#">Cr6022-Pkr3</a>               | CODE, CR6000 DPM SCANNER, DARK GRAY, 8 FT COILED RS232 CABLE, STAND, EU POWER SUPPLY   |
| <a href="#">Cr1411-Pku8-F1-C65</a>        |  |
| <a href="#">Cr2512g-Bh1-R0-Cx-Fips-F1</a> |  |
| <a href="#">Cr5020-C502</a>               |  |
| <a href="#">Cr1421-Mag-Pkr3</a>           |  |
| <a href="#">Cr921-Pkrs2</a>               |  |
| <a href="#">Cr1021-Pkr3-F1</a>            |  |
| <a href="#">Cr2012g-Hx-Bx-Rx-Cx-F1</a>    |  |
| <a href="#">Cr921fd-Pku-F0</a>            |  |
| <a href="#">Cr2012g-Hx-B2-Rx-Cx-F1</a>    |  |
| <a href="#">Cra-A123</a>                  |  |
| <a href="#">Cr3512g-H2-R0-Cx-F1</a>       |  |
| <a href="#">Cra-A148</a>                  |  |
| <a href="#">Cr2ag-S1</a>                  |  |
| <a href="#">Cr1421-Mag-Cx</a>             |  |
| <a href="#">Cr3512g-Bh1-Rx-C0-F1</a>      |  |
| <a href="#">Cr1421-Pku8-F1</a>            |  |
| <a href="#">Cr2ag-Bh1</a>                 |  |
| <a href="#">Cr25c65-Wb20210013</a>        | CODE, CR2500, BAR CODE READER, KIT, BLUETOOTH RADIO, SINGLE BAY CHARGER, 6 FT. STRAIGHT USB CABLE, US POWER SUPPLY, M3 MODEM MCKESSON SOFTWARE |
| <a href="#">Cr1421-Mag-C500</a>           |  |
| <a href="#">Cr1210g-C12-F1</a>            |  |
| <a href="#">Cr2012g-Hx-B2-R0-Cx-F1</a>    |  |
| <a href="#">Cr2612-Mag-Pkcmu</a>          | CODE, CR2600, SCANNER, HANDLE, LIGHT GRAY, BT, MAG LENS, BATTERY, CHARGING STATION W/EMBD. MODEM, USB CHARGE CABLE                             |
| <a href="#">Cra-U12</a>                   |  |
| <a href="#">Cr3512g-Bh2-Rx-Cx-F1-C301</a> |  |
| <a href="#">Cr3312g-Hx-Bx-Rx-Cx-F1</a>    |  |

|  |  |
|--|--|
| <a href="#">Cr3622-Pkcxa</a>             | CODE, CR3600, SCANNER, HANDLE, DARK GRAY,<br>BLUETOOTH, BATTERY, CHARGING STATION WITH US<br>POWER SUPPLY, EXTERNAL M3 MODEM, USB COMM CABLE |
| <a href="#">Cra-41-S1</a>                |  |
| <a href="#">Cr2ag-P3</a>                 |  |
| <a href="#">Cr8011-L00-Mt2-D1-C800</a>   |  |
| <a href="#">Cr2512gbh1r0cxf1</a>         |  |
| <a href="#">Cr1411-C508-C65</a>          |  |
| <a href="#">Cr2ag-A1</a>                 |  |
| <a href="#">Cra-A151</a>                 |  |
| <a href="#">Cr1411-C503-F1</a>           |  |
| <a href="#">Cr1411-Pku-C65-F1</a>        |  |
| <a href="#">Bthdg-M2-R0-C0-C160-Fips</a> |  |