

Contrinex

Garanti: 12 ay
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin info@yursat.com.tr e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.
Contrinex Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

Firmamız Contrinex Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.



| rn | Aıklama |
|------------------------------------|---|
| Dw-As-513-M18-002 | |
| DW-AS-613-M8 | (320-620-034) |
| LTR-M05MA-NSS-403 | (620-600-384) This is the successor to the requested and now discontinued: LTS-1050-303-505 |
| DW-AS-613-M8 | 10-30VC DC 2.5mm Switch |
| YBB-30S4-0900-G012 | 630-000-591) |
| YBB-30R4-0900-G012 | 630-000-687 |
| LHR-C23PA-PMS-101 | |
| LTK-1050-301 | |
| DW-AS-523-M12 | 330-020-158 |
| DW-AS-623-M8-123 | |
| DW-AS-503-P12-627 | INDUCTIVE SENSOR |
| LHR-C23PA-PMK-603 | |
| DW-AS-503-M12 | Inductive proximity switch, M12, Sn 6mm, installation flush, PNP clasp |

| | |
|---|---|
| DWAS 613 M8 001 | inductive proximity sensor, 2.5 mm, PNP normally open |
| DWAS 613 M18 002 | inductive proximity sensor, 8.0 mm, PNP normally open 1 piece available from stock, for further quantities Unfortunately no Temrin known yet. |
| DW-AS-623-C8-001 | |
| Dw-As-603-M8-129 | |
| DW-AD-633-M8 | |
| DWAS 513 M18 002 | inductive proximity sensor, 20.0 mm, PNP normally open |
| +DWAV-503-P5-276 | High pressure extra distance series 500 M5 embedable 1 m |
| DWAS 621M12 120 | inductive proximity sensor |
| DWAS 623M12 120 | inductive proximity sensor |
| DW-AS-63A-C44 | |
| DWAS 613 M8 001 | inductive proximity sensor, 2.5 mm, PNP normally open |
| DW-AS-509-M18-320 | |
| Proximity Switch DW-AS-613-M18-002 | 10-30VCDV,PX/2000HZ |
| +DWAS 623 M5 | Inductive proximity sensor M5 |
| +DWAS 624 M5 | Inductive proximity sensor M5 |
| DW-AD-623-C5 | |
| DW-AD-624-C5 | |
| DW-AS-513-M12 | |
| DW-AD-624-C5 | |
| DW-AS-503-M30-120 Sensor | |
| DW HD 60 M18 411 | |
| Contrinex: DW-AS-633-M8-001 | This switch has a stainless steel housing and 3500 HZ |
| DW-AS-611-C44 | |
| DWAD 623 M5 | inductive proximity sensor, 1.5 mm, PNP normally open |
| Dw-As-624-M5 Induktiver Sensor | |
| Dw-As-509-M12-390 Sensor Inductive320-020-104 | |
| Dw-As-603-M30-120 Induktiver Sensor | |
| V12-4tpd-001-Un0 | |
| 320-420-203 Induktiver Sensor | |

[P/N: 630-000-592, Type: Ybb-30s4-1000-G012](#)

[Lts-1050-303 Sensor](#)

[P/N: 630-100-132, Type: Yca-50s4-3500-D100-69k](#)

[Dwad500m12](#)

[Lts-1120-304](#)

[Lhs-1180w-303](#)

[S12-3fvw-050-921](#)

CONNECTOR-CABLES

[Dw-Ad-601-M30](#)

[Dw-Ad-423-M8](#)

[S12-4fvw-100-921](#)

CONNECTOR-CABLES

[320-920-332 Sensor Dw-Av-623-M5-278](#)

[B1100-Vf-Xc](#)

[Llk-1180w-000](#)

[Lrs-1180-301](#)

[S083fvw020023](#)

[620-400-120 Lls-4040-003-305](#)

[P/N: 630-100-128, Type: Yca-50r4-4400-D050-69k](#)

[Dw-As-623-C8-001 Sensor](#)

[Dw-Dd-615-M30-9005](#)

[P/N: 630-000-582, Type: Ybb-30s4-1300-D100](#)

[Dw-Hd-613-M50-502](#)

[Lxr-0000-084](#)

[P/N: 630-100-117, Type: Yca-50r4-6300-D100-69k](#)

[320-120-007 Sensor Dw-As-503-C8](#)

[Dw-Ad-601-M12 Induktiver Sensor](#)

[320-520-531 Sensor Dw-As-503-M8-001 Sin500_Basic_M8](#)

[Dw-As-603-M30-120 Sensor](#)

| |
|--|
| Dw-Ad-503-M5 |
| Dw-As-623-M5 Sensor |
| Lhs-1180w-301 |
| Dw-Ad-503-M12 Sensor |
| Dw-As-503-M8-001 Sensor |
| P/N: 630-000-663, Type: Ybb-30r4-0900-D050 |
| Bd20-I3-M30-Ex-298 |
| S12-3fug-080-12mg |
| Ltr-M05ma-Nsv-301 (620-600-348) Photoelectric Sensor |
| P/N: 630-000-588, Type: Ybb-30s4-0500-G012 |
| P/N: 630-100-126, Type: Yca-50s4-4400-D100-69k |
| Dw-As-702-M8 Sensor (320-020-172) |
| Asu-3012-180 Mounting Bracketbride Inox M24 Pour Detecteur M18 |
| Dw.Hd.613.M50.411 |
| P/N: 630-000-667, Type: Ybb-30r4-1400-D050 |
| Llk-1040-202 |
| Nd12-S3-M18s |
| P/N: 630-100-138, Type: Yca-50s4-6300-G012-69k |
| Dw-Ad-703-M30-295 Induktiver Sensor |
| Dw-As-703-M8-001 |
| S123fvg020921 |
| P/N: 630-000-589, Type: Ybb-30s4-0700-G012 |
| Lls-1050-201 |
| Dw-As-633-M8-732 Positionssensor Sin600 Extemp M8 |
| Dw-As-703-M12 |
| Dw-Ad-703-M8 |

[Lts-1180-103](#)

[Dw-Ad-509-M30-120 \(320-020-114\)](#)
[Sensor 10 ... 30 V](#)

[Dw-As-624-M18-002 Sensor 320-820-129](#)

[Dw-Ad-503-M12-245](#)

[Ltk-1180w](#)

[Ltk-1040-303](#)

[320-520-214 Dw-As-633-M8-732](#)

[Dw-As-503-M18-002](#)

[Lls-1181l-001](#)

[Llk-1120-202](#)

[320-120-458 Dw-Av-603-M5-278sensor](#)

[Dw-Ad-711-M8](#)

[320-420-053 Dw-As-503-Pc](#)
[Sin500 Hipresspc](#)

[Lls-1180w-003](#)

[Llk-1040-203](#)

[P/N: 630-000-587, Type: Ybb-30s4-0400-G012](#)

[S12-3fvg-020-015](#)

[Dw-As-624-M8-123 Sensor](#)

[P/N: 630-100-122, Type: Yca-50r4-3400-D050-69k](#)

[Dw-As-503-M30-002](#)

[Lrk-1180w-302](#)

[320-120-118 Dw-As-501-P20](#)

[P/N: 630-000-591, Type: Ybb-30s4-0900-G012](#)

[Lrs-1180w-304](#)

[Lrs-1180w-303](#)

[Prk-5555-3520-40-Jw](#)

[Dw-As-501-P20 Inductive Sensor](#)

| |
|--|
| Dw-Ad-503-M12 Inductive Proximity Sensor(M12, Cabele 2m, Pnp-Closer) |
| Las-3130-109 |
| Dwad513m8 |
| Dw-As-713-M18-002 |
| P/N: 630-100-115, Type: Yca-50r4-6300-D020-69k |
| Lls-1180w-004 |
| Dw-As-703-M8 Sin700 Extremem8320-020-173 |
| S12-4fug-050-Nnnq |
| Dw-Ad-607-C40 Sensor |
| Llk-1180w-004 |
| Dw-Ad-509-M30-320 |
| Lhk-1180w-303 |
| Dw-Ad-603-M10e-637 |
| Dw-As-603-M5 |
| Dwas503m12 |
| Llk-1050-203 |
| 620-200-785 Lts-1050-303-505 |
| 320-820-028 Dw-As-623-M12 |
| Dw-As-623-M5 (320-920-275) Sensor |
| Dw-As-501-P20 Sensor Contrinex Dw-As-501-P20 |
| Dw-Ad-621-M12 |
| Lts-1040-301 |
| Lhs-3131-303 |
| Llk-1120-201 |
| Rit-1491-000 |
| RFID INTERFACE GATEWAY |
| Sensor Dw-As-501-P20 |
| Lrk-1120-304 |
| Dw-As-603-065-123 Sensor |
| Dw-Ad-503-M18 Sensor |

| |
|---|
| P/N: 630-100-139, Type: Yca-50r4-6300-G012-69k |
| Lts-1040-303 |
| 320-820-028 Induktiver Sensor Dw-As-623-M12 |
| Dw-As-623-M12-M12-4mm-Pnp |
| Der Sensor Dw-Av-501-P20-276 |
| Dw-As-509-M12-390 (320-020-104)induktiver Sensor |
| Llk-1121l-201 |
| Dw-As-623-M8-123 Sensor |
| Llk-1180w-203 |
| P/N: 630-100-136, Type: Yca-50s4-5300-G012-69k |
| Dw-Ad-623-C5 |
| 320-920-242 Sensordw-As-603-M8-129 |
| Lhr-C12pa-Nsv-303 Lichtschanke |
| Dw-As-501-P20 |
| Lls-1180w-200 |
| P/N: 630-100-135, Type: Yca-50r4-3500-D100-69k |
| Lts-1050-303 (620-200-783) Photoelektrischer Sensor |
| Lts-1050-301-506 |
| Dw-Dd-615-M30 Induktiver Sensor(220-820-215) |
| Llk-1180-200-005 Sensor |
| 320-020-119 Dw-Ad-509-M12-320sensor |
| Lhs-3131-303 Inhaltssensor Rohre |
| Llk-1040-201 |
| Lhs-3131-303 Sensor |
| Dw-Ad-503-P12-625 |
| Dw-As-603-M8-123 (320-520-256) Sensor |

| |
|---|
| 320-920-280 Dw-As-624-M5 |
| Df-As-63a-C44 |
| P/N: 630-100-112, Type: Yca-50s4-6300-D020-69k |
| P/N: 630-000-590, Type: Ybb-30s4-0800-G012 |
| Lrk-1180w-301 |
| Cx320520760 |
| Lts-1040-303-505 |
| Dw-Ad-403-C5 |
| Dw-Ad-503-P12-627 |
| Dwad423065200 |
| Lts-1180-303 Sensor |
| Dw-As-63a-C44 |
| Dw-As-503-P20 Sensor Die Position Des Zylinders |
| Dw-As-519-M18-390 |
| Lls-1180w-203 |
| Dw-Av-501-P20-276 Contrinex Dw-Av-501-P20-276 |
| Lls-1180w-000 |
| Dw-Ad-711-M5 |
| Dw-As-623-M8-123 (320-520-264) Inductive Sensor |
| Lrs-3030-103 Photovoltaischer Sensor620-000-215 |
| Lrs-1120-304 |
| P/N: 630-100-127, Type: Yca-50r4-4400-D020-69k |
| Llk-1180-200-005 Photoelektrischer Sensor 620-200-603 |
| Lls-1181l-002 |
| Lhk-1180-302 |
| Dw-Ad-623-M8 |
| P/N: 630-000-665, Type: Ybb-30r4- |

| |
|---|
| 1200-D050 |
| Llk-1121l-200 |
| Ar-P-N-Pnp-Npn-Nr |
| S12-4fvg-050-12mg |
| 320-820-804 Sensor Dw-As-603-M30-120 |
| 620-200-305 Optischer Sensor Ltk-1120-303 |
| Dw-Ad-613-C40 |
| +DWAS 511 M8 001 Contrinex Dw-As-511-M8-001 |
| Llk-1120-204 |
| P/N: 630-100-113, Type: Yca-50s4-6300-D050-69k |
| Dw-Ad-604-M18 Sensor |
| Dw-Ad-603-C5 Induktiver Sensor |
| Lhk-1180-304 |
| Llk-1180w-001 |
| Dw-As-614-M30-002 Induktiver Sensor |
| 320-020-138 Dw-As-519-M30-3 90 Sin500 Analog M 30 |
| Dw-Ad-509-M12 Induktiver Sensor |
| Llk-3031-202 |
| Lhs-1180-304 |
| Dw-As-503-P20g-Lh |
| Llk-1180-001 |
| Dw-As-509-M12-390 Sensor Analog |
| Lls-1180-000 |
| 220-020-425 Dw-Ad-602-M5 |
| 320-820-036 Dw-As-621-M12-120 |
| 320-920-242 Dw-As-603-M8-129 |
| 623-100-102 S08-3fvg-020 Concon Connabstd |
| 320-420-107 Dw-Ad-509-C8-390 |

| |
|---|
| Lrs-1180-304 |
| Dw-As-61a-C44 |
| Dw-Ad-713-M12 |
| Dw-As-623-M12-120 Non-Contact Switch Inductived=12,0mm L=45,0mm 10...30vdc Pnp No Led |
| Llk-1181w-003 |
| Dw-Ad-702-M12-298 |
| Dw-Dd-615-M30-120 Induktiver Sensor(220-820-245) |
| Lhs-1180-303 |
| Llk-1180-204-005 Sensor |
| Llk-1180w-204 |
| 600-000-005 Ate-0000-002 Acctestsentest |
| Lls-1121l-203 |
| 320-420-103 Inductives Dw-Av-501-P20- 276 |
| P/N: 630-100-121, Type: Yca-50r4- 3400-D020-69k |
| Dw-Ad-602-M5 Sensor |
| Ltk-1040-303-305 |
| Ltk-1040-301 |
| Dw-As-603-M12-120 |
| Dw-As-603-M30-002 Induktiver Sensor |
| Dw-As-623-M18-002 Induktiver Sensor |
| S12-3fvw-020 |
| Dwas623m12 |
| Lts-1180-103 Optischer Sensor |
| Dwas423m8001 |
| Dw-As-623-M8-001 Sensor |
| Dw-As-713-M12 Sensor |
| Lfk-3030-103 |
| Lhs-1180w-304 |

| |
|--|
| Dwas513m8m |
| Lts-1050-301 |
| Lts-1180 |
| 320-520-911 Sensordw-As-503-P20 20 Sin500 Hipressp |
| P/N: 630-000-584, Type: Ybb-30s4- 1600-D100 |
| Lrs-1180-303 |
| Lls-1120-201 |
| P/N: 630-100-134, Type: Yca-50r4- 3500-D050-69k |
| Dw-As-503-P12-627 Induktive Sensor |
| CONTRINE DW-AD-509-M18-320 Sensor |
| Dw-As-703-M8 |
| 320-020-139 Sensor Dw-Ad-519-M30- 320sin500 Analog M30 |
| Cx320420632 |
| 320-820-003 Dw-Ad-603-M12 |
| Lrs-1180-304 |
| Dw-As-603-065-123 (320-520- 284)induktiver Sensor |
| Dwac540m12g |
| Lls-1121l-200 |
| Dw-As-807-M12 |
| Dw-Hd-613-M50-440 |
| Sensor Touch Dw-Av-603-M5-278 |
| Dw-Ad-613-M8 |
| Dw-As-623-M5 (320-920-275) Induktiver Sensor |
| Dw-As-513-M12 Sensor |
| 320-820-747 Dw-Ad-613-M30-295 |
| Dw-Ad-604-M5-290 Sensor10-30 Vdc, 200 Ma, 0.8 Mm, Npn/Nc |

| |
|---|
| Dw-32-52-P |
| Dw-As-509-M30-320 (320-020-124) |
| Nd25-H3-M50-20mt-230 |
| 320-820-026 Dw-As-621-M12 |
| P/N: 630-100-133, Type: Yca-50r4-3500-D020-69k |
| Lls-1180w-202 |
| Dw-As-613-M30-002 Sensor Contrinexdw-As-613-M30-002 |
| 320-920-280 Inductive Sensordw-As-624-M5 |
| Dw-As-703-M8 Steckverbinder Mit Einem Stecker Zum Sensor 2 M Dw-As-703-M8 |
| Dw-Ad-509-C8-390 DC15-30V,4mm,8 X 8 X 50MM,OUTPUT:0-10V |
| 320-520-170 Dw-As-623-M8-001 |
| Dw-As-503-P20 Sensor-Positionierung |
| Dw-As-509-M12-120sensor |
| Sensor Lts-1180-304 Reflexions-Lichttaster |
| Dw-As-633-M8-732 Stellungsgeber |
| Dw-Ad-519 |
| Dw-As-509-C8-404 |
| 204-100-041 Buchse Montageasu-3012-180 |
| Dw-As-623-M18-002 |
| Dw-As-623-M8-001 Induktiver Sensor (320-520-170) |
| 220-320-013 Induktiver Sensor Der Contrinex Dw-Ad-623-M4 |
| P/N: 630-000-661, Type: Ybb-30r4-0700-D050 |
| Dw-Av-603-M5-278 |
| P/N: 630-100-140, Type: Yca-50s4-3400-G012-69k |
| Dw-Ls-713-M12 |
| 320-420-218 W-As-713-M12 |

| | |
|---|--------------------------------|
| Lrs-5050-103-9002 | |
| Dw-Ad-601-M30 Sensor | |
| P/N: 630-100-123, Type: Yca-50r4-3400-D100-69k | |
| Dw-As-503-M8-001 | |
| Lts1050303 | |
| P/N: 630-000-651, Type: Ybb-30r4-0900-D020 | |
| 320-820-627 Dw-Ad-613-M18-245 | |
| Lls-1180-002 | |
| Dw-As-624-M8-123 Induktiver Sensor | |
| P/N: 630-000-594, Type: Ybb-30s4-1300-G012 | |
| Ate-0000-002 Tester Sensoren | |
| Asu-3112-080 | |
| Dw-As-603-M8-124 | Inductive sensor (320-920-518) |
| 320-520-284 Dw-As-603-065-123sensor | |
| Ltk-0507-303-501 Inhaltssensor | |
| 320-520-909 Dw-As-501-P20 | |
| Ltk-1050-303-505 | |
| Dwas513m8 | |
| Llk-1180-000 | (620-200-541) |
| Dw-As-503-P20 Cylinder Position Sensor | |
| S12-4fvw-050 | |
| 621-000-237 Lfp-1006-020 | |
| Dw-Ad-403-M5e | |
| 620-400-013 | |
| Lls-1180-001 | |
| Llk-1181w-002 | |
| 320 520 264 Induktiver Sensor Dw-As-623-M8-123 Pnp No | |
| Dw-As-623-065-129 | |

| | |
|---|---|
| S12-4mug-050 | |
| Dw-Av-703-M18-613 Sensordetect Induct D18 Connect M12 Lg150 Sn10 | |
| Ifp 02351-93650 | |
| Dw-As-703-M12 Induktiver Sensor | |
| 320-820-208 Induktiver Sensor Dw-As- 603-M30-002 | |
| Llk-1050-202 | |
| Dw-As-519-M30-390 | |
| 620-200-711 Lhs-1180-303-508 | |
| Dw-As-503-P20g Sensor | |
| Dw-As-603-M8-129 Induktiver Sensor | |
| P/N: 630-000-649, Type: Ybb-30r4- 0700-D020 | |
| Cx220220779 | |
| Ltk-1180l | |
| Lls-1040-202 | |
| Dw-As-623-M8 (320-620-030) Inductive Sensor | |
| Dwac543m12w | |
| Lhs-1180-303 Sensor | |
| Lrs-1120-303 | |
| S12-4fug-100-12mg | |
| P/N: 630-000-662, Type: Ybb-30r4- 0800-D050 | |
| Asu-3012-180 Zylindrische Sensorhalter(204-100-041) | |
| Dw-As--509-M12-390 Induktiver Sensor | |
| 320-120-393 Dw-Ad-513-M30-120 | |
| Dw-Ad-703-M30-295 Induktiver Endschalterm30x1.5, 10-30vdc, Pnp No- Type, Ip68 | |
| INS8S4PO45-M8 | Inductive proximity switch, M8 design, M8 connector, total length 45.0 mm, brass sleeve, 4 mm quasi-flush, 10-30 VDC, pnp, NO, 200 mA, 500 Hz, IP 67, LED |

| | |
|--|------------------|
| P/N: 630-100-131, Type: Yca-50s4-3500-D050-69k | |
| Rtp-0263-020 Transponder | |
| Ltk-3031-303 Sensor Lichtschranke | |
| 320-920-275 Dw-As-623-M5 | |
| Dw-Ad-404-M5-290 Sensor | |
| Lls-1040-203 | |
| Dw-Ad-602-M5 Npn Sensor | |
| Dw-As-614-M18-002 Induktiver Sensor | |
| S12-4fvg-100-921 | CONNECTOR-CABLES |
| Lts-1050-301-505 | |
| 320-020-139 Dw-Ad-519-M30-320 | |
| Ltk 3030-103-309 | |
| Dw-As-403-M5 | |
| Dw-As-503-M30-120 | |
| P/N: 630-000-596, Type: Ybb-30s4-1600-G012 | |
| Dw-As-503-P200 Sensor | |
| Dw-As-604-M8-001 | |
| Aa01.343.077 | |
| 320-420-345 Induktiver Sensordw-Ad-703-M30-295 | |
| Llk-1180-002 | |
| 320-120-304 Dw-As-513-M18-006 | |
| P/N: 630-100-137, Type: Yca-50r4-5300-G012-69k | |
| Dw-As-509-M30-320 Sensor | |
| Dw-As-503-M8 Sensor | |
| Lrs-1180w-302 | |
| Dw-Hd-613-M50-503 | |
| Df-Ad-601-C1735 | |
| Lts-1120-303 | |
| Lts-1050-303 (620-200-783) Sensor | |

| |
|---|
| Llk-1120-200 |
| Dw-As-509 |
| Dw-As-702-M8 Sensor(320-020-172) |
| Dw-As-519-M18-390 Sensor Analog U=15-30vdc Ua1=0- |
| P/N: 630-000-650, Type: Ybb-30r4- 0800-D020 |
| Lls-1180w-002 |
| Dw-Ad-403-04 |
| Dw-As-513-M8 |
| Dw-As-623-M8-123 |
| P/N: 630-100-142, Type: Yca-50s4- 4400-G012-69k |
| Lls-1181l-004 |
| Llk-1181w-004 |
| 620-200-828 Ltk-0507-303-502 |
| Ltk-1120-303 (620-200-305) Der Optische Sensor Ltk-1120-303 10 ... 36 V |
| Dw-As-623-M8 Induktiver Sensor |
| 320-820-104 Dw-Ad-604-M18 |
| Ltk-1040-301-506 |
| P/N: 630-000-652, Type: Ybb-30r4- 1000-D020 |
| P/N: 630-000-658, Type: Ybb-30r4- 0250-D050 |
| Lrs-1180-302 |
| Lls-1120-204 |
| Lls-1120-202 |
| Dwar503m18 |
| Dw-Dd-615-M30 |
| P/N: 630-000-653, Type: Ybb-30r4- 1200-D020 |
| Ltk-1040-303-306 |

| |
|--|
| Lrk-1180w-304 |
| Lrk-1180w-303 |
| Dw-As-611-M18-002 Induktiver Sensor |
| 320-020-403 Dw-Ad-604-M5-290 |
| Obt200-18gm60-E5-V1 Obt200-18gm60-E5-V1 , Reflex-Lichttaster |
| Dw-As-617-M18-002 |
| P/N: 630-000-659, Type: Ybb-30r4-0400-D050 |
| Dw-As-623-M8-001 Pnp No Induktiver Sensor |
| Dw-As-703-M8 Inductive Sensor(320-020-173) |
| 320-520-214 Dw-As-633-M8-732 Sensor |
| Lls-1120-203 |
| Llk-1121l-204 |
| 330-020-112 Dw-Ad-503-M12-245 |
| Dw-Ad-423-065-290 |
| Dw-As-513-M8-001 Sensor |
| 320-520-911 Dw-As-503-P20 Sin500 Hipressp 20 |
| Dw-As-501-M12 |
| 320-920-236 Dw-As-603-M5induktiver Sensor |
| Lrk-5050-115 - FlieŐband-Sensor |
| Dw-As-523-P12-635 |
| 320-620-038 Sensor Dw-As-603-M8 |
| P/N: 630-000-664, Type: Ybb-30r4-1000-D050 |
| Lls-1040-204 |
| Dw-Ad-603-M8 Sensor |
| Dw-As-624-M5 Induktive Sensor |
| Lrk-1120-301 |
| P/N: 630-100-143, Type: Yca-50r4- |

| |
|---|
| 4400-G012-69k |
| Dw Ac41020w |
| Lts1120303 |
| S12-4fug-100 |
| Dwad303m4 |
| Lls-1180-003 |
| Dw-Ad-703-M30-295 Contrinex Dw-Ad-703-M30-295induktiver Sensor, Ganzmetall, M30, 5m Pur-Kabel |
| Dw-As-624-M12 Contrinexdw-As-624-M12 |
| Vkhm-W-5/4 |
| Dwas503m8m |
| Dw-As-624-M5 Sensor |
| 620-200-785 Sensor Lts-1050-303-505 |
| Cx320020153 |
| S12-4fvw-020-Nnln |
| Ltk-1050-301 |
| Dw-Ad-603-M18 |
| Dw-As-519-M18-390 Sensor Analog |
| P/N: 630-100-130, Type: Yca-50s4-3500-D020-69k |
| Dw-As-519-M18-390 Sensor Inductive320-120-495 |
| Llk-1040-204 |
| 620-200-783 Lts-1050-303 Speminidiff |
| Dw-Ad-501-M8 P/N 320 520 501 |
| Lhs-1180w-302 |
| Bd8-S3-M18 |
| P/N: 630-100-144, Type: Yca-50s4-3500-G012-69k |
| Lls-1121l-201 |
| Lrk-1180-303 |
| S08-3fvg-050 Kabeldose |

| | |
|--|-------------------|
| Llk-1180w-200 | |
| Dw-As-501-P20 (320-520-909) 429689 A 3mm Npn N0 | |
| Dw-Ad-617-M18 | |
| 204-100-041 Asu-3012- 180accmoi Moun Qt | |
| Lrk-1180-302 | |
| Dw-As-603-M12 10-30vdc Sensor Drehzahl | |
| Dw-Ad-509-M12-320 | |
| Dw-As-509-M12-390 | DW-AS-509-M12-390 |
| 605-002-138 S12-3fuw-050- Ynnnconnectivity | |
| Dwad423m8 | |
| Lhk-1180-303 | |
| Dwas423065001 | |
| 620-200-783 Sensor Contrinex Lts-1050- 303 | |
| Dw-As-502-M18 | |
| Dw-Ad-703-M18-120 Inductive Sensor | |
| Lls-1120-200 | |
| Dwac41020g | |
| Inkt 121405 Induktiver Sensor | |
| 620-200-305 Der Optische Sensor Ltk- 1120-303 | |
| P/N: 630-000-646, Type: Ybb-30r4- 0250-D020 | |
| Dw-As-624-M8-123 (320-520-265) Inductive Sensor | |
| Dw-As-501-P20 Induktiver Sensor (320- 520-909) | |
| Dw-Ad-703-M12-10 Sensor 30vdc 200ma Pnp-S 6 Mm - N0 | |
| Contrinex LTR-M05MA-NMK-301 | LTR-M05MANMK301 |
| E1100-Gp-Hc | |

| |
|--|
| Rls-1183-020 Read/Write Modul(720-100-104) |
| 320-520-060 Dw-As-513-M12 |
| P/N: 630-100-120, Type: Yca-50s4-3400-D100-69k |
| Dw-Ad-617-M30 |
| Lts-1180l |
| Dw-As-513-M8-001 |
| S12fvw020921 |
| Dw-Ad-623-03 Dw-Ad-623-03 / Neu: Lagerartikel Induktivschalter 3mm Glatt; Sn 1mm, Kabel, Pnp |
| Lls-1050-203 |
| Llk-1050-204 |
| 320-020-119 Dw-Ad-509-M12-320 |
| P/N: 630-000-593, Type: Ybb-30s4-1200-G012 |
| Dw-Av-403 M5-278 Sensor P/N 320 920 332 |
| Dw-As-623-M12 |
| S12-3fvw-100-921 |
| CONNECTOR-CABLES |
| Dw-As-613-M30-002 Induktiver Sensor |
| P/N: 630-100-119, Type: Yca-50s4-3400-D050-69k |
| Dw-Ad-623-M12-159 050886 C Induktiver Sensor |
| Ltk-1050-303 |
| 320-820-747 Induktiver Sensor Dw-Ad-613-M30-295 |
| Dw-Ad-403-C5 Inductive Sensor, 320 020 475 |
| Llk-1120-203 |
| Llk-1121l-203 |
| S12-4fug-100-Nnnq |
| Dw-As-503-M18-002 Induktiver Sensor |
| P/N: 630-000-647, Type: Ybb-30r4- |

| | |
|---|---------------|
| 0400-D020 | |
| Llk-1180-003 | (620-200-537) |
| Dw-Ad-503-M8 | |
| Lls-1180w-001 | |
| Llk-1181w-000 | |
| Lhk-1180w-301 | |
| Dw-As-623-M18-002-M18-8mm-Pnp | |
| Lts-1040-301-506 | |
| Dw-As-624-M5 (320-920-280) Induktiver Sensor | |
| Lrk-1180-301 | |
| Dw-As-501-P20 Induktiver Sensor | |
| Lhk-1180-301 | |
| Dwad403m5 | |
| Dcc18m12psk-Ibsl (Ex.Dwas503m18-002) | |
| Dw-As-519-M30-320 Sensor | |
| 320-420-208 Dw-As-703-M12 | |
| Dw-Av-501-P20-275 Sensor | |
| P/N: 630-000-654, Type: Ybb-30r4-1300-D020 | |
| Dw-As-513-M12 Induktiver Sensor | |
| P/N: 630-000-595, Type: Ybb-30s4-1400-G012 | |
| Dw-Ad-603-?12 | |
| Dw-Rd-503-M12 Kontaktloser Schalter10...30vdc,200ma | |
| P/N: 630-000-655, Type: Ybb-30r4-1400-D020 | |
| Dw-Ad-605-04 Induktive Sensoren220-020-454 | |
| P/N: 630-000-666, Type: Ybb-30r4-1300-D050 | |
| Dw-As-513-M30-002 | |

| |
|---|
| S12-3fug-020-12mg |
| Lts-1120-302 |
| Dw-As-509-M12 (320-020-101) Induktiver Sensor |
| Dw-Ad-623-065-120 |
| Lls-1181l-000 |
| Ltr-C23pa-Pmk-301 Optic Sensor |
| 620-200-782 Ltk-1050-303 Speminidiff |
| Ltk-1120-304 |
| Ltk-1120-301 |
| P/N: 630-100-125, Type: Yca-50s4-4400-D050-69k |
| Dw-As-523-P12 |
| Dw-As-623-M18-120 |
| Lhs-1180-301 |
| P/N: 630-000-670, Type: Ybb-30r4-0250-D100 |
| 620-200-305 Optischer Sensor Ltk-1120-303 10 ... 36 V |
| S12-3fug-100-12mg |
| Lls-1040-201 |
| Lts-1180w |
| 320-920-216 Induktive Sensordw-As-601-M8-124 |
| 320-820-627 Induktiver Sensor Dw-Ad-613-M18-245 |
| P/N: 630-100-116, Type: Yca-50r4-6300-D050-69k |
| Lls-1181l-003 |
| Ltk-1120-303 |
| Llk-1180-200emitt Sensor Lichtschanke |
| Dw-As-624-M12-120 |
| 320-820-128 Sensor Inductivedw-As-623-M18-002 |
| Dw-Ad-613-M12-159 Sensor |

| |
|--|
| Dw-Ad-513-M8 Inductive Sensor330-020-051 |
| Lls-1180l-000 |
| Dw-Ad-513-M8 |
| Llk-1180-004 |
| Dwad23m8 |
| P/N: 630-100-114, Type: Yca-50s4-6300-D100-69k |
| Lls-1121l-202 |
| Ltk-1050-301-505 |
| Dwac540m12w |
| Dw-As-603-M12-120 (320-820-048) |
| 320-520-961 Dw-Av-501-P20-276 |
| 220-820-873 Induktive Sensoren Mit Integriertem Zweidraht-Kabel; Output: No - Contact Dw-Dd-625-M8 |
| Llk-1180w-003 |
| Dw-As-603-M8-129 |
| Dw-As-519 |
| Dw-As-503-P20 Sensor |
| Dw-Ad-509-M18-390 |
| Cxg24c-512-Bn-V30-M7-050 |
| Dw-Ad-703-M12 |
| Lrk-1120-303 |
| Lls-1050-204 |
| Asu-3012-180 |
| Dwas623m5 |
| 320-520-003 Sensor Dw-Ad-503-04-10..30vdc-200ma-Pnp-S2,2mm-No |
| Asu-3112-120 |
| Dw-As-509-M12 |
| P/N: 630-100-124, Type: Yca-50s4-4400-D020-69k |

| |
|--|
| P/N: 630-000-648, Type: Ybb-30r4-0500-D020 |
| Dw-As-613-M12 |
| Dw-As-503-P20 |
| Dw-Ad-509 |
| P/N: 630-000-586, Type: Ybb-30s4-0250-G012 |
| Dw-Av-501-P20-276 |
| Lls-1121l-204 |
| Dw-Ad-503-M12 |
| Dw-As-623-M8-123 Sensor Dw-As-623-M8-123 Pnp No |
| 623-100-051 S12-4fvg-050 |
| 320-520-248 Dw-Ad-613-M8-121 |
| S083fvg020921 |
| Llk-1181w-001 |
| P/N: 630-000-583, Type: Ybb-30s4-1400-D100 |
| Llk-1180w-002 |
| Dw-As-303-M4 |
| P/N: 630-100-118, Type: Yca-50s4-3400-D020-69k |
| Dw-As-603-M30-120 |
| Dw-Av-623-M5-276 Contrinex Induktiver Sensor Dw-Av-623-M5-276 |
| Dw-As-601-M08-124 Non-Contact Sensor M8*27 L40 Npn No Ip 67 Connector S8 |
| P/N: 630-000-656, Type: Ybb-30r4-1600-D020 |
| Dw-Ad-621-M8-120 |
| Dw-As-601-M8-124 Induktiver Sensor 220-220-846 |
| Lrk-1120-302 |
| Dw-As-701-M8 Induktiver Sensor |
| 320-520-921 Sensor Dw-As-503-P20-678 |

| |
|---|
| P/N: 630-000-668, Type: Ybb-30r4-1600-D050 |
| Dwas503m8 |
| Dw-As-623-M8-001-M8-2mm-Pnp |
| S12-3fug-120-12mg |
| Lrs-1180w-301 |
| DW-AS-703-M18-002 |
| Contrinex Dw-Ad-503-M12-245 |
| Dw-Ad-603-065-400 |
| Dw-Ad-509-C8-390 (320-420-107) Induktiver Sensor |
| P/N: 630-100-129, Type: Yca-50r4-4400-D100-69k |
| Lts-3030-103 Sensor |
| Asu-0001-120 Asu-0001-120 |
| Uts-1180c-303 Ultrasonic Sensor Power Supply: 20 ... 30vdc; Range: 3 ... 20cm, Output: No |
| Dw-Ad-523-M8-245 |
| S083fw020921 |
| Dw-Ad-509-M18-390 Induktiver Sensor |
| 320-820-008 Sensor Dw-As-603-M12 |
| Lts-1180-304 Der Optische Sensor Lts-1180-304 |
| Dw-Av-303-M4-276 |
| Ltk-1180 |
| Dw-As-623-M8-123 Inductive Sensor |
| Dw-As-623-M8-123 Induktive Sensor(320-520-264) |
| (320-020-173 Dw-As-703-M8induktiver Sensor |
| S12-3fug-050-12mg |
| Dw-Ad-613-m18 Induktiver Sensor |
| Llk-1180-204-005 Sensor Photoelektrischer Sensor 620-200-602 |

| |
|---|
| Lrk-1180-304 |
| 320 820 400 Dw-As-60a-C44 |
| Llk-1050-201 |
| P/N: 630-100-141, Type: Yca-50r4-3400-G012-69k |
| Lts-1040-303-506 |
| Lrs-1120-302 |
| 320-520-264 Dw-As-623-M8-123 |
| P/N: 630-000-660, Type: Ybb-30r4-0500-D050 |
| Dw-As-613-M30-002 Sensor |
| Llk-1121l-202 |
| Lls-1050-202 |
| Dw-As-503-P20 Contrinex Sensor Die Position Des Zylinders |
| Lhs-1180-302 |
| Ltk-1120-302 |
| Dw-As-702-M8 Sensor |
| Ltk-1050-303-506 |
| Ltk-1040-301-505 |
| Dw-Ad-503-M12-245 Sensor |
| Llk-1181l-000 |
| Dw-As-501-P20 Sensor |
| Lrs-1120-301 |
| Lts-1040-301-505 |
| Dw-As-503-Pc 726640 A |
| Dw-As-503-M12-001 (320-020-921)induktiver Sensor |
| Dw-As-503-M12 |
| Lts-1120-301 |
| Dwad30303 |
| Dw-As-601-M08-124 |

[320-520-501 Sensor Contrinex Dw-Ad-501-M8](#)

[320-520-409](#)