

## Cutler Hammer



Garanti: 12 ay

Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine başvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.

**Cutler Hammer** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Cutler Hammer Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*

rn	Aıklama
<a href="#">CN15SN3</a>	270 AMP 600V
<a href="#">CONTACTOR 270 AMP 600V</a>	
<a href="#">1785T-EX</a>	Panel-mate 1700, 8,4" Color IET Display, Touchscreen, obsolete
<a href="#">BRIDGE (4A36454G01)</a>	
<a href="#">MODULE DE-EXCITATION 600V, 2000A</a>	2D80386G05
<a href="#">E50SA SERIES A2</a>	
<a href="#">MP-3000</a>	STYLE 66D2032GX1
<a href="#">Mp-3000</a>	Motor Protection Relay MP-3010
<a href="#">Dh-362nrk</a>	60A/3P HD FUSIBLE SAFETY SWITCH 600V W/NEUT NEMA 3R
<a href="#">Ecn1608aaa</a>	STARTER MAGNETIC 3PHASE W 30AMP DISC. NEMA12 120VA
<a href="#">48-554-8</a>	
<a href="#">Ds200ek2</a>	Electric Interlock
<a href="#">17-8047</a>	
<a href="#">Mpc1p20</a>	MPC-120 Access Control Module MPC-120
<a href="#">1775t-Pmpp-1700</a>	Operator Panel
<a href="#">E-22w59</a>	
<a href="#">Dh363ngk</a>	100A/3P HD FUSIBLE SAFETY SWITCH 600V W/NEUT NEMA 1
<a href="#">Fd3060</a>	TYPE FD BREAKER 3P 60A 600VAC MAX 18K AIC
<a href="#">Fdb</a>	
<a href="#">Fd3200I</a>	FD 3P 600VAC RATED LINE AND LOAD TERMS

<a href="#">10250t53</a>	Contact Block 10250T-53
<a href="#">87-02008-01</a>	AB Acceleration Module
<a href="#">Mmx34aa012f0-0</a>	AC Drive
<a href="#">Wms2d02</a>	Thermal Magnetic Circuit Breaker
<a href="#">24-3304-8</a>	
<a href="#">Dk3400w</a>	TYPE DK BREAKER 3P 400A 240VAC MAX 65KAIC @ 240V
<a href="#">S801v50n3b</a>	Soft Starter Module
<a href="#">Kd3400kw</a>	Molded Case Circuit Breaker Switch SERIES C TYPE KD-K
<a href="#">Dn50dsr14</a>	D50 Expansion I/O Module DN50DSR14K
<a href="#">Dh364ugk</a>	200A/3P HD NON-FUSIBLE SAFETY SWITCH 600V NEMA 1
<a href="#">Ecn1611aac</a>	COMBINATION STARTER NEMA SIZE 1 FUSIBLE
<a href="#">Hfd3030l</a>	
<a href="#">Xtob040dc1dp</a>	Overload Relay module
<a href="#">A10b-1</a>	SERIES A1 STARTER CONTACTOR NEMA SIZE 0
<a href="#">Brfpp</a>	Filler Plate Kit
<a href="#">92-01670-00</a>	OPERATOR INTERFACE TOUCH SCREEN PANEL MATE
<a href="#">D15cr44a1b</a>	
<a href="#">D60la0</a>	PHASE UNBAL RLY
<a href="#">Hmcp</a>	
<a href="#">E50ki549</a>	
<a href="#">91-01538-05</a>	CRT MODULE
<a href="#">Ch151-E22b2</a>	
<a href="#">6-Y-1rmf-Pm-115a</a>	
<a href="#">Cn15gn3ab</a>	
<a href="#">E30kg10</a>	
<a href="#">Hmcp150t4c</a>	
<a href="#">92-01273-03</a>	Operator Panel A1023-099
<a href="#">Fd3150l</a>	TYPE FD BREAKER 3P 150A 600VAC MAX 18K AIC
<a href="#">Cut_Ghb3015</a>	
<a href="#">Fd3125l</a>	TYPE FD BREAKER 3P 125A 600VAC MAX 18K AIC

<a href="#">92-01755-01</a>	Touch Panel 1500 Power Series 1550 PM
<a href="#">92-01940-03</a>	1775T-PMPP-1700 Operator Panel 1775T-PMPP-1700
<a href="#">D40rpb</a>	
<a href="#">Elcm-Ph16nndt</a>	ELCM Controller
<a href="#">189574</a>	
<a href="#">Xtce018c01</a>	Contactora XTCE-018C01A
<a href="#">D100cr40h</a>	High Speed Relay Output D100H
<a href="#">D830mpm</a>	OPERATOR INTF
<a href="#">Fd3040I</a>	TYPE FD BREAKER 3P 40A 600VAC MAX 18K AIC
<a href="#">C3000k2a</a>	3000 VA TYPE MTK CONTROL TRANSFORMER
<a href="#">D50er14</a>	D50 SERIES 14 I/O EXP. RELAY OUTPUT D50EA14
<a href="#">X17-8047</a>	
<a href="#">V201k4cj</a>	
<a href="#">E65InI9f</a>	PHOTOELECTRIC DIFUSE REFLECTIVE 24-48 DUAL OUTPUT
<a href="#">92-01683-00</a>	OPERATOR INTF
<a href="#">41141-405</a>	
<a href="#">92-01938-01</a>	Operator Interface Panel 755T-PMPP-1700
<a href="#">92-01683-01</a>	OPERATOR INTF
<a href="#">E-22w50</a>	
<a href="#">Fd3020I</a>	TYPE FD BREAKER 3P 20A 600VAC MAX 18K AIC
<a href="#">92-00635-00</a>	PANELMATE INTERFACE POWER SERIES W/KEYBOARD
<a href="#">Cn15nn3a</a>	CONTACTOR NEMA4 3PH 3POLE 135A 120VAC COIL 1NO AUX
<a href="#">92-00556-07</a>	Panelmate III Touch Screen Display
<a href="#">Jgs3250nn</a>	Circuit Breaker, 3-P, 250A Frame J250S
<a href="#">E84aan</a>	LIMIT SWITCH 2NO-1NC
<a href="#">E30kg20</a>	
<a href="#">D7dba10aga1xxx</a>	Touch Screen Display Panel
<a href="#">E50sal6p</a>	
<a href="#">D520ta1</a>	ANALOG OUTPUT
<a href="#">63-00375-01</a>	19" PanelTec Keyboard Panel 63-00375-00
<a href="#">Cn15-Kn3a</a>	CONTACTOR 90AMP SIZE3 3POLE 120VAC 1NO AUXILIARY

<a href="#">Fd3070I</a>	TYPE FD BREAKER 3P 70A 600VAC MAX 18K AIC
<a href="#">Dg-324ngk</a>	200A/3P GD FUSIBLE SAFETY SWITCH W/NEUT 240V NEMA 1
<a href="#">Ch063-E22b1</a>	
<a href="#">Hfd3060I</a>	
<a href="#">D40rpa</a>	
<a href="#">Pxd-Mmg</a>	Power Xpert Meter Display Panel
<a href="#">A201k3ca</a>	CONTACTOR, SIZE 3, OPEN, 3 POLE, 120V / 60HZ COIL
<a href="#">6-26-B187g17</a>	CONTACT KIT, A201, MODEL J, SIZE 4, 3 POLES
<a href="#">542vm</a>	PanelMate Series 500 92-01413-04
<a href="#">Ed3225</a>	ED 65KA @ 240 V, 3 POLE 225 AMPS, LOAD TERMINALS
<a href="#">D100era40</a>	D100 I/O Expansion Unit D100-ERA40
<a href="#">E50dr1</a>	
<a href="#">Ecn0521aaa</a>	STARTER SIZE 2 W/H1044 HEATER OVERLOAD
<a href="#">E211608</a>	
<a href="#">E209115</a>	
<a href="#">1755t Pmpp-1700</a>	Operator Interface Panel PANELMATE
<a href="#">E22b2</a>	
<a href="#">A10d-1</a>	SERIES A1 STARTER CONTACTOR NEMA SIZE 2
<a href="#">Fdb3150</a>	TYPE FDB, 3 POLE, 150A TRIP, 600V CLASS, LOAD TERMINALS ONLY
<a href="#">D40rb</a>	
<a href="#">J11</a>	
<a href="#">5285k Pmpp 5000</a>	10.4" Color TFT Operator Interface Panel 5285KPMPP5000
<a href="#">54-2764</a>	
<a href="#">6-27-2</a>	CONTACT KIT, CITATION, SIZE 5, 3 POLE
<a href="#">D520fc1</a>	COMMUNICATION MODULE
<a href="#">D26mb</a>	Type M Relay Module
<a href="#">Idtpgglobl76c8te</a>	
<a href="#">A201k6cac</a>	CONTACTOR 500AMP 3POLE 600V 110/60 120/60
<a href="#">Fd1125I</a>	FD 1P 125A LL TERM
<a href="#">D100cra40</a>	PROG CONTROLLER

<a href="#">92-01667-01</a>	PANELVIEW PANELMATE 1500 POWER SERIES
<a href="#">S801t24n3s</a>	
<a href="#">S801v42n3s</a>	
<a href="#">S801t24n3b</a>	Soft Starter
<a href="#">D520ta2</a>	ANALOG OUTPUT
<a href="#">Elcm-Ex08nndr</a>	ELCM I/O Module
<a href="#">D100cra28w</a>	Programmable Controller D100
<a href="#">1037-0h-57a</a>	
<a href="#">Hfd3020I</a>	