

## Danaher Motion



Garanti: 12 ay

Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.

**Danaher Motion** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Danaher Motion Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*

rn	Aıklama
<a href="#">VDE0530-S1</a>	
<a href="#">ACS4808-350F01</a>	
<a href="#">AHR 92-G4-64S-C33</a>	
<a href="#">AHR 115-A6-88S-C33</a>	
<a href="#">AHR 115-C6-88S-C33</a>	
<a href="#">AHD115-E6-130S</a>	
<a href="#">AHD115-G6-130S</a>	
<a href="#">AHR 142-C6-88S-C33</a>	
<a href="#">AHR 142-G6-130S-C33</a>	
<a href="#">AKM21C-ANMNR-00</a>	KOLLMORGEN synchronous servo motor Standstill torque = 0.48 Nm Standstill current = 1.58 A Nominal voltage = 230VAC Rated speed = 8000 rpm Flange: IEC with tolerance N Wave: smooth wave Connection: 2 Molex plugs on 0.5m cable, IP20 without holding brake Feedback: resolver
<a href="#">VMC20</a>	
<a href="#">133119</a>	
<a href="#">Sv3410-01000</a>	DRIVE 460VAC 10HP 50/60HZ AC FLUX VECTOR
<a href="#">Utr0060250rm0601</a>	GEAR BOX 1GEAR MACHINED
<a href="#">Ac5-0030r1 (Ex Kt4030-10)</a>	
<a href="#">Akm51e-Hcs2r-02</a>	
<a href="#">Btcs620 (30126589)</a>	
<a href="#">00-11217-001</a>	SERVO DISC MOTOR DC

<a href="#">Akm31c-Ancnr-00</a>	KOLLMORGEN synchronous servomotor Standstill torque = 1.15 Nm Standstill current = 1.37 A. Rated voltage = 230/400 VAC Rated speed = 2500/5000 rpm 2-pole resolver without holding brake Smooth wave
<a href="#">6sm56s-3.000-00</a>	
<a href="#">Sam-Pa-400-80-E</a>	POWER SUPPLY
<a href="#">X32-113-349</a>	GEAR BOX
<a href="#">Ep165090-G2ljbxc-C33-76w 329c</a>	
<a href="#">Pc833-001-A</a>	SERVO DRIVE 12/240V
<a href="#">Vdo0530-S1 / Dc Motor</a>	
<a href="#">Dbl2h00040-0r2-110-S40</a>	
<a href="#">Kollmorgen Resolverkabel</a>	S300/400/600/700 - AKM/DBL/DBK76SMx7 20m, 4x2x0,25mm <sup>2</sup> ****ECCN-   AL-****
<a href="#">Ahr115c6 88s</a>	
<a href="#">Dt115-020-O</a>	PLANETARY GEARHEAD RATIO 20:1 1549IN-LBS
<a href="#">34-613238-5959</a>	GEAR BOX
<a href="#">605-E1</a>	
<a href="#">6sm100m 3 000 0</a>	
<a href="#">Servostar? 446m-Na</a>	
<a href="#">Vsd2000-30t4-C</a>	
<a href="#">Ahr190j8-520s, Nr. 4077581-0011</a>	
<a href="#">Akm53k-Acc2r-00</a>	
<a href="#">Ahr9264 64s</a>	
<a href="#">63024 09k Ls4 2 0</a>	
<a href="#">Akm 43g-Ancnr-00</a>	
<a href="#">0566520</a>	
<a href="#">Pn: 9032 0121 22</a>	
<a href="#">3yl 20</a>	
<a href="#">9032 0121 30 (Obsolete- No Replacement)</a>	
<a href="#">S30601-Na</a>	
<a href="#">Ahr115c6-88s</a>	
<a href="#">32-113-353</a>	GEAR BOX

<a href="#">Mcs605-E2 , Btcs620!!!</a>	
<a href="#">Dbl4-0530-30-Y-560s-B-P</a>	
<a href="#">620-As-S6200120a</a>	
<a href="#">Dbl3-0300-30-Y-560 S-B Px88</a>	
<a href="#">Ahr9264-64s</a>	
<a href="#">A320a462a Nsc</a>	
<a href="#">Dt90ds-050 Rm090-Tbd</a>	
<a href="#">32-615701-8971</a>	GEAR BOX
<a href="#">34-510-882-2489</a>	GEAR BOX
<a href="#">Kgf-D 4040 Rh-Ee</a>	
<a href="#">Sv3440-01000</a>	AC FLUX VECTOR DRIVE 52AMP 40HP 0-120HZ 3PH
<a href="#">9032010522</a>	
<a href="#">Dt115-003</a>	PLANETARY GEARHEAD RATIO 3:1 2513IN-LBS
<a href="#">Akm53k-Accnr-00</a>	
<a href="#">Hkt4010-10</a>	
<a href="#">9032 0121 30</a>	
<a href="#">Ahr190-J8-520s-F07d01k99c33b</a>	
<a href="#">1109375</a>	
<a href="#">9032 012124</a>	
<a href="#">6sm-Resolv.Ste.</a>	
<a href="#">6sm-Motorl.St.-Kurz</a>	
<a href="#">3yl-20</a>	
<a href="#">Ctr.Aa.0156</a>	
<a href="#">Cte.Am.0047</a>	
<a href="#">64-116862-B243</a>	GEAR BOX
<a href="#">32-313908-9109</a>	GEAR BOX
<a href="#">6sm37l 4 000 00</a>	
<a href="#">3200</a>	
<a href="#">70 650 479</a>	
<a href="#">Tnx318a6mp3mt1idc0</a>	

<a href="#">Akm54I-Ancnem-00</a>	
<a href="#">Mx20002a</a>	
<a href="#">810-032</a>	SERVO MOTOR BRUSHLESS 115-230V MODEL B32
<a href="#">Dbl3h00130-Br2-000-S40</a>	
<a href="#">605 E1</a>	
<a href="#">Akm53k - Anfnr-00</a>	
<a href="#">Old Code Mcs2000-Drv2- New Code Hmcs2000-Drv2</a>	
<a href="#">Mh112-Fj-4201</a>	STEPPER MOTOR 200STEPS 3.2V 4AMP
<a href="#">Dbl1x00020-0r0-Llk-P40</a>	
<a href="#">Ss2000md7-128</a>	
<a href="#">Akm33c-Accnr-00</a>	
<a href="#">M172-Fd-306</a>	
<a href="#">Rc-1002</a>	DRIVE QUADRALINE R MOTOR CONTROL 10AMP 230VAC 2HP
<a href="#">Ce062500-00000</a>	SERVO DRIVE 10AMP 7.8PH 115/230VAC
<a href="#">00-88008-003</a>	SERVO AMPLIFIER SWITCHING
<a href="#">7820597</a>	BALLSCREW ,1.500X0.473X240,RH
<a href="#">Tnx315b4mp3mt1idc0</a>	
<a href="#">Wm08z170-01100-01590-As-0000</a>	
<a href="#">Akm22/Akm33(Not Available)</a>	
<a href="#">Dt115-020</a>	PLANETARY GEARHEAD RATIO 20:1
<a href="#">34-712-419-5933</a>	GEAR BOX
<a href="#">Firmware V1.17</a>	
<a href="#">Dt90-003x</a>	GEAR HEAD 3/1RATIO
<a href="#">S70302-Na (Ex S70301-Na)</a>	
<a href="#">9032012000</a>	
<a href="#">6dam90056</a>	
<a href="#">Dbl2h00060-0r2-110</a>	
<a href="#">Dmc50412ext24v</a>	MOTION CONTROLLER 3.5AMP 570VDC
<a href="#">Dsm9-Sd-03</a>	
<a href="#">Ctr.Aa.0155</a>	

<a href="#">Servostar 406 A</a>	
<a href="#">B-402-A-23</a>	SERVO MOTOR 230V 1500RPM
<a href="#">42-114324-F431</a>	UT010-005-S-RM100-17 (SPECIAL RM)
<a href="#">X32-113-341</a>	GEAR BOX
<a href="#">Sam-Da-400-480-28b-P4n-E</a>	Driver
<a href="#">S71202-Na (Ex S71201-Na)</a>	
<a href="#">Akm54I-Xxcnr-00 Akm54I-Xxcnr-00</a>	
<a href="#">Kollmorgen TI5</a>	
<a href="#">0088055003</a>	COMMUNICATION MODULE
<a href="#">42-314279-C345</a>	GEAR BOX
<a href="#">Sam-Da-400-480-14b-P4n-F</a>	Driver
<a href="#">Dbl6n02900/Br2/000/S40</a>	
<a href="#">D535071</a>	
<a href="#">De-83212</a>	SERVO MOTOR
<a href="#">Xce1500</a>	
<a href="#">2600303560sbb26nm+frdam10063</a>	
<a href="#">9032 012 132</a>	Cat. No: DMC 2 51540P
<a href="#">32-113344-7854</a>	GEAR BOX
<a href="#">Akm22c-Acbnr-00</a>	
<a href="#">Akm 43g Ancnr 00</a>	
<a href="#">32-217263-B153</a>	GEAR BOX
<a href="#">Sv3405-11000</a>	DRIVE 5HP 7.6AMP 460VAC 6KVA
<a href="#">R43gena-Ts-Ng-Nv-00</a>	SERVO MOTOR 10OHM 3.5AMP 128V
<a href="#">50720</a>	
<a href="#">Ce03250-000000</a>	SERVO DRIVE 3AMP 300V ANALOG W/ ENCODER FEEDBACK
<a href="#">6sm 100-S 3000-426, 7.7 Kw</a>	
<a href="#">83r09170a S/N:6440823-048</a>	
<a href="#">Servostar 400 M</a>	
<a href="#">K42v-Em</a>	SERVO MOTOR HIGH TORQUE W/500PPR ENCODER
<a href="#">Sr-06004-000000</a>	SERVO AMPLIFIER

<a href="#">32-113369-C830</a>	GEAR BOX
<a href="#">Akm43g-Ancnr-00</a>	
<a href="#">Psr4/5a-212</a>	POWER SUPPLY 12AMP/PHASE 3PH 230VAC
<a href="#">Me9-203-B-Aq9-254</a>	SERVO MOTOR 3000RPM 230V 100HZ 2500LPR ENCODER
<a href="#">Cr03550</a>	SERVO DRIVE
<a href="#">32-113349-6608</a>	GEAR BOX
<a href="#">Ss451tg3</a>	STEPPER MOTOR 0.8A 120VAC 50/60HZ 1PH 20/24RPM
<a href="#">Bds4a-220j-0001-W/O</a>	SERVO DRIVE
<a href="#">Bds4a220j-0001-404d21p</a>	SERVO DRIVE 380VDC/28AMP IN 230VAC/20AMP OUT
<a href="#">A103 000</a>	
<a href="#">Kst093t1y</a>	MOTOR SYNCHRONOUS 1A 120VAC 50/60HZ 1PH 60/72RPM
<a href="#">Wm80zrtdt090</a>	
<a href="#">A103-000</a>	
<a href="#">63024-09k Ls4-2.0</a>	
<a href="#">M112-Fj12</a>	NEMA 42 STEP MOTOR, 2 STACK
<a href="#">Mx2000-6</a>	MX2000 SYSTEM ENCLOSURE FOR UP TO SIX AXIS WITH STANDARD I/O
<a href="#">6sm37l-4.000-00</a>	
<a href="#">S60600-Na</a>	SERVO DRIVE IP20 6AMP 4KVA 3X230-480V
<a href="#">Ato14030so</a>	GEARHEAD PLANETARY INLINE 30:1 ACCU TRUE
<a href="#">6sm 100-S 3000-426 + Re-21-1-A05 ( U 4-10v) 36 Nm 26,7 A 7,7 Kw S1 Ip 64/65 KI F 3000 U/Min</a>	
<a href="#">Akm43e-Xxcnr-00</a>	
<a href="#">Sv3401-11000</a>	DRIVE 1HP 460VAC 3PHASE
<a href="#">Acs8010 220f</a>	
<a href="#">Ts-230</a>	MAGNIFIER 00-230X VARIABLE W/O CABLE
<a href="#">Dbl4-0530-30y-560 S-B P</a>	
<a href="#">Kmt093f10c5</a>	STEPPER MOTOR 3.21VDC 5.1AMP 200STP/REV
<a href="#">Se10200-000000</a>	SERVO DRIVE IP-140-310VDC OP-115/230VAC
<a href="#">64-116849-C351</a>	NT23-050-S-RM060-130 (SPECIAL RM)
<a href="#">Kgs4040-2300</a>	

<a href="#">53no12a</a>	
<a href="#">34-510-090-3881</a>	GEAR BOX
<a href="#">Servostar 341</a>	KOLLMORGEN servo controller SERVOSTAR 341 CAN S30101-NA Nominal power supply 3x208V-10% ... 480V + 10%, 50 / 60Hz Rated output current at 3x400V: 1.5A Peak output current: 4.5A Integrated mains filter and brake resistor
<a href="#">Tm84-Dh-S-4-C</a>	PRESS LOAD MONITOR 120V
<a href="#">Ss2000d12</a>	
<a href="#">Sru-Ms-Ilk11-6k</a>	
<a href="#">Vsd2000-22t4-C</a>	
<a href="#">M-203-A-23</a>	SERVO MOTOR GOLDLINE 6.8NM AMP 2500RPM 230V
<a href="#">Sv3405-01000</a>	DRIVE AC 0-0120HZ 3PH 5HP 460V 7.6AMP 6KVA
<a href="#">Bds5a-220-01010-604a-2-020</a>	SERVO CONTROLLER
<a href="#">Digifas-7204</a>	SERVO MODULE 4.2AMP 400VAC 2.5KVA
<a href="#">Dbl4n00750-0r2-00-S40</a>	
<a href="#">M5hlen-00115-00</a>	DRIVE MILLENNIUM NON-REGEN 50HP 3PH 50HZ
<a href="#">M112-Fj-12e</a>	STEPPER MOTOR 200STEPS/REV 3.66VDC 6.1AMP
<a href="#">Lm-Mrs004</a>	LINEAR POSITIONER
<a href="#">Vsd2000-15t4-C</a>	
<a href="#">Dbl4-0260-30-Y-560s-B-P</a>	
<a href="#">S/N : 105 101 35</a>	
<a href="#">P315x-H</a>	SERVO DRIVER INDEXER MICRO-STEP
<a href="#">Sc753-A010-02</a>	SERVO DRIVE 115/230V 1/3PHASE 12/12AMP 50/60HZ
<a href="#">Dt090-010</a>	
<a href="#">Se06000-000000</a>	SERVOSTAR IN 140/310VDC OUT 115/230 VAC 6 AMP/PHAS
<a href="#">0566520, Ac58/0412ek.42pgb</a>	
<a href="#">606-As-S60601</a>	
<a href="#">Rw32v</a>	ROUNDWAY BEARING
<a href="#">Ss700e</a>	MOTOR SYNCHRONOUS 1.1A 120VAC 1PH 60/72RPM
<a href="#">32-513751-A851</a>	GEAR BOX
<a href="#">Xt060-010-0-Rm060-6</a>	
<a href="#">222419-001</a>	CONTROL BOARD MX2000 DSP

<a href="#">Acs8010-220f</a>	
<a href="#">B-206-A-31</a>	SERVO MOTOR
<a href="#">32-513798-8603</a>	NTR23-060-0-RM060-1
<a href="#">1013350132</a>	
<a href="#">Sam-Da-400/480-07b-P4n-E</a>	Driver
<a href="#">00d12a02112-2</a>	SERVO DISC DC MOTOR PLATINUM SERIES
<a href="#">Ss452lg20</a>	NEMA 34 GEARED SYNCHRONOUS MOTOR, 240 VOLT 3PH
<a href="#">M111-Fd-12</a>	STEPPER MOTOR 2.26VDC 200STEPS/REV
<a href="#">63024-21</a>	
<a href="#">Mt322a1-R2c1</a>	SERVO MOTOR BRUSHLESS GOLDLINE
<a href="#">Bcl-02820-A00</a>	SERVO DRIVE
<a href="#">Sce-903-001-01a</a>	SERVO DRIVE 480VAC 3PH 5FLA 50/60HZ
<a href="#">Ep3640-1436-7-56bc-Cu</a>	1/2HP 1750 RPM 90V EXP PMDC MOTOR FGE0213 FGE0213 P2-I-S-19 STK
<a href="#">Srf5360-4985-84-5-82bc-Cu</a>	2.0HP 1750 RPM 180V TEFC PMDC MOTOR FGS2754 FGS2754 LG-I-A-15 STK
<a href="#">42-314279-7853</a>	GEAR BOX
<a href="#">S33nlyy-Lnf-Ns-01</a>	MOTOR SYNCHRONOUS 120VAC 60HZ 72RPM .41AMP
<a href="#">At-006-08-S0</a>	GEARHEAD ACCUTRUE 28/1 5/8INCH SHAFT
<a href="#">Pce-835-001-T</a>	SERVO DRIVE BRUSHLESS 15.5AMP 50/60HZ 380/400/480V
<a href="#">Pce833-001-T</a>	SERVO DRIVE BRUSHLESS
<a href="#">34-510-202-2499</a>	GEAR BOX
<a href="#">Mcs 2000-Drv2 , Bx2drv!!!</a>	
<a href="#">R34-Jenc-R2-Ns-Nv-00</a>	SERVO MOTOR BRUSHLESS 27LB-IN 3.7A NO BRAKE 3.7AMP
<a href="#">B-204-A-99-056</a>	SERVO MOTOR BRUSHLESS GOLDLINE 1900RPM 230V
<a href="#">Sc403-030-T4</a>	SERVO CONTROL BRUSHLESS
<a href="#">Spae-1215-104</a>	SERVO AMPLIFIER
<a href="#">0530303560sbb5,3nm+fdam10025</a>	
<a href="#">S60100-Na</a>	SERVOSTAR DRIVE 1.5AMP 230-480V 1KVA
<a href="#">Akm54k-Acc2r-00</a>	
<a href="#">42-314287-C338</a>	GEAR BOX
<a href="#">Ss452g3</a>	NEMA 34 GEARED SYNCHRONOUS MOTOR, 240 VOLT



<a href="#">Hmcs2000-Drv2</a>	
<a href="#">Ksl093t1ye</a>	MOTOR SYNCHRONOUS 1AMP 1PH 120V 50/60HZ
<a href="#">Dbl3-0250-30-Y-560 S-B P</a>	
<a href="#">Ss400b-E</a>	NEMA 42 SYNCHRONOUS MOTOR, 120 VOLT
<a href="#">Bds5a-206</a>	SERVO AMPLIFIER
<a href="#">Sam-Da-400/480-07b-P4n-F</a>	Driver
<a href="#">Akm52k-Acc2r-00</a>	
<a href="#">Sbd2-20-1100-0000023/160-20</a>	DRIVE BOARD
<a href="#">34-510572-6666</a>	GEARHEAD PLANETARY INLINE 30:1 ACCU TRUE
<a href="#">R32genp-R2-Ns-Vs-00</a>	SERVO MOTOR BRUSHLESS SQ. FRAME EXP PF VITON SEAL
<a href="#">B-404-A-23</a>	SERVO MOTOR GOLDLINE 230V 1500RPM 50HZ
<a href="#">Dbl4-0260-30-Y-560s-B-Bp</a>	KOLLMORGEN synchronous servomotor DE-10605, ID10021 **** ECCN   AL - ****