



## Datasensor

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Datasensor** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Datasensor T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*

¼r¼n	A¼ıklama
<a href="#">Hpj-R21 10.8-26,4 Vdc Npn Output 0 V</a>	
<a href="#">S50-ML-5-B01-PP</a>	
<a href="#">770000071526</a>	
<a href="#">950201150</a>	
<a href="#">950201250</a>	
<a href="#">950551030</a>	
<a href="#">950801040</a>	
<a href="#">951451400</a>	
<a href="#">951451480</a>	
<a href="#">951451520</a>	
<a href="#">952001021</a>	
<a href="#">952001270</a>	

<a href="#">952001330</a>
<a href="#">952001370</a>
<a href="#">952021201</a>
<a href="#">952021250</a>
<a href="#">952021260</a>
<a href="#">952701521</a>
<a href="#">952701611</a>
<a href="#">952701771</a>
<a href="#">952701801</a>
<a href="#">953151070</a>
<a href="#">953151080</a>
<a href="#">954651000</a>
<a href="#">956201040</a>
<a href="#">956201080</a>
<a href="#">956201831</a>
<a href="#">957505040</a>
<a href="#">957801030</a>
<a href="#">957951030</a>
<a href="#">95A151340</a>
<a href="#">95ACC6170</a>
<a href="#">95B020060</a>
<a href="#">95B040080</a>
<a href="#">95B060770</a>
<a href="#">964401000</a>
<a href="#">BCC02PL</a>
<a href="#">DS20110005</a>
<a href="#">ELK22S-240-R-2R</a>
<a href="#">ELK22S-240-S-2R</a>
<a href="#">G5210830</a>
<a href="#">LD46-UL-755</a>

<a href="#">LDU-455 SV2239</a>
<a href="#">LDµ-015</a>
<a href="#">QD-10</a>
<a href="#">S12M-5-B82B</a>
<a href="#">S15-NA-5-B01-NK</a>
<a href="#">S300-PA-2-F01-OC</a>
<a href="#">S300-PA-2-G00-EX</a>
<a href="#">S3-R-B2 SV2016</a>
<a href="#">S3-R-D12</a>
<a href="#">S3T-R-B2</a>
<a href="#">S3T-R-B2 SV2016</a>
<a href="#">S3T-S-E1</a>
<a href="#">S3Z-PR-2-B01-PD</a>
<a href="#">S41-5-T-P</a>
<a href="#">S50-MA-2-F01-PP</a>
<a href="#">s50-pa-5-b01-pp</a>
<a href="#">S50-PA5-C01PP</a>
<a href="#">S50-PA-5-D00-PP</a>
<a href="#">S50-PA-5-T01-PP</a>
<a href="#">S50-PR-5-B01-PP</a>
<a href="#">S51-MA-5-C01-PK</a>
<a href="#">S51-PA-2-A00-NK</a>
<a href="#">S51-PA-5-B01-PK</a>
<a href="#">S51-PA-5-C01-PK</a>
<a href="#">S51-PR-5-B01-PK</a>
<a href="#">S5-5-A4-32</a>
<a href="#">S5-5-C10-32</a>
<a href="#">S5N-PA-5-C21-NN</a>
<a href="#">S5N-PA-5-E01-PP</a>
<a href="#">S60-PA-5-B01-PP</a>
<a href="#">S60-PA-5-M08-PH</a>

<a href="#">S6-1-B5</a>	
<a href="#">S62-PA-5-M01-PP</a>	
<a href="#">S6-5-M25</a>	
<a href="#">S6-5-M25 SV2241</a>	
<a href="#">S6R-5-M50-P</a>	
<a href="#">S7-5-E-P PNP-M8</a>	
<a href="#">S7-5-E-P PNP-M8 50.314.5364</a>	
<a href="#">S90-MA-5-T51-PP CAT.1,5m</a>	
<a href="#">S936420000</a>	
<a href="#">SG4-RB2L-050-OO-W</a>	
<a href="#">SR21-AR SV2532</a>	
<a href="#">TL50-W-815</a>	
<a href="#">TLU-115</a>	Contrast sensor , red, green LED, TLU series, 6-12mm, 10 to 30V DC, 80mA, PNP, vertical light spot
<a href="#">S60-PA-5-T51-PP</a>	
<a href="#">S5-5-G12-02</a>	
<a href="#">S5-5-F12-32</a>	
<a href="#">S50PR5B01PP</a>	
<a href="#">S50PA5B01PP</a>	
<a href="#">S50MA5B01PP</a>	
<a href="#">S50PL5C01PP</a>	
<a href="#">S50PA5C01PP</a>	
<a href="#">S50PH5C01PP</a>	
<a href="#">Ds4600-3101</a>	LASER SCANNER HIGH PERFORMANCE COMPACT .5-.2AMP
<a href="#">Ds50-L</a>	BAR CODE SCANNER 10-30VDC
<a href="#">Matrix-2155</a>	SCANNER STANDARD DENSITY ETHERNET 10-30VDC
<a href="#">951451400 S300-Pa-1-C01-Rx Diff 24-240vac/Vdc</a>	
<a href="#">Ldu-425</a>	LUMINESCENCE SENSOR
<a href="#">S5-5-C10-32 Sensor Gewinde M18kabelanschluss M8</a>	

<a href="#">S81-Pl-5m03-Ppc</a> <a href="#">Ds6100-1100</a>	BARCODE SCANNER
<a href="#">Qd10</a>	
<a href="#">Ls50h-Sh999</a>	BAR CODE SCANNER
<a href="#">Ls50-Lr2</a>	SCANNER FIXED MOUNT 4.75-28VDC
<a href="#">Ds4600-3100</a>	PHOTOELECTRIC BARCODE SCANNER 10-30VDC 6W
<a href="#">Ds8100a-3020</a>	BARCODE LASER SCANNER HIGH-RE LINEAR AXIOM C-BOX
<a href="#">Ds2100a-2214</a>	BARCODE SCANNER FIXED 10-30VDC
<a href="#">S90-Ma-5-T51-Pp Cat.1,5m Sensor</a>	
<a href="#">Ds41-30</a>	BARCODE SCANNER 0.46 10-30VDC CLASS 2 LASER
<a href="#">Sensor Datasensor S6-1-B5</a>	
<a href="#">952021250 S50-Ma-5-F01-Ppreceiver</a> <a href="#">Metal Axial Pnp No/Nc - M12</a>	
<a href="#">S15-Pa-2-C10-Pk</a>	
<a href="#">Ds2400-1110</a>	SCANNER 5W 10-30VDC
<a href="#">Ls50-Lr2dx9</a>	BARCODE SCANNER
<a href="#">S51-Pa-2-A00-Nk (Max.150 Ma</a> <a href="#">Sn.100mm)</a>	
<a href="#">956201080 Sensor S60-Pa-5-M08-Ph</a>	
<a href="#">S7-5-E-P Pnp-M8 50.314.5364</a> <a href="#">Lichtschränke Sensor</a>	
<a href="#">950201150 Sensor S6-5-C200</a>	
<a href="#">957901000</a>	
<a href="#">Ds2100-2014</a>	BARCODE COMPACT LINE SCANNER 10-30VDC 4W
<a href="#">950801040 Fotosensor S8-Pr-5-T51-Pp</a>	
<a href="#">Pwo-480</a>	POWER CONTROL PANEL OMNI SYSTEM 480W
<a href="#">Ld46-UI-755 Sensor</a>	
<a href="#">S41-5-C-P</a>	
<a href="#">S50-Pa5-C01pp Sensor</a>	
<a href="#">S51-Pr-5-B01-Pk Sensor</a>	
<a href="#">953151070 Sensor Sr ProdtSr21</a> <a href="#">953151070 Sr21-Ir Label Sensor Infra</a> <a href="#">Red Pnp/Npn - M8</a>	

<a href="#">Chs1265-Ind-01</a>	RFID CONTROLLER INDUSTRIAL ETHERNET
<a href="#">Ds2100n-2214</a>	BARCODE SCANNER .5-.17AMP 10-30VDC
<a href="#">Matrix-2031</a>	BARCODE SCANNER 1AMP 10-30VDC
<a href="#">S40-Pr-5-C03-Ph</a>	
<a href="#">S18-5-K-30</a>	
<a href="#">S18-5-C-30</a>	
<a href="#">S5-5-A4-32 Sensor G5210232</a>	
<a href="#">Mx4000-1000</a>	DATALOGIC SCANNINGMULTIPLEXER MX4000-1000 RS485 NETWORK / HOST STD.N/A
<a href="#">952001201</a>	
<a href="#">200-213-100</a>	BARCODE SCANNER MATRIX 200 0.32/0.12AMP 10-30VDC
<a href="#">Ld90910</a>	BARCODE LASER SCANNER EXTENDED PERFORMANCE
<a href="#">Ds2400-2010</a>	BARCODE SCANNER 10-30VDC 5W
<a href="#">Sensor Datasensor Tlu-115</a>	
<a href="#">S5-5f12-32</a>	
<a href="#">Tlu-011 Fotosensor</a>	
<a href="#">F18-5-C-30</a>	
<a href="#">Us18-Pa-5-No3-Vh</a>	
<a href="#">S50-Pa-2-C21-Pp</a>	
<a href="#">S50-Pa5-B01pp Optical Sensor</a>	
<a href="#">Optischer Sensor Datasensor S41-5-B-P</a>	
<a href="#">Ld90510e</a>	BARCODE SCANNER LAZERDATA 9000E
<a href="#">Sensor Tlu-115</a>	
<a href="#">Der Optische Sensor S6-5-C200 Datasensor/950201150</a>	
<a href="#">Sensor S50pa5w03pp Moq 5 Sht</a>	
<a href="#">957951030 Lichtschanke Sg4-Rb2-050-Oo- W</a>	
<a href="#">952001161</a>	
<a href="#">S60-Pa-2-C11-Pp</a>	
<a href="#">Ds2400a-02210</a>	SCANNER 5W 10-30VDC
<a href="#">Ds20110005 Sf-30-Pm</a>	

<a href="#">Sr31</a>	
<a href="#">952701311</a>	
<a href="#">770000071526 Der Optische Sensor S6-5-C200 /950201150</a>	
<a href="#">S50-Ma-5-G00-Xg</a>	
<a href="#">S50-Pa-5-T01-Pp Sensor</a>	
<a href="#">Is64</a>	
<a href="#">S51-Ma-5-C10-Nk Optischer Sensor</a>	
<a href="#">S60-Pa-5-M08-Ph Fotosensor</a>	
<a href="#">970452011</a>	CHS1265-IND-01 HS-ETH/IND INTERFACE (***)
<a href="#">V80500</a>	
<a href="#">952701611 S51-Ma-2-B01-Nk</a>	
<a href="#">M220e-00101-04030r</a>	MGL2200VS,STD CONGIF, IBM/USB CABLE, NO P/S, SUREPOS POT 15
<a href="#">Ds2100a1204</a>	BARCODE SCANNER FIXED POSITION
<a href="#">S50-Ma-5-B01-Pp Sensor</a>	
<a href="#">S6-5-M25 Bgs Plastic Radial Dc Npn/Pnp Cable</a>	
<a href="#">TI50-W-815 Sensor</a>	
<a href="#">Sr21-Ar Sv2532 Sensor</a>	
<a href="#">S62-Pa-2-M01-Pn</a>	
<a href="#">Ld96910e</a>	BARCODE SCANNER LAZERDATA 9000E
<a href="#">Bws-T4-Mt</a>	
<a href="#">Skf30</a>	
<a href="#">Got-5016</a>	
<a href="#">Uxga-Bs-Cm-Eth-Std</a>	BARCODE READER MATRIX-400 600-010
<a href="#">952001271</a>	
<a href="#">S51-Pa-2-G00-Xg</a>	
<a href="#">937401005</a>	MATRIX 400 600-010 UXGA-BS-CM-ETH-STD
<a href="#">Ds4600-1001</a>	DECODER MEDIUM RANGE LINEAR OPTIC J-BOX CONNECTOR
<a href="#">S3-R-B2 Sv2016 E13602 0829 Datasensor</a>	
<a href="#">95b040010</a>	

<a href="#">Sg2-30-150-00-X</a>	
<a href="#">952001270 S50-Pa-5-T01-Ppreflex Transparent Plastic Axial Pnp No/Nc - M12</a>	
<a href="#">S3t-S-E1 Optischer Sensor</a>	
<a href="#">952021260 S10-Ma-5-G00-Xgemitter Metal Axial Test Input - M12</a>	
<a href="#">C-Fs4tzv0720</a>	
<a href="#">S50-Pa-5-D00-Pp Optischer Sensor</a>	
<a href="#">Ds41-10</a>	BARCODE SCANNER 11-30VDC CLASS 2
<a href="#">S40-Ph-5-B03-Ph/Catarif</a>	
<a href="#">953151070 Sr21-Ir M8 Npn/Pnp</a>	
<a href="#">Ds2100n-1214</a>	BARCODE SCANNER10-30VDC .5-.17AMP
<a href="#">Matrix-2161-Sh3786</a>	BARCODE SCANNER 10-30VDC
<a href="#">S51-Ma-2-C01-Pk</a>	
<a href="#">S300-Pa-2-F01-Oc Optischer Sensor</a>	
<a href="#">Tlu-115 Sensor Kontrastierenden Markierungen</a>	
<a href="#">S50-Ma-5-C01-Pp</a>	
<a href="#">Ds2100-1014</a>	BARCODE SCANNER 4W 10-30VDC
<a href="#">S50-Pa-5-T01-Pp Optischer Sensor</a>	
<a href="#">951451250</a>	
<a href="#">Axiom-X</a>	LASER BARCODE SCANNER OMNI-DIRECTIONAL AXIOM-X
<a href="#">S40-Pr-5-M03-Ph</a>	
<a href="#">S50-Pr-5-B01-Pp Tubular Photoelectric Sensorreflex Polarized Plastic Radial Pnp No/Nc - M12</a>	
<a href="#">S51-Pr-5-C10-Pk</a>	
<a href="#">S51-Pa-5-C01-Pk Sensor</a>	
<a href="#">Skf30-5-P</a>	
<a href="#">S50-Ma-2-F01-Pp Optisch/Opto Sensor Receiver</a>	
<a href="#">M8-Kd-05-4 (Ex Cs-B1-02-G-05 4p.M8 5m Gr)</a>	



<a href="#">Ld90110</a>	INDUSTRIAL LASER SCANNER MODEL 9000
<a href="#">Is61d</a>	
<a href="#">S51-Mr-5-B01-Pk</a>	
<a href="#">Ld90910e</a>	BARCODE SCANNER/DECODER LAZER DATA MODEL LD9000
<a href="#">Us30-Pr-5-N13-Vh</a>	
<a href="#">952701801 S51-Ma-5-A00-Pk</a>	
<a href="#">Sg2-30-045-Oo-X</a>	
<a href="#">Sensor Tlu-115 Steuerung Mit Npn.</a>	
<a href="#">S60-Pa-5-B01-Pp Sensor</a>	
<a href="#">S5-5-C10-35</a>	
<a href="#">S5-5-A4-35</a>	
<a href="#">09401-02122-04020a</a>	BAR CODE SCANNER SCALE 20IN
<a href="#">Sm-Pr-2-Foo-Nn</a>	
<a href="#">Ds2400n-1210</a>	BARCODE SCANNER MED RANGE RS232/485 1000SS 17.7IN
<a href="#">Photovoltaik-Touch-Sensor-S7-5-E-P-Pnp-M8 Sensor Data 50.314.5364</a>	
<a href="#">S3-S-C50</a>	
<a href="#">Ls50mdx9</a>	BARCODE SCANNER
<a href="#">Ldµ-015</a>	
<a href="#">S6r-5-M50-P Sensor Infrarot</a>	
<a href="#">G5110610</a>	
<a href="#">S40-Ph-5-B03-Ph</a>	
<a href="#">Sg4-Rb2I-050-Oo-W Reflektor</a>	
<a href="#">S300-Pa-2-G00-Ex Optischer Sensor</a>	
<a href="#">Sso-Pa-5-T01-Pp Npn(Ex S5-5-T1-32)</a>	
<a href="#">S3t-R-B2 Sv2016 (001305) Datasensor</a>	
<a href="#">Qs-11 Single Screen Temperaturanzeige</a>	
<a href="#">Sensor Sensor Data Tlu-115</a>	
<a href="#">9000</a>	DECODER SCANNER 24K CMOS 32K EEPROM 16CHAR LED
<a href="#">Hs870b</a>	CONTROLLER INTERFACE W/I/O
<a href="#">964401100 Sensor Typ: Tlu 115</a>	

<a href="#">400-600-010</a>	BARCODE READER MATRIX 0.8-0.27AMP 10-30VDC
<a href="#">Rx S. 5.5 F 12.32-24v Dc</a>	
<a href="#">S50-Ma-5-F01-Pp</a>	
<a href="#">964401100 Sensor Tlu-115</a>	
<a href="#">950201150 Sensor S6-5-C200</a>	
<a href="#">Ds2100-1104</a>	BARCODE SCANNER FIXED POSITION
<a href="#">952001061</a>	
<a href="#">S51-Pa-5-A00-Pk</a>	
<a href="#">S80-Mh-5-Y09-Nniz</a>	M12 8P
<a href="#">Sm-Pr-2-Goo-Xg</a>	
<a href="#">Ls2200-2010</a>	PHOTOELECTRIC LASES SCANNER
<a href="#">Model-20</a>	BAR CODE SCANNER 700SCANS/SEC MAX 500MA 5VDC
<a href="#">S940700023</a>	
<a href="#">S50-Pa2-C10pp</a>	
<a href="#">S3t-R-B2 Reflex Polarized Plastic Radial Pnp Out - M8</a>	
<a href="#">Dm3500</a>	SCANNER DIMENSIONING SYSTEM
<a href="#">S51-Pa 5-B01 Pk Sensor</a>	
<a href="#">S50-Pa-5-B01-Pp Sensor</a>	
<a href="#">S62-Pa-5-M01-Pp Optischer Sensor</a>	
<a href="#">C827-06</a>	PASSIVE READER/WRITER 400-130MA 10-30VDC
<a href="#">Sensor Der Kontrastmarkierung F. Datasensor Typ: Tlu 115 Code: 964401100</a>	
<a href="#">Ds4600a-3100</a>	BARCODE SCANNER 0.5-0.2 10-30VDC
<a href="#">S50-Pl 5-C01 Pp</a>	
<a href="#">S62-Pa-5-B01-Pp 956211000</a>	
<a href="#">G5210230</a>	
<a href="#">Axiom-2l</a>	BAR CODE SCANNER 2LASER 10-30 VDC
<a href="#">S3-R-A2-5</a>	
<a href="#">400-400-010</a>	BAR CODE READER SCANNER .8-.27AMP 10-30VDC

<a href="#">10000-65116</a>	LASER BARCODE SCANNER OMNI-DIRECTIONAL AXIOM-X
<a href="#">S50-Pa2-C10pp Datasensor</a>	
<a href="#">S81-PI-5-M03-Ppc</a>	
<a href="#">S18-5-F-32</a>	
<a href="#">S50-Ma-5-A00-Pp</a>	
<a href="#">95b020060 Rf-50-5-P Slot Sensor 50mm M8 Pnp</a>	
<a href="#">952001330 S50-Pa-5-W03-Ppcontrast Sensor Plastic Axial Pnp No/Nc - M12</a>	
<a href="#">Ds6400-105-010</a>	931351103/ VLD HIGH PERFORMANCE LASER SCANNER/ SEPARATE GATEWAY FOR DEVICENET COMMUNICATIONS
<a href="#">S18-5-A82</a>	
<a href="#">Ds4800-1100</a>	BAR CODE SCANNER
<a href="#">Datasensor S50-Pa5-Co1pp</a>	
<a href="#">50.314.5364</a>	
<a href="#">964401100 Sensor Kontrastierenden Markierungen F. Datasensor Typ: Tlu 115</a>	
<a href="#">Ds2100-1110</a>	BARCODE SCANNER G8 FIXED POSITION 350SCAN/SEC STD
<a href="#">S3-R-D12 Fixed Focus Plastic Radial Npn/Pnp Out Cable</a>	
<a href="#">S50-Na-5-C01</a>	
<a href="#">964401100</a>	
<a href="#">Av4000-24s</a>	POWER SUPPLY OP:24VDC 12A IP:100-240VAC 4.5A
<a href="#">Ds8100a-3015</a>	BAR CODE SCANNER 1.3-0.9AMP 20-30VDC
<a href="#">Sf30-Pm, Ein Altes Produkt, Neue Es - 953151070 Sr21-Ir M8 Npn/Pnp</a>	
<a href="#">S10-Ma-5 B01-Nd Sensor</a>	
<a href="#">06-Av4000-001</a>	DECODER 6.3AMP 115-230VAC 47-63HZ
<a href="#">Qd-01</a>	
<a href="#">Av4000</a>	CAMERA CCD ASSEMBLY
<a href="#">S50-PI-5-C01-Pp</a>	
<a href="#">Das76021801</a>	
<a href="#">951501080</a>	M12 8P

<a href="#">J950330000</a>	
<a href="#">Optischer Sensor Datasensor S8-Pr-3-Wo3-Pp Mit Gegenstecker Und Kabel 2m</a>	
<a href="#">S6-5-M25 Sv2241 Sensor</a>	
<a href="#">951451300</a>	
<a href="#">Double-X</a>	LASER BAR CODE SCANNER
<a href="#">70a</a>	LASER SCANNER
<a href="#">951451520 S300-Pa-1-B01-Rx Pol 24-240vac/Vdc</a>	
<a href="#">Sr21-Ir Sensor</a>	
<a href="#">S936420000 Sensor</a>	
<a href="#">Em-50</a>	SCANNER EXPANSION MODULE 100-240VAC .6AMP
<a href="#">Sm-Pr-2-G00-Xg</a>	
<a href="#">Hf-Cntl-Pbs-02</a>	COBALT RFID PROFIBUS CONTROLLER
<a href="#">951451480 S300-Pa-1-A01-Rxreflex Plastic Axial Ac Relay Out No/Nc Terminalblock</a>	
<a href="#">1000069265</a>	TL ACCESSORY, AXIOM/AXIOM-X, PRE-ASSEMBLED, DOMESTIC WIRING BASE/IP40 POWER SUPPLY/UNIVERSAL MOUNTING BRACKET
<a href="#">Hs880b</a>	PARALLEL CONTROLLER W/64 I/O
<a href="#">Ds41-11</a>	BARCODE SCANNER 10-30VDC
<a href="#">Mini-X</a>	BARCODE SCANNER OMNI-DIRECTIONAL
<a href="#">S50-Ma-5-B01-Pp</a>	
<a href="#">0104638001</a>	BARCODE SCANNER HEAD 2LASER STANDARD AXIOM400
<a href="#">55bvv</a>	BAR CODE SCANNER HEAD
<a href="#">Ldu-455 Sv2239 Sensor</a>	
<a href="#">Tx S5.5.G12.02-24vdc</a>	
<a href="#">S62-Pa-5-M01-Pp Sensor/S62-Pa-5-M01-Pp/300mm/ Pnp/Stecker M12</a>	
<a href="#">Av4000-D</a>	DECODER MODULE
<a href="#">Cm21-R006</a>	INTERFACE MODULE 20-28VDC
<a href="#">950551030 S7-5-E-Pfiber Optic Amplifier With Display - M8 Connector Pnp</a>	

<a href="#">S5-5-C35-32</a>	
<a href="#">Avi-S</a>	AVI-S SODIUM ILLUMINATION MODULE
<a href="#">954651000 Fotosensor TI50</a>	
<a href="#">S51-Ma-5-C01-Pk Sensor</a>	
<a href="#">S50-Ma-5-C01-Pp Sensor Touch</a>	
<a href="#">G5210530</a>	
<a href="#">Sensor S5-5-C10-32</a>	
<a href="#">Ds2400a-2210</a>	SCANNER 10-30VDC CLASS2 WAVE630~680NM
<a href="#">952701521 Optischer Sensorproximity Metal Axial Pnp L/D Input - M12 /0- 100mm</a>	
<a href="#">S50-Pa-5-C01-Pp Datasensor</a>	
<a href="#">S50-Pa-5-C01-Pp Sensor</a>	
<a href="#">S5-5-B3-37 Sv2031</a>	
<a href="#">S50-PI-5-B01-Pp</a>	
<a href="#">S12m-5-B82b Optical Sensor</a>	
<a href="#">Av3700</a>	CAMERA CCDW/LED MODULE
<a href="#">S2-5-B3</a>	
<a href="#">Sr21-Ir</a>	
<a href="#">S2-1-C90</a>	
<a href="#">95acc6170 Sicherheitsrelais Se-Sr2-Type 4 Safety Relay 3no 1nc</a>	
<a href="#">Ds2400-2100</a>	BARCODE SCANNER LONG RANGE VLD RS-232 +RS-485
<a href="#">0611001-091008-217</a>	BARCODE SCANNER STANDARD RANGE W/12FT CABLE
<a href="#">S6-1-B5 Optic Sensor</a>	
<a href="#">Hms820-05</a>	READER/WRITER PASSIVE CONVEYOR MUX32