



## Endress & Hauser

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Endress & Hauser** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Endress & Hauser T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen Özel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*

¼r¼n	A¼ıklama
<a href="#">PRPSONIC FLOW 92F</a>	Ultrasonic flowmeter 12-30VDC , 4..20mA , DIN50 , Order code: 92F50-DSEA12A0A4AA , for Cements Inlet Shoe Bearing
<a href="#">PRPSONIC FLOW 92F</a>	Ultrasonic flowmeter 12-30VDC , 4..20mA , DIN80 , Order code: 92F80-ASEA12A0A4AA , for Cements Inlet Gearbox
<a href="#">FTC260-AA4C</a>	
<a href="#">10w1f-UI0a1aa0a4aa</a>	ELECTROMAGNETIC FLOW METER 85-250VAC 4-20MA
<a href="#">Fmi51-Aiktdjb2eia</a>	LEVEL SENSOR CAPACITIVE
<a href="#">Dc12ta-J11fc1bkr1</a>	PROBE LEVEL TRANSMITTER 30IN STEM
<a href="#">3adt220090r0040</a>	MODULE
<a href="#">Cls52-A1cs1a3</a>	INDUCTIVE SENSOR W/TRI CLAMP 2IN 20M CABLE
<a href="#">Ftm50cgjba2ah7ad</a>	DEVICE
<a href="#">50p40-2l1a1r10baaa</a>	FLOWMETER PROMAG 1-1/2INCH 85-260VAC
<a href="#">Fmr245-Tcalkac4a</a>	TRANSMITTER LEVEL RADAR MICROPILLO

<a href="#">Rma42-Aab</a>	TRANSMITTER MODULE
<a href="#">53w1h-Plgb1aa0baai</a>	ELECTROMAGNETIC FLOW MEASURING SYSTEM PROMAG
<a href="#">Rsq30b1b1aba1</a>	TOUCH SCREEN
<a href="#">Dme-270</a>	MASS FLOW TRANSMITTER 115V 50/60HZ
<a href="#">Ftl51h-Agw2bc2g6a</a>	LEVEL SWITCH
<a href="#">Ftm50agj2a4a37a</a>	MODULE
<a href="#">Cm42-Mga001eae00</a>	PH/ORP TRANSMITTER LIQUILINE M CM42
<a href="#">53w2f-Ulob1raobaa2</a>	ELECTROMAGNETIC FLOW MEASURING SYSTEM PROMAG 53W
<a href="#">Nx 9121</a>	3 Channel NX 9121 Power Supply Unit K30648383/002
<a href="#">Pmp75-Aba2p11tkaaa</a>	PRESSURE TRANSMITTER CERABAR
<a href="#">Cpm200-00ae82</a>	CONTROLLER LIQUISYS-P / PH AND REDOX MEASURE 24VDC
<a href="#">Cyk10-A251</a>	Data Cable Assembly 58020336
<a href="#">Fmb70-Acd1hb260caa</a>	PRESSURE TRANSMITTER 4-20MA 11.5-45VDC
<a href="#">Cus41-A2</a>	OXYGEN SENSOR
<a href="#">50p25-Er0b1rc2bbah</a>	FLOW METER 15.9BAR
<a href="#">83f15-Aftaaanab2aa</a>	PROMASS F FLOW METER
<a href="#">Pmc51-Aa12id1fgfu7ja</a>	Cerabar Pressure Transmitter, no LCD, 6psi gauge
<a href="#">50w25-Ulga1ra0b8aa</a>	FLOWMETER PROMAG 50W WATER
<a href="#">Fmu861r1f2b8</a>	LEVEL CONTROL 115VAC 50/60HZ
<a href="#">Rn221n-B1</a>	Functional Safety Active Barrier Module PTB 00 ATEX 2018
<a href="#">Fmb70-Abt1c42tdcaa</a>	FLOWMETER 11.5-45VDC
<a href="#">Pmd235-2u4g9eh3d</a>	PRESSURE TRANSMITTER -400 TO 400IN/H2O 2000PSI MAX
<a href="#">Com223f-Hs1405</a>	TRANSMITTER DISSOLVED OXYGEN
<a href="#">Clm121-3cd03</a>	MYCOM-L Controller
<a href="#">Cld132-Pmv138ab2</a>	CONDUCTIVITY SYSTEM 4-20MA 24VAC/DC 0-60HZ 7.5VA
<a href="#">50106094</a>	KIT MEAS. AMPLIFIER PMASS 80
<a href="#">Pmp55-132r9/0</a>	CERABAR PRESSURE SENSOR
<a href="#">Fmx167-A1aba1a7</a>	PRESSURE SENSOR 0-0.1BAR
<a href="#">50098300</a>	FLOWMETER 2RELAY
<a href="#">Nt 471</a>	Power Supply Module AP153.500

<a href="#">53h801f0b1rc5b2aa</a>	FLOWMETER MAGNETIC INDUCTV 15VA/W 85-260V PROMAG53
<a href="#">Fmd76-And7f4dpaa</a>	PRESSURE TRANSMITTER DELTABAR S 200 IN H2O 32VDC
<a href="#">72f25-Se0ac11aa4aa</a>	PROWIRL 72F25, DN25 1, VORTEX FLOWMETER
<a href="#">Fmu41-Anb2a4</a>	TRANSMITTER LEVEL MEASUREMENT
<a href="#">Fmd230-Kp3f9ec4bdk</a>	PRESSURE DELTABAR 0-280BAR 9-32VDC PROFIBUS-PA
<a href="#">50w1f-UI091ak5b4aa</a>	FLOW METER ELECTROMAGNETIC UP TO 700 MGAL/DAY
<a href="#">Fmr250-A5e1x3jaa4m</a>	TRANSMITTER RADAR LEVEL 36VDC MAX .8WATT 200DEG C
<a href="#">Fmu40-Ard1a5</a>	TRANSMITTER LEVEL MEASUREMENT 4-20MA
<a href="#">Fmu90-R12ca111aa1a</a>	FMU90 Prosonic S Ultrasonic Transmitter FMU90
<a href="#">Pmc51-Ca22id1sgfu7jj+aa</a>	Cerabar Pressure Transmitter, CSA C/US, HART, 600psi gauge
<a href="#">Cum253-Tu0005</a>	TURBIDITY TRANSMITTER TEMP -5/70C 7.5VA 230VAC
<a href="#">Fto1650-3-W-H2-I-N-N</a>	FLOW TRANSMITTER 115VAC 50/60HZ 11VA 4-20MA 217LB
<a href="#">52010286</a>	ULTRASONIC PROBE 14-36VDC 2WIRE 5METER RANGE
<a href="#">Cld134psms38ab1</a>	TRANSMITTER
<a href="#">Pmd230-2u1b2ea7f</a>	PRESSURE TRANSMITTER DIFFERENTIAL 145PSI
<a href="#">50p80-Er0a1aa0babw</a>	FLOWMETER PROMAG 15.9BAR 20-130C
<a href="#">Cm42-Maa000eac00</a>	PH/ORP TRANSMITTER LIQUILINE M CM42
<a href="#">53p25-El0b1aa0baaa</a>	FLOWMETER PROMAG DN25 1INCH 85-260VAC W/SENSOR
<a href="#">50h08-Eb0a1aa0abaa</a>	ELECTROMAGNETIC FLOWMETER PROMAG 50 5/16IN
<a href="#">50p1far0a1aa0ba</a>	METER
<a href="#">CIm223-Cd0010</a>	CONDUCTIVITY TRANSMITTER 230VAC 50-60HZ
<a href="#">33ft80-Fd1ab11a21a</a>	FLOW METER ELECTROMAGNETIC 3INCH
<a href="#">53h1h-1f0b1rc2baaa</a>	FLOWMETER MAGNETIC INDUCTV 15VA/W 85-120V PROMAG53
<a href="#">Rmc621a-Aa</a>	Flow and Energy Manager RMC621
<a href="#">53p1h-Eh0b1ac2aaap</a>	FLOWMETER PROMAG 53P1H DN100 4INCH
<a href="#">Ftm50-Dtd5k2ah7ac</a>	LEVEL SWITCH VIBRONIC 10-55VDC 3WIRE PNP 316L
<a href="#">Pmp51-1p4a3/101</a>	PRESSURE TRANSMITTER CERABAR-M 45VDC 1BAR
<a href="#">Pmp718bc1k11gaaa</a>	TRANSMITTER
<a href="#">Fmb70-Abt1hb200caa</a>	FLOWMETER 115-45VDC 20MA

<a href="#">Fmb50-Aa21sa1fgdunjb3u</a>	PRESSURE SENSOR 4-20MA 0.2-4BAR 11.5-45VDC
<a href="#">Fmr240-T4v1gnjac4a</a>	TRANSMITTER LEVEL-RADAR MICROPILOT
<a href="#">Pmp75-Abr1h11tfdaa</a>	PRESSURE TRANSMITTER CERABAR S 4-20MA 11.5-45VDC
<a href="#">Pmc45-Ge11m3r1yy1</a>	PRESSURE TRANSMITTER PROFIBUS PA 4/40MH20
<a href="#">Pmc41-Re25cbj11r1</a>	PRESSURE TRANSDUCER 100MBAR 4-20MA
<a href="#">Fmr245acalkba4a</a>	SENSOR
<a href="#">Clm223-Id1105</a>	CONDUCTIVITY TRANSMITTER LIQUISYS-M 4-20MA
<a href="#">Fmu860-R1a1b1</a>	PROSONIC CTRL
<a href="#">Fmu 860</a>	Ultrasonic Measurement Control Panel
<a href="#">Fm151-P1yrdjb1c1a</a>	LEVEL MEASUREMENT TRANSMITTER
<a href="#">Pmc71-Abc1p6raaaa</a>	PRESSURE TRANSMITTER 4-20 MA
<a href="#">50p2h-El0a1ra0baaa</a>	FLOW METER
<a href="#">50p50-2l1a1r10baaa</a>	FLOW METER PROMAG 2INCH 85-260VAC
<a href="#">93wa1-Ba1a20rcbaah</a>	FLOW MEASUREMENT SYSTEM 85-260VAC
<a href="#">Fmp57-Fdaccldla4rge-La</a>	LASER LEVER INDICATOR 580PSI 30VDC .8W 3630INCH
<a href="#">Fmx21-9fd4/0</a>	PRESSURE TRANSMITTER PROBE 0-200MBAR
<a href="#">53p50-El2b1ba0abab</a>	FLOW METER PROMAG 20-55VAC 16-62VDC 15VA 15W
<a href="#">Pmc51aa31rd1fgft</a>	CAPACITOR
<a href="#">63mt25-Saa09a25b1c</a>	FLOW METER 600PSI 1INCH
<a href="#">Fmr245-A3aekab2a</a>	TRANSMITTER LEVEL RADAR MICROPILOT 16-36VDC 0.8W
<a href="#">Com223f-Hx0005</a>	PRESSURE TRANSMITTER 96X96MM 230VAC FRONT IP54
<a href="#">Cld132-Pmv131aa1</a>	CONDUCTIVITY SYSTEM 115VAC 50/60HZ 7.5VA
<a href="#">Ftl70-1a50/0</a>	LEVEL SWITCH 250VAC 6AMP 3/4 NPT LIQUIPHANT-S
<a href="#">Rsg40b111b1a1c2a1</a>	MEMOGRAPH M 100-230VAC 50/60HZ
<a href="#">80f40-Aftsaaaabaad1</a>	PROMASS FLOW METER 80F40 DN40 1-1/2IN 600PSI/40BAR
<a href="#">50p15-El091rk5b4aa</a>	FLOW METER ELECTROMAGNETIC UP TO 42268 GAL/MIN
<a href="#">Ftl51h-Qyy9cd4e5a</a>	FLOW METER LIQUIPHANT M
<a href="#">Db42g-R1004dy31a1l</a>	DELTAPILOT PRESSURE TRANSDUCER
<a href="#">Fmx167-A1bbd1b7</a>	PRESSURE TRANSMITTER PROBE 0-0.6BAR 4-20MA 8-30VDC
<a href="#">50h08eb0a1aa0ab</a>	FLOW METER
<a href="#">Ftv1836-0d-A1-2-HI-K-0</a>	TRANSMITTER LIQUID FLOW VORTEX .5IN 24VDC 13.3ACFM

<a href="#">ClD132-Pva151aa1</a>	CONDUCTIVITY SYSTEM 7.5VA 115VAC 50/60HZ
<a href="#">53h50-1f0b1ab0b9ac</a>	FLOW MEASURING SYSTEM 230PSIG
<a href="#">Fmp40-Apr3cnjb11aa</a>	LEVEL TRANSMITTER LEVELFLEX M 580PSI 16-36VDC
<a href="#">50098801</a>	FLOWMETER PROLINE FIELDCHECK
<a href="#">Fmc-671-Z</a>	SILOMETER LEVEL MEASUREMENT FOR LIQUIDS SOLIDS
<a href="#">50p80-El0a1rc1b4aw</a>	CONTROLLER FLOW METER 260V 60HZ
<a href="#">Fmu43amh2a4</a>	ULTRASONIC CTR
<a href="#">Cpm223-Mr6005</a>	TRANSMITTER LIQUISYS
<a href="#">73f25-Sk4aa1naj6ah</a>	FLOW METER PROWIRL 73F25 DN25 1IN PROFIBUS PA
<a href="#">ClD132pmv118aa1</a>	UNKNOWN
<a href="#">Fmu860-R2d1a1</a>	LEVEL CONTROL TRANSMITTER PROSONIC FDU80 SERIES
<a href="#">Clm223f-If8105</a>	CONDUCTIVITY AND RESISTANCE TRANSMITTER
<a href="#">Fdu91sn4aa</a>	SENSOR
<a href="#">Pmd75-20n14\0</a>	PRESSURE TRANSMITTER DELTABAR CAL./ADJ. 0-600PSI
<a href="#">Ousaf44-B1b1</a>	UV SENSOR
<a href="#">Fmu40-Anb2a4</a>	TRANSMITTER LEVEL MEASUREMENT
<a href="#">10h02-Ec0a1ra0b4aa</a>	FLOW METER PROMAG H
<a href="#">Fmp40-Abd3njb21ca</a>	LEVELFLEX CONTINUOUS LEVEL TRANSMITTER
<a href="#">83f15-Aaasaarabaac</a>	FLOW METER PROMASS 83F15 DN15 1/2IN 4-20MA HART
<a href="#">Pmp46-Re13p1jlyyd</a>	PRESSURE TRANSMITTER 1/10BAR 11.5/45VDC
<a href="#">Fmr240-A5e1ggjaa2f</a>	LEVEL TRANSMITTER MICROPILLOT 40BAR 4-20MA 16-36VDC
<a href="#">ClD132-Pva151ha1</a>	CONDUCTIVITY SYSTEM 115VAC 50/60HZ 7.5VA
<a href="#">Cpm223ms5105</a>	TRANSMITTER
<a href="#">63fs50-99900a25b2a</a>	FLOWSENSOR MASS FLOW MEASUREMENT SYSTEM PROMASS 60
<a href="#">53xxx-Xxxxxa95baa2</a>	ELECTROMAGNETIC FLOW METER 85-260VAC 15VA/W
<a href="#">Fmb70-Ana1f12chcaa</a>	DELTAPILOT S SENSOR 0-400MBR 9-32VDC
<a href="#">Db50-Ac10bc11cg10</a>	PRESSURE SENSOR 0-1.2BAR IP66 M20X1.5
<a href="#">83f25-Aftaaanab2aa</a>	PROMASS FLOW METER 83F25 DN8
<a href="#">Db50-Ac22bb11ed10</a>	LEVEL TRANSMITTER HYDROSTATIC COMPACT 0-400MBAR
<a href="#">Pmc71-Aac1p62gdaa</a>	PRESSURE TRANSMITTER MWP 400.5PSI

<a href="#">Pmd75-Sac7bb1daaa</a>	PRESSURE TRANSMITTER 11.5-30VDC 4-20MA NEMA4X/6P
<a href="#">50h041aq30</a>	FLOW METER
<a href="#">80f1h-Aaasaarcbbah</a>	FLOW METER PROMASS 80 20-55VAC/16-62VDC 50-60HZ
<a href="#">Ftl 170 Z</a>	Nivotester FTL170Z Module FTL170Z
<a href="#">St37/A570</a>	FLOW METER MAGPHANT IP66 4-20MA 20-30VDC 2.5W
<a href="#">Pmp-48-Ge-13p-2r-2ekhi</a>	PRESSURE TRANSMITTER CERABAR M
<a href="#">Fmi51-A1btdjb1a1a</a>	TRANSMITTER LEVEL LIQUID 420MA
<a href="#">50p25-El0a1rc2baaw</a>	FLOW METER PROMAG 50 260V 60HZ 15W
<a href="#">50d803lga1aa0baa</a>	FLOW METER
<a href="#">Th27-Bb1e1cgc1ak</a>	THERMOWELL ASSEMBLY
<a href="#">50p1f-AI0a1aa0baaw</a>	FLOWMETER ELECTROMAGNETIC
<a href="#">Tmt162-F21131baa</a>	TEMPERATURE TRANSMITTER
<a href="#">Fmp40spr3cnjb21pa</a>	LEVEL TRANSMITTER LEVELFLEX M 580PSI 16-30VDC
<a href="#">83e25-Aaasaarabaa2</a>	FLOWMETER 1IN 85-260VAC 15V 316SS
<a href="#">Clm431-A3b21a</a>	CONDUCTIVITY TRANSMITTER MYPRO 4-20MA 12-30VDC
<a href="#">Pmc71tac1p6rabaa</a>	PRESSURE TRANS
<a href="#">53p15-El0b1aa0aaab</a>	FLOWMETER PROMAG-53 85-260VAC 50/60HZ 15VA/W
<a href="#">Cls52-A1cs1b2</a>	CONDUCTIVITY SENSOR 2INCH FITTING PEEK 10M CABLE
<a href="#">52028260</a>	ELECTRONIC INSERT UNIVERSAL HART
<a href="#">Fmb50-Aa21sa1mgbupjb3u</a>	PRESSURE SENSOR 4-20MA 0.2/4BAR 11.5-45VDC
<a href="#">Fmi51a1amrjb2a1a</a>	PART
<a href="#">Fmb70-Ana1h12chcaa</a>	DELTAPILOT S SENSOR 1.2BAR 9-32VDC
<a href="#">Cls54d-Aacs1a2a</a>	INDUCTIVE CONDUCTIVITY SENSOR 12BAR 3M CABLE
<a href="#">Fmr-130-0yyy9c3a2a</a>	LEVEL TRANSMITTER 3/4IN/NPT 20M 115VAC
<a href="#">50p25-Er1b1rc2bbah</a>	FLOW METER 15.9BAR
<a href="#">Ftl51-Agw2bb2g5a</a>	LEVEL SWITCH POINT 350MA MAX 212MM SWITCH 55VDC
<a href="#">Promag-50</a>	FLOW METER 20-55VAC/16-62VDC 50-60HZ 15VA/W
<a href="#">53h04-Ea0b1rc2b2aa</a>	FLOW METER 260V 60HZ 15W
<a href="#">Ftc-681-Z</a>	LEVEL METER 115V 50/60HZ 6VA
<a href="#">Fmb50-2mx6/0</a>	SILOMETER

<a href="#">Fmu41arb2a2</a>	LEVEL SENSOR
<a href="#">65i40ab4ad1aaab</a>	FLOW METER
<a href="#">Fmp40-Abb2grjb211a</a>	LEVEL TRANSMITTER LEVELFLEX 7000MM 40BAR
<a href="#">Fmu860-R1e1b8</a>	PROSONIC CTRL
<a href="#">Fmr244-A2vgnsac4a</a>	TRANSMITTER LEVEL RADAR MICROPILOT
<a href="#">Pm75-3rqa5\0</a>	PRESSURE TRANSMITTER DELTABAR CAL./ADJ. 0-40IN H2O
<a href="#">30ft50-Ma1aa11a11b</a>	ELECTROMAGNETIC FLOW METER PROMAG 30F 2INCH
<a href="#">Clm223-Cs0505</a>	CONDUCTIVITY AND RESISTANCE TRANSMITTER LIQUISYS-S
<a href="#">63m-T40-Stf00a25b1a</a>	FLOW METER 260VAC 50/60HZ 1/2IN NPT NEMA 4
<a href="#">Fmu90-R21ca111aa1a</a>	LEVEL TRANSMITTER PROSONIC-S 90-253VAC
<a href="#">Th13-13a12a2gd31ak</a>	THERMOCOUPLE 7-1/2IN 4WIRE 50-200C
<a href="#">Pmp75-Abr1f11tfdaa</a>	PRESSURE TRANSMITTER CERABAR S 4-20MA 11.5-45VDC
<a href="#">Clm223id8005</a>	MODULE
<a href="#">Cld132-Pmv138ab1</a>	CONDUCTIVITY SYSTEM 24VAC 0-60HZ 7.5VA IP67
<a href="#">Fmu41-Anb1a4</a>	TRANSMITTER LEVEL MEASUREMENT
<a href="#">Pmc71-Tbc1k6ra13u</a>	PRESSURE TRANSMITTER
<a href="#">50h50-1f0a1ab0b9aw</a>	FLOW METER 85-260VAC 15VAW 50/60HZ DIGITAL DISPLAY
<a href="#">Fmu860-R7d1b1</a>	LEVEL CONTROL SWITCH PROSONIC FMU860
<a href="#">Pmd235-2u4f9eh3d</a>	PRESSURE TRANSMITTER -200 TO 200IN/H2O 2320PSI MAX
<a href="#">53p1f-Eh0b1ac2aaaa</a>	FLOWMETER PROMAG 53P1F DN150 6INCH
<a href="#">53h50-Vh0b1ac2b2am</a>	FLOW METER ELECTROMAGNETIC 85-260VAC
<a href="#">Clm223-Cd8405</a>	CONDUCTIVITY AND RESISTANCE TRANSMITTER
<a href="#">80f25-Aftsaaaabaaa</a>	FLOWMETER MASS DN25 1IN 85-260VAC 15VA/W
<a href="#">Fmb70-Abt1f4257caa</a>	FLOWMETER 115-45VDC
<a href="#">Cpm223mr8105</a>	HOUSING
<a href="#">Clm223-Cd1505</a>	CONDUCTIVITY TRANSMITTER LIQUISYS
<a href="#">Fmu860-R7d1a1</a>	Prosonic FMU 860
<a href="#">Fmb50-Aa21ra1hgatej3u</a>	DELTAPILOT M FMB50
<a href="#">Promag-H</a>	FLOW TRANSMITTER 3-3/4IN ID
<a href="#">Pmc41pg21f6j11a1</a>	PRESSURE TRANS
<a href="#">Cpm153-A5e10a010</a>	PH/ORP TRANSMITTER 100-230VAC 50/60HZ 10VA



<a href="#">73f25-Sk4aa1nab4aw</a>	FLOW METER VORTEX 1INCH 4-20MA PROWIRL
<a href="#">33ft50-Ad1aa11a21a</a>	FLOW METER 85/260VAC 50/60HZ
<a href="#">Th13-1a22a2aii1bk</a>	TEMPERATURE DETECTOR
<a href="#">Hta423-H0</a>	HTA 423 Contactor 15027
<a href="#">Promag-P</a>	FLOW METER 85/260VAC 15VA 50/60HZ
<a href="#">80f15-Aaasaarcbbah</a>	FLOW METER/CONTROLLER 20-55VAC 16-62VDC
<a href="#">Pmp731-R33z9e11f1</a>	PRESSURE TRANSMITTER 4-20MA -15-6000PSI 11.5-45VDC
<a href="#">33ft32-Fh1bb41a22a</a>	ELECTROMAGNETIC FLOW METER PROMAG 33
<a href="#">Cpm153-04a00a100</a>	TRANSMITTER MYCOM 20MA 2PH 100-230VAC 1/2NPT
<a href="#">Tmt162-A2a3aafkd</a>	TEMPERATURE TRANSMITTER
<a href="#">Tmt162-F41231da1</a>	TEMPERATURE TRANSMITTER
<a href="#">Ria45-A1c1</a>	DIGITAL INDICATOR 24-230VDC 50-60HZ 14VA
<a href="#">Ftl51c-Aaekbk5g4aa-1500mm</a>	LEVEL SWITCH LIMIT LIQUIPHANT 8/16MA 11-36VDC
<a href="#">50p80-Eh0a1aa0abaw</a>	FLOWMETER PROMAG 16BAR 20-130C
<a href="#">32077076/0010</a>	MEMO-GRAPH 16INPUT RECORDER DISPLAY 5.7IN
<a href="#">33at04-2d1ab11a21a</a>	ELECTROMAGNETIC FLOW METER PROMAG 33A
<a href="#">Mf0-08055b12001</a>	PRESSURE CONTROLLER
<a href="#">50p1h-El0a1rc1baaw</a>	FLOW METER PROMAG50 260V 60HZ 15W
<a href="#">286502-004</a>	TRANSMITTER SUPPLY 24VDC 5RW 4-20MA
<a href="#">Cld132pmv111aa2</a>	MEASURE DEVICE
<a href="#">Pmd70-Sbc7f4daau</a>	PRESSURE TRANSMITTER 4-20 MA HART
<a href="#">53w1h-Ul0b1ac2baaa</a>	ELECTROMAGNETIC FLOW MEASURING SYSTEM PROMAG 53
<a href="#">Cls54d-1020/0</a>	INDUCTIVE CONDUCTIVITY SENSOR 12BAR 3M CABLE
<a href="#">Pmp41-Pc23pbr21g1</a>	FLOW METER DIGITAL DISPLAY
<a href="#">Rsg35-B1b+aac1</a>	Ecograph T Universal Graphic Data Manager Paperless Recorder
<a href="#">Fmp51-2q8h8/0</a>	LEVELFLEX FLOW TRANSMITTER 275PSI 30VDC
<a href="#">83f08-Cfudaanab3ae</a>	MASS FLOW MEASURING SYSTEM 20/55VAC 50/60HZ 15VA/W
<a href="#">Pmd753bj7cb1daau</a>	MEASURE DEVICE
<a href="#">50w25-Ul0a1aa0baaa</a>	FLOW METER ELECTROMAGNETIC 1INCH 85-260VAC PROMAG



<a href="#">Fmp55-1tq5/0</a> <a href="#">Cm42-Maa000eaj00</a>	TRANSMITTER LEVELFLEX 4-20MA HART US PH/ORP TRANSMITTER LIQUILINE M CM42
<a href="#">50h65-1f0a1a40baaw</a>	FLOW METER 85-260VAC 15VAW 50-60HZ DIGITAL DISPLAY
<a href="#">Pmc51-Aa21rd2pgftdj</a>	Cerabar Pressure Transmitter, HART, LCD, SS Housing w/Window
<a href="#">Pmc71-Snd1p6rdaaa</a>	PRESSURE TRANSMITTER
<a href="#">Tmt162-A213aaaaka</a>	TEMPERATURE TRANSMITTER
<a href="#">53w2f-Ulhb1ak5baa2</a>	ELECTROMAGNETIC FLOW MEASURING SYSTEM PROMAG 53W
<a href="#">Pmc71-Snc1cbrddau</a>	FLOW METER W/DIGITAL DISPLAY 9-24VDC
<a href="#">63mt08-99f00a25b1f</a>	FLOWMETER PROMASS 63 M 5/16IN TRICLAMP NEMA 4X
<a href="#">Cpm223pr0005</a>	TRANSMITTER
<a href="#">Fmr245-Abaekaa4a</a>	TRANSMITTER LEVEL-RADAR MICROPILOT
<a href="#">53p1h-El1b1rc1baaa</a>	FLOWMETER PROMAG ELECTRONIC
<a href="#">Att11-A11d31b6d1</a>	FLOW SWITCH T-SWITCH
<a href="#">Pmd75abc7f41bamu</a>	TRANSMITTER
<a href="#">Cpm223-Pr1505</a>	LIQUISYS PH REDOX TRANSMITTER 115VAC 1X20MA
<a href="#">Cld132-Wcs118aa1</a>	CONDUCTIVITY MEASURING SYSTEM KIT 24VAC 0-60HZ
<a href="#">Fmb50hfc10</a>	MODULE
<a href="#">50p4h-El0a1ra0baaa</a>	FLOWMETER PROMAG 50P4H DN400 16INCH 85-260V 4-20MA
<a href="#">Cls21c3b3a</a>	SENSOR
<a href="#">Cus31-W2e</a>	TURBIDITY SENSOR 880NM
<a href="#">50p1h-Al0a1ac1baaw</a>	FLOWMETER ELECTROMAGNETIC
<a href="#">Fmb70-Abr1ha2tdcaa</a>	DELTAPILOT S FMB70
<a href="#">Fdu 80-Jg1a</a>	Ultrasonic Sensor FDU 80-JG1A
<a href="#">33dt25-Bd1eb11a22a</a>	FLOW METER ELECTROMAGNETIC PROMAG 20-55VAC 16-62V
<a href="#">Pmd75aac7h41danu</a>	LINEAR PRESSURE TRANSMITTER
<a href="#">Ftm51-Agg2m4a12aa</a>	POINT LEVEL SWITCH, SOLIPHANT. .
<a href="#">83e25-Aaasaaaabaaa</a>	FLOWMETER PROMASS DN25 1INCH 85-260VAC W/SENSOR
<a href="#">Cpm223mr5105</a>	TRANSMITTER
<a href="#">Fmx167f2bv1c5</a>	WATER
<a href="#">CIm253cd8105</a>	TRANSMITTER

<a href="#">Fmr250-Nee3apjaa4m</a>	TRANSMITTER MICROPILOT RADAR CONTINUOUS LEVEL
<a href="#">Fmb-50aa22qa1mgbu</a>	SILOMETER LEVEL MEASUREMENT
<a href="#">40e25aacsaanab5a</a>	FLOW TRANSMIT
<a href="#">80f40-Aftsaanabaaa</a>	FLOW METER MASS
<a href="#">83f15-Aaasaaralaah</a>	FLOW METER PROMASS 83F15 DN15 1/2IN PROFIBUS
<a href="#">Tmt162-F41231dae</a>	TEMPERATURE TRANSMITTER 4/20MA 20/4MA 11V 0.022AMP
<a href="#">50p2har0a1aa0ba</a>	METER
<a href="#">Pmc41-Re11p1h21m1</a>	PRESSURE SWITCH 0-10BAR 11.5-45VDC
<a href="#">Fmu42-Atd2a22a</a>	ULTRASONIC PROBE MEASUREMENT DEVICE
<a href="#">Fmb70-Abt1fa257caa</a>	FLOWMETER 115-40VDC
<a href="#">50h04-Eb091rc5b4aa</a>	FLOW METER WALL MOUNT HOUSING 1250GAL/MIN
<a href="#">Pmd75-1ba7bb1babu</a>	PRESSURE TRANSMITTER
<a href="#">80a04-Astaaaaabbaa</a>	FLOW METER 1/8INCH PROMASS 80 DN04
<a href="#">Pmp55-Dwp0/0</a>	PRESSURE TRANSMITTER 4-20MA 11.5-30VDC 7.5-150PSI
<a href="#">Fmu90-R12ca262aa1a</a>	TRANSFORMER CONTROL 90/253VAC 50/60HZ
<a href="#">10d1h1170142</a>	METER
<a href="#">Cld132-Wmv130aa1</a>	CONDUCTIVITY SYSTEM 230VAC 50/60HZ 7.5VA
<a href="#">Fmu90-R11cb232aa3a</a>	ULTRASONIC LEVEL TRANSMITTER
<a href="#">Cm42-Maa001eae00</a>	TEMPERATURE READER 750MW 30V 12.5VDC
<a href="#">Ftl320-01b1</a>	RELAY 90-140V 50/60HZ
<a href="#">53p50ea0b1aa0a7a</a>	TRANSMITTER
<a href="#">53h65-2lw7/0</a>	FLOW MEASURING SYSTEM PROLINE PROMAG 53H
<a href="#">Ftm50dgj2a4a37a</a>	SWITCH
<a href="#">Ccm253-Ek1110</a>	CONDUCTIVITY TRANSMITTER
<a href="#">50p15-El0a1ra0baaw</a>	FLOW METER ELECTROMAGNETIC 85-260VAC DISPLAY STAND
<a href="#">Pmc71-Abc1h6agaaa</a>	PRESSURE TRANSMITTER W/DIGITAL DISPLAY 0-15PSI
<a href="#">Fmb70aca1h1200ca</a>	TRANSMITTER
<a href="#">53h50-1f0b1ra0baaa</a>	FLOW MEASURING SYSTEM 85-260VAC 50/60HZ 15A
<a href="#">Pms45-Rc11p6j1yy1</a>	PRESSURE TRANSMITTER 0-150PSI 600PMAX 45VDC
<a href="#">Cpm223-Pr1405</a>	TRANSMITTER LIQUID PH/ORP
<a href="#">Fmb50-2a97/115</a>	DELTAPILOT M HYDROSTATIC SENSOR 11.5-45VDC

<a href="#">Rsg10-A212a21fa</a>	MEMO-GRAPH 25VA 24VAC/DC 50/60HZ
<a href="#">80f25-Aflwaaaaabaa</a>	FLOW METER VOLUMETRIC 4-20MA 20-55VAC/16-62VDC
<a href="#">80f40-Aaasaarbbaad</a>	PROMASS FLOW METER 80F40 DN40
<a href="#">Fmx21-Aa211hge21a+prpspw</a>	Waterpilot Hydrostatic Level Probe, HART, .87", Ext. Cable
<a href="#">50090792</a>	TRANSMITTER MODULE FOR PROMASS 60 HART
<a href="#">Dc35000e10002000</a>	CONTROLLER
<a href="#">50p25-Er0a1aa0babw</a>	FLOW METER 260VAC 50-60HZ
<a href="#">Pmp48-Ge-13p-2r-1eka1</a>	PRESSURE TRANSMITTER CERABAR M
<a href="#">Pmp71-1vcd9/0</a>	DIGITAL PRESSURE TRANSMITTER CERABAR 0-1500PSI
<a href="#">63fs08-Fuw00a10b2a</a>	FLOW SENSOR MASS FLOW MEASUREMENT SYSTEM PROMASS 63
<a href="#">FtI515atw80</a>	MODULE
<a href="#">Pmc41-Cc21cbh11n1</a>	PRESSURE TRANSMITTER CERABAR M 45VDC TYPE 4X
<a href="#">Fmp40-Apr2cnjd21da</a>	TRANSMITTER LEVEL RADAR LEVELFLEX M 36IN 580PSI
<a href="#">Cpm223-Ps0005</a>	TRANSMITER PH 230VAC 4-20MA
<a href="#">50p1h-Er9b1rc2bbah</a>	FLOW METER PROMAG P NEMA 4
<a href="#">50h15a00a1aa0ab</a>	METER
<a href="#">Pmc51-Aa12qd1sgirlja</a>	Cerabar Pressure Transmitter, no LCD, 6psi gauge
<a href="#">Pmd75-Abc3lb1daua</a>	PRESSURE TRANSMITTER 45VDC
<a href="#">Pmd75acj7bb1daau</a>	MEASURE DEVICE
<a href="#">Cld134xsms38aa1</a>	TRANSMITTER
<a href="#">Fmu-860-U1a1b1</a>	PROSONIC CONTROL 115VAC 15VA
<a href="#">Rta421-A11a</a>	Contactora
<a href="#">Tmt162-A21231bka</a>	TEMPERATURE TRANSMITTERS
<a href="#">50h04-Kaiaiaaooaca</a>	PRESSURE TRANSMITTER PROMAG H
<a href="#">Fmx167a2cbe1a7</a>	COIL
<a href="#">Fmb50-1lh0/0</a>	LEVEL MEASUREMENT HYDROSTATIC 4-20MA 11.5-45VDC
<a href="#">Cls52-A1mv1a1</a>	INDUCTIVE SENSOR 16BAR W/5M CABLE
<a href="#">50w50-Ul0a1ra0baaw</a>	FLOW METER 85-260VAC 15VA 15WATT 50/60HZ
<a href="#">Pmp46-Re27h1jcyyd</a>	PRESSURE TRANSMITTER -1-1BAR 20MA HART 11.5-45VDC
<a href="#">Fml621-B22ghaaaa11</a>	Vibronic Measurement Density Computer FML621

<a href="#">Pmd70-Snd7f4daau</a>	PRESSURE TRANSMITTER
<a href="#">Fmb70aaa1c42cgca</a>	TRANSMITTER
<a href="#">Ftl320-G1a1</a>	RELAY 180-253V 50/60HZ
<a href="#">83f15-Aftsaanab2as</a>	PROMASS FLOW METER 83F15 DN15 1/2IN 600PSI/40BAR
<a href="#">50h22-Eb0b1ac5b4aa</a>	FLOW METER WALL MOUNT HOUSING 1250GAL/MIN
<a href="#">ClD132-Pcs138ab1</a>	CONDUCTIVITY TRANSMITTER 15AMP 24VAC/DC
<a href="#">Fmp41c-Sdafkb21a4a</a>	TRANSMITTER 40INCH 150LB 315FLANGE W/DISPLAY
<a href="#">Fmp57aaaacanca4</a>	MODULE
<a href="#">33ft25-Mh1fd41d21a</a>	FLOW METER W/SENSOR/XMITTER 1/2IN NPT 150LB ANSI
<a href="#">Pmp75-3ba1fb1tfdba</a>	PRESSURE TRANSMITTER 400MBAR 4-20MA CERABAR-S
<a href="#">Fmu862-R1a2c1</a>	LEVEL CONTROL 48VAC
<a href="#">50p15-El0a1rc2b4aa</a>	FLOW METER 16BAR TM MAX 130/265DEG F
<a href="#">Rsa10-31b2c</a>	CHART RECORDER 253VAC 50/60HZ
<a href="#">Fmr231aafapk1a4a</a>	SENSOR TRANSMITTER MICROPILOT II 30VDC
<a href="#">Pmc45-Sc21pbj1bf1</a>	PRESSURE TRANSMITTER PIEZORESISTIVE MEASURING CELL
<a href="#">Fmu90-R11ca161aa1a</a>	ULTRASONIC LEVEL TRANSMITTER
<a href="#">Clm431-A3b2ia</a>	CONDUCTIVITY TRANSMITTER MYPRO 4-20MA 12-30VDC
<a href="#">Mmy30-R1c1a</a>	SENSOR DEWPRO 32VDC 500PSIG
<a href="#">48055188/0010</a>	MEMO-GRAPH 25VA 24VAC/DC 50/60HZ
<a href="#">83f50-Aftaaacb2aa</a>	FLOW TRANSMITTER 85/260VAC 15VA/W 50/60HZ
<a href="#">Za 371</a>	Interface Module
<a href="#">315023-0200</a>	POWER SUPPLY BOARD 115VAC
<a href="#">33ft1h-Mh1fd51f21a</a>	FLOW METER 4INCH
<a href="#">Fte30-Ea13</a>	LEVEL LIMIT SWITCH 20-28VDC 250VAC 10A 75MM SHAFT
<a href="#">Fmp41camafkb21a4a</a>	RADAR LEVEL TRANSMITTER 12IN 275 PSI
<a href="#">Att12-A22-D21-A4-D1</a>	FLOW MONITOR
<a href="#">53h08-Ea0b1aa0abaa</a>	ELECTROMAGNETIC FLOW METER PROMAG 53 5/16IN
<a href="#">Pmc51v4x60</a>	DEVICE
<a href="#">Ftl70-Qgm2ab4e7al</a>	LEVEL SWITCH 250VAC 6AMP 3/4 NPT LIQUIPHANT-S
<a href="#">80f15-A999aarcbbah</a>	FLOW METER W/CONTROLLER 1/2IN 16BAR

<a href="#">93wa1-Ba1a20rcbaaa</a>	FLOW MEASUREMENT SYSTEM 85-260VAC 4-20MA
<a href="#">Dc11tan-Ka14c1bms2</a>	LEVEL TRANSMITTER 20 360PSI
<a href="#">53p25-Ef0b1ac1aaaa</a>	FLOWMETER PROGAM 53P25 DN25 1INCH
<a href="#">33ft25-Ad1ab11a21a</a>	ELECTROMAGNETIC FLOW METER PROMAG 33 1INCH
<a href="#">30fh1h-Md1fd51d21b</a>	FLOWMETER 85/260VAC 50/60HZ
<a href="#">Cld134pcs130aa1</a>	SENSOR
<a href="#">63fs4099900a25b2a</a>	FLOWSENSOR MASS FLOW MEASUREMENT SYSTEM PROMASS 60
<a href="#">Fmb50-Aa21sa1hgbupjb3u</a>	LEVEL MEASUREMENT HYDROSTATIC 4-20MA 11.5-45VDC
<a href="#">Pmc71-Sbc1p6rdaaa</a>	PRESSURE TRANSMITTER 4-20 MA HART 0-200 IN H2O
<a href="#">33ft1h-Mh1fd11f21a</a>	FLOWMETER PROMAG ELECTRONIC
<a href="#">At70f-A25g11bcb11</a>	FLOWMETER FOR O2 GAS 20C 20MA
<a href="#">Pmc71-Abc1p6rdaaa</a>	Cerabar S Pressure Transmitter, 4-20mA HART, LCD
<a href="#">83f25-Aftsaanab2aa</a>	FLOW METER MASS
<a href="#">Pmp55-Aa21ra-1sgjnzja4a</a>	PRESSURE TRANSMITTER CERABAR-M -10-400M H2O
<a href="#">Pmd230-Su1b2ea7f</a>	PRESSURE TRANSMITTER DIFFERENTIAL 145PSI
<a href="#">Ftc 671 Z</a>	Nivotester Module
<a href="#">FtI51hatc2dd4e6a</a>	PROBE
<a href="#">50p1h-Er9b1rc0bbah</a>	FLOW METER 4INCH 20-55VAC 16-62VDC
<a href="#">53p1h-El1b1aa0baaa</a>	FLOW METER ELECTROMAGNETIC 4IN 85-260VAC 15VA/W
<a href="#">52017193</a>	PRESSURE TRANSMITTER 4-20MA 0-200 IN H2O
<a href="#">50w25-UI0a1aa0laah</a>	FLOW METER ELECTROMAGNETIC 85-260VAC
<a href="#">50p25-Ea0a1aa0abaw</a>	ELECTROMAGNETIC FLOWMETER PROMAG 50P25 DN25 1INCH
<a href="#">Pmp46-Rc17h4jcdga</a>	PRESSURE TRANSMITTER 11.5-45VDC 1/2IN NPT
<a href="#">Pmd75-Snc7hb1daau</a>	FLOW METER W/DIGITAL DISPLAY 45PSI 9-24VDC
<a href="#">Fmu 861</a>	Ultrasonic Transmitter Prosonic
<a href="#">Cpm152-A1a1c20a</a>	TRANSMITTER 115V 47/64HZ
<a href="#">Fmr250-A5e1gnjba4m</a>	LEVEL RADAR MICROPILOT
<a href="#">Pmp46-Re13p1h1gld</a>	PRESSURE TRANSMITTER 0-10BAR 4-20MA 11.5-45VDC
<a href="#">Ftm50agj2a4a37aa</a>	LEVEL SWITCH
<a href="#">Fmb52-Cd21jd1hge25rgjb3u</a>	HYDROSTATIC LEVEL MEASUREMENT 11.5-45VDC

<a href="#">Cum253-Ts0010</a>	TURBIDITY TRANSMITTER TEMP -5/70C 7.5VA 230VAC
<a href="#">Pmd75-Snc7cb1daau</a>	FLOW METER 9-24VDC DIGITAL DISPLAY
<a href="#">Pmd75-Aba2881daau</a>	DIFFERENTIAL PRESSURE TRANSMITTER LCD 4-20MA HART
<a href="#">Pmc731-051k9h1k14</a>	PRESSURE TRANSMITTER FLUSH MOUNT 1/2NPT 30PSIG
<a href="#">Promag-53</a>	FLOWMETER MAGNETIC INDUCTIVE 15VA/W 85-120V 50-60H
<a href="#">50p15-El091ra0b4aa</a>	FLOW METER ELECTROMAGNETIC
<a href="#">50p80eloa1raobaaw</a>	FLOW METER 120V 3INCH
<a href="#">Pmp48rc17h6h2kd</a>	TRANSMITTER
<a href="#">83f25aftsaanab2aa</a>	MASS FLOW SENSOR PROMASS 83
<a href="#">83f15-Afuwaanab2as</a>	FLOW METER 85-260VAC 50-60HZ
<a href="#">Pmp46-Sc1m6jcdgd</a>	PRESSURE TRANSMITTER 0-60PSIA 160PSI 30 VDC
<a href="#">Fmu862-R1a1a1</a>	FLOW TRANSMITTER/ULTRASONIC LEVEL 2 CHANNEL
<a href="#">83f08-Aftsaanab2as</a>	PROMASS FLOW METER 83F08 DN8 3/8IN 600PSI/40BAR
<a href="#">C0a451-B1c</a>	BALL VALVE 2BAR DEPTH 270MM SENSOR 200-220MM
<a href="#">Pmd235-2u4h9eh3d</a>	PRESSURE TRANSMITTER -1200 TO 1200IN/H2O
<a href="#">Fmb50-Aa21ra1fgbmrjb3u</a>	SENSOR
<a href="#">Ccm253-Ep3005</a>	CONDUCTIVITY TRANSMITTER 115VAC 7.5VA 50/60HZ
<a href="#">Fmr240-T5e1yy9ac4a</a>	TRANSMITTER OPEN PATH LEVEL
<a href="#">50h40-W h0a1aa0bbad</a>	FLOWMETER 20/55VAC 16/62VDC 1.5INCH 1/2INCH NPT
<a href="#">319084-02000</a>	Power Supply Board Flowtec
<a href="#">83i15-Afudaaacl2ak</a>	FLOW TRANSMITTER 85-260VAC 50/60HZ
<a href="#">33dt80-Bd1ed11f21a</a>	FLOW METER ELECTROMAGNETIC 85-260VAC
<a href="#">Ftm50-Hgj2a4ah7aa</a>	LEVEL SWITCH SOLIPHANT M 19-253VAC/55VDC
<a href="#">72f1h-Sk0aa1nab6ah</a>	FLOW METER PROWIRL 72 250MA 1.2WATT 24V
<a href="#">Db50l-Ac00bc14bd30</a>	PRESSURE SENSOR DELTAPILOT S 0-1.200BAR
<a href="#">Pmp71-Sbc1w611aaaa</a>	PRESSURE TRANSMITTER 4-20MA 6000PSI
<a href="#">Pmc41-Cc21cba11r1</a>	PRESSURE TRANSMITTER CERABAR M 45VDC TYPE 4X