

Hochiki

Garanti: 12 ay
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin **info@yursat.com.tr** e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.
Hochiki Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

Firmamız Hochiki Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.



rn	Aıklama
Fnp1127us2ers120	FIRENET PLUS FACP, 1 LOOP, W/DIALER, EXPANDABLE, RED, 120V
Ns-24mcw-Fr	
Sfh45-153075r-25s	
Sh24c-177r	
Dh-99a	
Hec24-75ww	
Fnencbcr9th	
Hps-Bb	
Fnp-1127e-Bo	
Hp-24tr	
Fn-4127n-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD (220V) W/

Sprm	
B02002-00	
B02410-01	
Sfh45-75110r-25r	
Fn-Enc-Bc-Dd	
Hes24-177pww	
Fn-642-Ulada-R	
Glassrods	
Gus9-16	FIRENET GRAPHIX SOFTWARE PACKAGE- 9 TO 16 NODES
Fnv-100	100WATT VOICE EVACUATION MODULE WITH MICROPHONE
Nstt-H	
Fnm-Frcma	
Evax-50e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Sra-24reflector	
Fn-Lcd-N-Bb-G	
Fnv-50em	50 WATT EXPANDER MODULE WITH MICROPHONE. NO DMR)
Fn-Ctm	
Sbc-4/24w	
Fn-Lcd-N-Etr-R	
Fnm-Aca-V	
Sfh47-153075r-25s	
Fnv-Ioi	
Slr-24f	
Dsc-Ea	
Sig24	
Hp-25tw	
End Device - Not Hochikiã39;S	
Rai-Led	
Fn-2127-Ddw-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, CHARCOAL
Hes24-177ww	

R2mh-I	
Fn-Lcd-S-Bb-R	
Tse-A100	SMOKE GENERATOR POLE
Hec3-24ww	
Evax-200r/12z	EVAX 200 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Fn2127us0ers120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, RED
Sif-24f	
Fnv-M-Dr	
B03100-0	
Evax-400e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Ybc-RI/12	
Evax-150r	EVAX 150 PANEL. RED CABINET
Fnv-Mfh	
Slr-835bh-2w	
Fnv-100e	100 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Evax-150r/12z	EVAX 150 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Hec24-177wr	
Fn-Pmp	
Evax-200emr	200 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Guc232a	
Sfh47-75110r-70s	
Hmcc-1024-6	
Evx-2za	
Evax25r/2za	EVAX-25 PANEL WITH 2 CLASS A SPEAKER ZONES, RED CABINET
Ms-Ra	
Evax-50/8z	EVAX 50 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Alg-V(Blk)	
Fn-642-Ulada-G	
Shp24-153075r	

Hcp-204e	
Fn-2127nc	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, CHARCOAL
Frcme-A	
En54-7-2000 Replaced By Aln-En M (010-095)	
0200-03660	
Evx-Byc-4-H	
B02011-00	
Som-A-I	
Fn-Enc-Do-C	
Evax-25e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Slr-835	
Slr-24dh	
Dcp-Som-Ai	
Evax-50r	EVAX 50 PANEL. RED CABINET
Fn2127us0egs120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, GRAY
Sp4-Loc-Sb	SURFACE MOUNT LOCAL OPERATOR CONSOLE
Fnv-Mfp-Hs	
Dcd-Ae3	
Evax-150	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Fn-2127c	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS), CHARCOAL
Fnp-1127-Enc-Bc	
Hes24-75wr	
Fn-4127nc	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, CHARCOAL
Tch-B100	
Frcma/1	
Fnv-Dps25/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 25W, FIRE PHONE
Fn-Lcd-S-Bo	
Heh12-Pw	

Fnp-Etr-R	
Rfd-2000x	UV/IR FLAME DETECTOR (STAINLESS STEEL)
Evax-25	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BAT
Fn-Enc-C	
Fn-4127-Cpa-Bo	
Fnv-Fo	
Chq-Szm2(Sci)	
Evax50c8zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Pfc-4410-Wc	PT-4 ZONE AGENT OR WATER RELEASING PANEL, 4 INPUTS, 4 OUTPUTS, 1 SUPERVISORY, WHITE CABINET
Fn-4127-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) (220V) W/MANUAL(JUMPER/L
Fn-Lcd-N-Ct	NETWORK ANNUNCIATOR W/TRIM RING (CHARCOAL)
Fnp-1127-Enc-Do	
Fn-Etr-C	
Sfh45-153075r-70s	
Hcp-1008e (220 Vac)	8 ZONE DIP SWITCH FIRE ALARM CONTROL PANEL 220V
Sfh47-153075r-70r	
Fnp-1127de-C	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, EXPANDABLE, CHARCOAL
Heh24-W	
Evax-300e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Hcp-E	
Fn-2127-Ddwn-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW , W/NETWORK CARD, RED
Fn-Enc-Dd-R	
Hocdimdimm	
Sh-1224wp-R	
Hps-Dbb	
Sr Mounting Box	
Chq-Ab	

Dh24120gb2	
Evax-25er	25-WATT EXPANDER PANEL W/O DMR OR PAGING MICROPHONE. RED
Gus5-8	FIRENET GRAPHIX SOFTWARE PACKAGE- 5 TO 8 NODES
Sij-24	
Evax50r8zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-1, 120V
Hcfg	
Eolr-12	
Fnv-Dps100/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 100W, FIRE PHONE
Hx93-R	
Fnv-Dps50	DISTRIBUTED PANEL, SINGLE CHANNEL, 50W
Pfc-100rc	
Slb24-75cr	
Nh-12/24-W	
Sci-B4	
Atj-Ea	
Hes3-24pww	
Sif-E	
Frmce-A-I	
Ssc8-3075110r	
Dh-98i	
Hs24-60wr	
Evax-100/8z	EVAX 100 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Ns-24mcw-Fw	
Slr-E-Is	
Evax50c4zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Fnv-Mbr	
Fnv-Evx-Cab-1r	
Dcc-2el	
Fnp1127us20rs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, NOT EXPANDABLE, RED

Tsa-B110	SMOKE DETECTOR TEST BOX
Fn-Lcd-N-Bo	
Sbp-1	
Fn-4127-Bo	
Hs24-60ww	
Fnp-1127us0ers-120	FIRENET PLUS FACP, 1 LOOP, EXPANDABLE, RED, 120V
Fnv-Mp80/P	MASTER PANEL, 80 SWITCH / 48 INPUT, MASTER FIRE PHONE
Ashp-Acsmr-25	
Tch-B200	
Evax-100/4z	EVAX 100 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Fnv-Dp100-42	42 X26 X 6 CABINET
Evax-50/12z	EVAX 50 PANEL WITH 12 SPEAKER ZONES. GRAY CABINET
Ps-Exp	
Evax25/4za	EVAX-25 PANEL WITH 4 CLASS A SPEAKER ZONES, GRAY CABINET
Ns6-220	
Fn-2127n-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD (220V) W/
Fnv-Fpi	
Fnv-Ri	
Evax-150em	150 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY
R2m-H	
Sh24w-75110r	
Fn-2127-Ny-R	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW, NYC LOCK, RED
Hf-24 , Alternative B05401-00!!!!	
Evax-600er	600 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Evax150r12zm120	150 WATT VOICE EVACUATION PANEL W/DMR, MIC, 12 CLASS B SPKR CKT, RED CAB-2, 120V
Slr-24vn	
Fn-4127-Ddw-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, RED

Evax50r4zm120	50 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
Dcd-190	
Evax-200r/8z	EVAX 200 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Ir2-Uv-Ex	EXPLOSIVE PROOF RATED
Mx-Fo	
Dcp-Frcme-P	
Evax-600e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Fnlcdsus00g024	
Fh-47r-25s	
Sp4-Tzc	
Hes24-60pwr	
Dcp-Ams	
Solo108	
Fnv-Dps50/P	DISTRIBUTED PANEL, SINGLE CHANNEL, 50W, FIRE PHONE
Bk-2	
Fn-4127-Ddwn-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, CHAR
Hdact-100	
Hcp-W (Red) - Unknown Model	
C900v2	
Fn-4127n	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, RED
Hec3-12pwr	
Fn-Eck	
Evx-4z	
Evax25r4zm120	25 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
R2ml	
Gusr2004	2-4 WORKSTATIONS (4 REPEATER PACKAGE)- OPTIONAL ADDITIONAL 2-4 LICENSES FOR USE WITH PACKAGES, NO PH
Dcp-Ams-Lp/S	
Hps-Dakcat30	

Fnv-Dp25	DISTRIBUTED PANEL, DUAL CHANNEL, 25W
Hec3-12wr	
Som	
Mba-10	
Fnv-Dp200rp42120	100 WATT AMPLIFIERS), 4 FIR
Fn-300ulx-G	
Fnp1127us0egs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, GRAY
Nsrt-H	
Slr-835bh-2	
Hsc-224l	
808401347 -Unknown Model	
Hcp-202	
Fnv-Ev-Spkr-4w	
Fn-300ulx-C	
Dcp-Ams-Kl-Lp/S	
Fnv-50	50 WATT VOICE EVACUATION MODULE WITH MICROPHONE
Fnp-1127-Enc-C	
Fnv-Dp50/P	DISTRIBUTED PANEL, DUAL CHANNEL, 50W, FIRE PHONE
Pfc-Tr	
Fn-Natc	
Evax-25/4z	EVAX-25 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Fn-2127c-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) (220V) CHARCOAL GREY W/M
Banshee Exel Ip 66	
Pba-10	
Slr-24h	
Evax-25r/4z	EVAX-25 PANEL WITH 4 SPEAKER ZONES, RED CABINET
Fnv-Dp100	DISTRIBUTED PANEL, DUAL CHANNEL, 100W
Hcp-E(Sci), Sr2t	
Sp4-Loc-Fb	

Dh-98hvp	
Evax-100r/12z	EVAX 100 PANEL WITH 12 SPEAKER ZONES, RED CABINET
Fnm-Ams-Kl-Lp	
Evx-Ba-100	
Hsc-224r	
Atg-E - Is Atj-En(Wht)	
Fn-4127-Io	
Mx-Fj	
Fn-2127nc-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD (220V) CH
Fnv-Evx-Bb-2	
Evax25/2za	EVAX-25 PANEL WITH 2 CLASS A SPEAKER ZONES, GRAY CABINET
Slr-835b-4	
Dcp-Ams-Lp	
Fn-Lcd-N-C	NETWORK ANNUNCIATOR (CHARCOAL) W/MANUAL
Aca-E- , - Acc-En	
Hes24-60wr	
Hps-Sa-Ex/Wp	
Ashx-24smr-70	EXPLOSION-PROOF (CLASS I, DIV. 1, GROUPSB, C, D) SPEAKER AMPLIFIER 24VDC, 70
Hps-Dak-Sr	
Pfc-100rc-Pcb	
Fnv-Ev-Sab	
Gus33+	FIRENET GRAPHIX SOFTWARE PACKAGE- 33+ NODES
Spc-1	
Fn-Dc	FIRENET DEMO CASE
Fnv-Evx-Cab-42	26 X 42 X 6 W-H-D CABINET, GRAY
Fnv-Dps100/P-42	42 X26 X
Kentec H80161 M2	
Da-C/S	
Evax-200r/16z	EVAX 200 PANEL WITH 16 SPEAKER ZONES, RED CABINET

Evax50/4za	EVAX 50 PANEL WITH 4 CLASS A SPEAKER ZONES, GRAY CABINET
Fn-1042-Ulada-B	
Ssc2-3075110w	
Ashp-24smr-70	
Dcd-1e(Is)	
Fn-1042-Ulada-R	
Alk-E - Not Available	
Hec24-60pwr	
H-1224r	
Fnp-Man	
Fn-400ulx-R	
Evax-25r/8z	EVAX-25 PANEL WITH 8 SPEAKER ZONES. RED CABINET
Fn-Enc-Bc-C	
Hes24-110ww	
Sh24c-3075110r	
4bx-5w	
Alk-V	
Fn-Lcd-N-Rt	NETWORK ANNUNCIATOR W/TRIM RING (RED)
Sfh47-75110r-25r	
Evx-Za	
Slr-835+ns6-220	DET SMK SLR-835+NS6-220 W/BASE 60PCS SET
Fnencbaddr	
Heh12-Pww	
Heh24-Wr	
Fn-4127-Slc	
B02401-00	
Frcma-I	
Som-A	
Fnv-Mp16/P	MASTER PANEL, 16 SWITCH / INPUT, MASTER FIRE PHONE

Fn-Ps402	
Scm-24w-75110r	
Hec24-177pww	
Env-Mp48/P	MASTER PANEL, 48 SWITCH / 32 INPUT, MASTER FIRE PHONE
Fnp-1127-Bo	
Fh-47r-25r	
Evx-OI8-H	
Hec24-15ww	
Call Point	
Sp-Coa	
Slr-Em	
Hs24-1575pww	
Fn-2127-Ddw-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW , RED
Eol	
Chq-Ws2	
Env-25e	25 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Ge/Ifsd1300	RS485 TO FIBER CONVERTER, TRANSCEIVER GE/IFS D1300 24VDC
B02322-00	
Evax-200em	200 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY
Pba-8-120	
Fn-300ulx-R	
FnIctnus00g024	NETWORK ANNUNCIATOR W/TRIM RING (GRAY)
Env-Ev-Str-110	
Env-Dps25	DISTRIBUTED PANEL, SINGLE CHANNEL, 25W
Frcme-P	
Fn-V187	
Evax-25em	25 WATT EXPANDER PANEL WITH MICROPHONE, WITHOUT DMR, GRAY
Fn-4127-Ddw-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW , CHARCOAL

Evax-50/4z	EVAX 50 PANEL WITH 4 SPEAKER ZONES, GRAY CABINET
Fnv-Sp6	
Slr-835w	
Hps-Dak	
Evax-100r	EVAX 100 PANEL. RED CABINET
Fn-4127nc-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/NETWORK CARD (220V) CH
TI-205	TEST LAMP FOR RDF-2000X
Evx-Rly-H	
Sfh45-153075r-70r	
Spmb4z	
Fnp-1127-C	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, CHARCOAL
Dfj-Ae3	
Fnv-Evx-Cab-1	
Fn-842-Ulada-C	
Mx-Mfp-Hs	
Pb-Sa	
Cam	
Ybn-R/6	
Fnv-100em	100 WATT EXPANDER MODULE WITH MICROPHONE. (NO DMR)
Evax200r8zm120	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-2, 120V
Hs24-1575pwr	
Fnaccg	
Alg-V	
Fnp-1127d-C	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, NOT EXPANDABLE, CHARCOAL
Chq-Dim(Sci) Obsolete , Successor Is Chq-Dim2(Sci)	
Frcma	
Fnlcdnus00g024	NETWORK ANNUNCIATOR (GRAY) W/MANUAL

Alk-E (Wht) - Not Available, Similar Product Rm 3.3	
Fnv-Dfp-2	
Mx-Llc	
Evax-100e	
Dimm	
Sts-2.5	
Hec24-15wr	
Slr-24v+ns6-220	DET SMK SLR-24V+NS6-220 W/BASE 60PCS SET
Hes3-24wr	
Hcc24cw	
Ssc25-3075110r	
Ms-Rh/Ka/P/R	
Asb	
Fn-4127-Ny-R	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 4 LOOP, WITH PLEXIGLASS WINDOW, NYC LOCK, RED
Hrm-204	
SI24c-177r	
Evax-50/16z	EVAX 50 PANEL WITH 16 SPEAKER ZONES, GRAY
Mx-Mbi	
Evx-Byc-H	
Evax-150/12z	EVAX 150 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Evax-100r/4z	EVAX 100 PANEL WITH 4 SPEAKER ZONES, RED CABINET
Fnm-2127-C	FIRENET MARINE PANEL, 2-LOOP, GRAY
Evax50/2za	EVAX 50 PANEL WITH 2 CLASS A SPEAKER ZONES, GRAY CABINET
Nstp-15a	
Sts-10	
Evax-50r/16z	EVAX 50 PANEL WITH 16 SPEAKER ZONES. RED CABINET
Atj-En(Wht)	
Hsc-221I	
Rms-L&Amp;P-Nyc	

Slv-24	
Hes24-15wr	
Hes24-1575pwr	
Slv-24m	
Hes24-177wr	
Fnp-1127-Enc-R	
Gusr2001	
Tch-B100 - (By Tch-B200)	
Ns6-220m	
Acb-Ew	
Heh24-R	
Sbc-2rw	
Ns6-221	
Fn-4127-Ddwn-R	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, RED
Dh24120gc1	
Evax-25emr	25 WATT EXPANDER PANEL WITH MICROPHONE, WITHOUT DMR, RED
Slr-835w+ns6-220	DET SMK SLR-835W +NS6-220W W/BASE 60PCS SET
Mx-Ri	
Slr-835b-2	
Slr-835b-2w	
Fnm-2127-R	FIRENET MARINE PANEL, 2-LOOP, RED
Hes24-30wr	
Evx-IL8-H	
Fn-Ps776	
64460045	
Hmx-Dp200-42	42 X
Evax200c16zm120	200 WATT VOICE EVAC. PANEL W/DMR, MIC, 16 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Atg-Ea	
Fnlcdnus00r024	NETWORK ANNUNCIATOR (RED) W/MANUAL

Alg-En Repalced By (B02002-00 Aln-En)	
Dcd-1e-Is	
Evax-100r/16z	EVAX 100 PANEL WITH 16 SPEAKER ZONES, RED CABINET
Fnv-M-Bbr	
Fh-45r-703s	
Fn-S-Dd	
Fnp1127us20gs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, NOT EXPANDABLE, GRAY
Evax-50r/4z	EVAX 50 WITH 4 SPEAKER ZONES. RED CABINET
Evax-25/8z	EVAX-25 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Fn-Lcd-S-C	
Fnpetrg	
Evax-150e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Hes24-15ww	
Alk-E (Hfp) - Aln-En	
Fnp1127us00gs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, GRAY
Sra-24	
Tse-P100	
Fnm-Lcd-S-R	
Hec24-60ww	
Hcs24cr	
Hec24-15pwr	
Fh-47r-70r	
Rxb-1r	
Sfh47-153075r-25r	
Tzc-Usb	
Slr-24v	
Sfh45-153075r-25r	
Evax-150/16z	EVAX 150 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Hsb-Nsa-6	
Fn-Etr-R	

Chq-Wsb	
R2ml-I	
4bx-3r	
Sci-B6	
Evax150c12zm120	150 WATT VOICE EVAC. PANEL W/DMR, MIC, 12 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Fn-600ulx-R	
Fnm-Lcd-S-C	
Fnlcdnt-R	
Fnv-Nys	
Tsc-A100/Holder	
Sbc-4/12	
Fnp-1127-Mp	
Fnm-R2ml	
Evax-200/8z	EVAX 200 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Ca2z	
Fnm-Nsa-6	
Hec24-110ww	
Fnv-Brk	
Evax-50emr	50 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Hec3-24wr	
Hsb-Nsa-6(Blk)	
Fn-1042-Ulada-G	
Hec24-177ww	
Dfe-190	
Evax-100emr	100 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Hec24-75pwr	
Ashh-24smr-70	
Fn-Lcd-Nyn-R	NETWORK ANNUNCIATOR (RED) (W/O RESET CAPABILITY)

B02220-00	
Evax200r16zm120	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 16 CLASS B SPKR CKT, RED CAB-2, 120V
Slr-835bh-4	
Evax-50r/8z	EVAX 50 WITH 8 SPEAKER ZONES. RED CABINET
B05401-00	
SI-1224wp-R	
Fnm-Alk-V	
Fnv-Dp100/P	DISTRIBUTED PANEL, DUAL CHANNEL, 100W, FIRE PHONE
Evax-150r/16z	EVAX 150 PANEL WITH 16 SPEAKER ZONES, RED CABINET
Ms-Ra/P/R	
Pe-10sn(110v)	
Fnv-Dp100rp42120	42 X 26
Wcp1a-Ra470sf-H029-01 - Is Ccp-W	
Fnp-Key-S	
Fn-Acc-C	
Hp-25tr	
Fnv-Evx-Dr-2r	
Fn-1024ulx-C	
Fn-2127-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) (220V) W/ MANUAL (JUMPER
Fnv-Mfi	
Hps-Sak-Ex/Wp	
Dcp-Dimm	
Evax-200e	TEMPORAL PATTERN, POWER SUPPLY AND BATTERY
Slk-24f	
Acc-V	
Sbx-1	
Solo100	
Mx-Mfa	
Fnp-1127e-R	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, RED

Sp4-Loc-Kit	
Sfh45-75110r-70s	
Evax-200er	200 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Sza-Na(Fm)	HIGH SENSITIVITY SMOKE DETECTION SYSTEM
Fnv-M-Bb	
Fnv-Mp96/P	MASTER PANEL, 96 SWITCH / 48 INPUT, MASTER FIRE PHONE
Fnv-Dp100p-42	DISTRIBUTED PANEL, DUAL CHANNEL, 100W, 16 AUDIO, 4 FP CKTS, CAB 26 X 42 X 6
Fn-Lcd-S-R	
Alb-Ea	
Tcf-142-M-St	
Fnv-Mp16	MASTER PANEL, 16 SWITCH / INPUT
Fnv-Dp200r42120	42 X
Hca-8/120v	
Evax-200/16z	EVAX 200 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Fnv-Dps100-42	42 X26 X 6 CABINET
Fn2127us0egd120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW, GRAY
Chq-Drc(Sci)	
Hes24-1575pww	
Fnv-50e	50 WATT EXPANDER MODULE (NO MICROPHONE, NO DMR)
Solo461complete	SOLO 461 (1) 460 HEAT TESTER, (1) 725 CHARGER, (2) 720 BATTERY
Hs24-30ww	
Fn-Lcd-N-R	NETWORK ANNUNCIATOR (RED) W/MANUAL
Evax-50er	50 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Fnlcdst-R	
Sl-1224wp-W	
Fnv-Dfp-1	
Heh12-Wr	
Hec24-1575wr	
Ms-Ka/R	

Battery 12v; 12ah	
Smp-101	
Dcp-Ams-Kl	
Ns6-224	
Hps-Sak-Psk	
Sbc-2w	
Hsgm-1004	
Ybn-Nsa-4	
Fnv-Ev-Ss-30	
Heh24-Pr	
Hs24-15ww	
Fn2127us0erd120	ANALOG ADDRESSABLE FIRE CONTROL PANEL, 2 LOOP, WITH PLEXIGLASS WINDOW , RED
Hps-Sah-Wp	
Ev-Dmr-H	
Fnp-1127-R	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, RED
Fn-2127n	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) W/NETWORK CARD W/MANUAL, RED
Smokesabre	
Ssc70-3075110r	
Fnv-Dps100	DISTRIBUTED PANEL, SINGLE CHANNEL, 100W
Sl24c-177w	
Pfc-4410rc-Pcb	
Hcp-W(Sci)	
Hec24-15pww	
Hes24-60ww	
Rsb24-153075r	
Fn2127u	
Fnv-Ev-Ss-110	
Fnlcdst-G	
Led Indicator For Slr-E3n	

Evax-150er	150 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Hsc-220I	
Hec24-30pwr	
Mba-8-12	
Hd7033	
Dcd-1e - Is Dcd-Ae3	
Hcs24cw	
Fnm-Nsa-4	
Fnv-Mp32/P	MASTER PANEL, 32 SWITCH / 16 INPUT, MASTER FIRE PHONE
Pam-4	
Hec24-1575ww	
Fn-BIj	
Hps-Dah/S	
Fn-Lcd-N-Cpa-Bo	
Gus1-4	FIRENET GRAPHIX SOFTWARE PACKAGE- 1 TO 4 NODES
Fnv-Ev-Spkr-4	
B02472-00	
Sh24w-153075r	
Spc-24	
Y Bf-RI/4h3h , By Ybf-RI/4h5	
Fn-Prc	
Ms-Ra/P	
Evx-Sc	
Hs24-75ww	
Ashx-24smr-25	EXPLOSION-PROOF (CLASS I, DIV. 1, GROUPSB, C, D) SPEAKER AMPLIFIER 24VDC, 25
Ssc8-3075110w	
Chq-Dim2(Sci)	
Hes24-60pww	
B05406-00	
Dh24120sb	

Sfh47-75110r-70r	
Hps-Sah	
B02431-00	
Sfh47-75110r-25s	
Fn-300ulx-B	
Fn-642-Ulada-C	
Shb24-75cr	
Fn-4127	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/MANUAL, RED
Heh24-Ww	
Sgp-R	
Hes24-75pwr	
Scm-24c-177r	
Fnp-1127e-C	ANALOG ADDRESSABLE 1 LOOP NO DIALER, EXPANDABLE, CHARCOAL
Dcd-135	
Spb-24	
Hp-24r	
Evax200c8zm120	200 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-2, 120V
Fn-Enc-Bc-R	
Hes3-12pww	
H24wr	
Fnv-Aor	
Dh-98hvi	
Fn-Acc-R	
Hec3-12ww	
Hocfrcma	
Fnv-Slc	
Fnp-1127-Slc	
Alg-En (Wht)	
Fnv-Ev-Ssynch	

Hsc-4r/12w	
Frcme-S	
Hs24-30pww	
Czm	
Hsc-221r	
Evax-300er	300 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Alh-E (Wht)	
Evax-200/12z	EVAX 200 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Evax-25r	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BAT
Ssc8-177r	
Evax-100er	100 WATT EXPANDER PANEL W/O DMR OR MIC RED CABINET
Hcc24cr	
Fnp-1127de-R	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, EXPANDABLE, RED
Sp40s-B	
Fnv-Ev-Ss-75	
Asbl	
Hdm-204	
Evax100r4zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, RED CAB-1, 120V
Ns4-224	
Ap-15tuc	
Frcme-4	
Fn-400ulx-C	
Evx-Rmr	
Fn-Lcd-N-Bb-R	
Evax-100/12z	EVAX 100 PANEL WITH 12 SPEAKER ZONES, GRAY CABINET
Ashp-24smr-25	
Fnv-Fsf	
Fnv-25em	25 WATT EXPANDER MODULE WITH MICROPHONE. (NO DMR)
Sh-1224r	

Pfc-4410-Rc	4 ZONE AGENT OR WATER RELEASING PANEL, 4 INPUTS, 4 OUTPUTS, 1 SUPERVISORY, WHIT
Fn-Cb-Dd	
Fnv-Ev-Str-75	
Hec24-60wr	
Fh-45r-253r	
Pba-8	
Fnp1127us2egs120	ANALOG ADDRESSABLE 1 LOOP W/ INTEGRATED DIALER, EXPANDABLE, GRAY
Fn-2127	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS), RED
Hcp-204	
Hs24-30wr	
Fnv-Tc	
Fnv-Mp64/P	MASTER PANEL, 64 SWITCH / 32 INPUT, MASTER FIRE PHONE
Evax-100/16z	EVAX 100 PANEL WITH 16 SPEAKER ZONES, GRAY CABINET
Fnv-Dp25/P	DISTRIBUTED PANEL, DUAL CHANNEL, 25W, FIRE PHONE
Dcp-Som	
R2m-L	
Evax-50em	50 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, GRAY CABINET
D262	
Gus17-32	FIRENET GRAPHIX SOFTWARE PACKAGE- 17 TO 32 NODES
Bbx-1	
Fnv-Ii	
Evax25c4zm120	25 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evax-150/8z	EVAX 150 PANEL WITH 8 SPEAKER ZONES, GRAY CABINET
Hcp-1008e	8 ZONE DIP SWITCH FIRE ALARM CONTROL PANEL, 110V/220V
Acc-En(Wht)	
Fn-2127-Ddwn-C	ANALOG/ ADDRESSABLE FIRE CONTROL PANEL (2 LOOP/4AMP PS) WITH PLEXIGLASS WINDOW, W/NETWORK CARD, CHAR
Hec24-110pwr	

Fnlctnus00r024	NETWORK ANNUNCIATOR W/TRIM RING (RED)
Fnv-Mp96	MASTER PANEL, 96 SWITCH / INPUT
Evax-T17528	
Chq-Cp(Pcb)	
Nstt-C	
Fh-45r-703r	
Hech-1048	
Fnv-Evx-Cab-2	
Hec24-60pww	
Dfe-135	
Frcme-M	
Evax-500er	500 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
SI24w-153075r	
Fnv-Mfp	
Dcd-1e-1s	
Fnv-Pwr2a	
Gusr2008	5-8 WORKSTATIONS (8 REPEATER PACKAGE)
Chqdsc/ Oem(Sci	
Evax-50	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER. S
Hes3-24ww	
Evax-150emr	150 WATT EXPANDER PANEL W/ MICROPHONE, W/O DMR, RED CABINET
Fn-4127c	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) W/MANUAL, CHARCOAL
Hs24-110ww	
Sh24w-153075w	
Fnv-25	25 WATT VOICE EVACUATION MODULE WITH MICROPHONE
Evax-150r/8z	EVAX 150 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Nstp-15	
Hb-40	

Acae/ Wht/	
Fnlcdnt-G	
Slr-835bh-4w	
Fn-400ulx-G	
Hca-8d/120v	
X187	
Fnv-M-Cab-R	
Evax100c4zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 4 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evax-100	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Evax100c8zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, CHARCOAL CAB-1, 120V
Evx-Zab	
Pe-6sn	
Banshee Exel Lite	
Evax-100r/8z	EVAX 100 PANEL WITH 8 SPEAKER ZONES, RED CABINET
Testmagnet	
Fnv-Mp80	MASTER PANEL, 80 SWITCH / INPUT
Hps-Sah-Psk	
Chq-Sim	
Evax-400er	400 WATT EXPANDER PANEL W/O DMR OR MICROPHONE, RED CABINET
Mba-8	
Dh-98p	
Heh12-W	
SI24c-3075110w	
Sbc-4/24	
Hps-Cp	
Ybn-Nsa-4(Blk)	
Ssc25-177r	
Fnv-Ev-Cms-4	

Fnv-Asc	
Hx93-W	
Fnv-Xo	
Evax-200	INCLUDES DMR, TEMPORAL PATTERN, POWER SUPPLY AND BATTERY CHARGER.
Fn-Key	
Hps-Sak211key	
En54 Hpf Ap-2	
Fnv-Ev-Ss-15	
Hes24-1575wr	
Hps-Dak211key	
Sfh45-75110r-25s	
Hs24-110pwr	
Hs24-15pwr	
Hp-26r	
Pfc-4410rc-Ps	
Hec3-12pww	
Fnv-Ami	
Ybf-RI/4h5	
Fnp1127us00rs120	ANALOG ADDRESSABLE 1 LOOP NO DIALER, NOT EXPANDABLE, RED
Evx-Zm-H	
4bx-1	
Evax-500e	100 WATT AMPLIFIERS/SPEAKER CIRCUITS), GRAY CABIN
Fnv-Mp48	MASTER PANEL, 48 SWITCH / INPUT
Fn-1024ulx-R	
Dh24120fc	
Ashh-24smr-25	
Ashp-Acsmr-70	
Fnp-1127d-R	ANALOG ADDRESSABLE 1 LOOP W/INTEGRATED DIALER, NOT EXPANDABLE, RED
Hes24-75pww	

Ns4-220m	
Hes24-110wr	
Evax25r/4za	EVAX-25 PANEL WITH 4 CLASS A SPEAKER ZONES, RED CABINET
Fnv-Evx-Bb-2r	
Fn-4127c-220v	ANALOG /ADDRESSABLE FIRE CONTROL PANEL (4 LOOP/4AMP PS) (220V) CHARCOAL GREY W/M
SI24c-3075110r	
Scm-24c-3075110w	
Dh-98ar	
Chq-Mrci(Hfp)-Sci - Not Available, Similar Model Chq-Mrc2(Sci)	
Fn-4127-Nic	
Evax100r8zm120	100 WATT VOICE EVACUATION PANEL W/DMR, MIC, 8 CLASS B SPKR CKT, RED CAB-1, 120V
Hs24-110pww	
Sbc-4/12w	
Evax-50r/12z	EVAX 50 PANEL WITH 12 SPEAKER ZONES. RED CABINET
Fn-842-Ulada-G	
Ssc70-177r	
Fnv-Dp50	DISTRIBUTED PANEL, DUAL CHANNEL, 50W
Evax-T2885	
Fnv-Mp64	MASTER PANEL, 64 SWITCH / INPUT
Evx-Rm	
Scm-24w-153075r	
Shb120-75cr	
Fnv-Mp32	MASTER PANEL, 32 SWITCH / INPUT
Fnv-M-Cab	
Evx-Mic-H	
Fnv-Evx-Cab-2r	
Hmx-Dp200p-42	100 WATT AMPLIFIERS), 4 FIRE
Evax-200r	EVAX 200 PANEL. RED CABINET

[Spb-160-B](#)

[Ae2](#)

[Scm-24c-3075110r](#)