

Igel

Garanti: 12 ay
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in **info@yursat.com.tr** e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.
Igel Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

Firmamız Igel T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.



¼r¼n	A¼ıklama
Tse 31-400	POWER SUPPLY
Isa-D 72-600	CONTACTOR
Isa-D 105-500	CONTACTOR
Isa-D 580-500	CONTACTOR
Isa-D 580-1000	CONTACTOR
Tse 31-500	POWER SUPPLY
Isa-D 390-690	CONTACTOR
Isa-D 170-400	CONTACTOR
Isa-SI2 960-600	CONTACTOR
Tse 310-400	POWER SUPPLY
Isa-SI2 105-600	CONTACTOR
Isa-D 210-1000	CONTACTOR

Isa-D 145-690	CONTACTOR
Isa-D 1100-400	CONTACTOR
Tse 72-400	POWER SUPPLY
Isa-SI2 170-600	CONTACTOR
Isa-D 58-690	CONTACTOR
Isa-D 85-600	CONTACTOR
Isa-SI2 690-480	CONTACTOR
Isa-D 170-600	CONTACTOR
Isa-SI2 960-480	CONTACTOR
Imb 390-690	BRAKE
Isa-SI2 230-480	CONTACTOR
Isa-D 31-500	CONTACTOR
Isa-D 44-400	CONTACTOR
Tse 145-500	POWER SUPPLY
IgeI5/4	DRIVE MODULE INPUT +12VDC 4A 50W
Tse 85-500	POWER SUPPLY
Isa-SI2 690-600	CONTACTOR
Imb 210-690	BRAKE
Tse 8-500	POWER SUPPLY
Isa-D 390-500	CONTACTOR
Tse 460-600	POWER SUPPLY
Isa-D 105-1000	CONTACTOR
Isa-SI3 515-480	CONTACTOR
Tse 210-500	POWER SUPPLY
Isa-D 44-500	CONTACTOR
Imb 390-500	BRAKE
Isa-D 105-690	CONTACTOR
Imb 105-690	BRAKE
Isa-SI3 230-690	CONTACTOR
Tse 72-500	POWER SUPPLY

Isa-D 310-500	CONTACTOR
Isa-SI3 145-600	CONTACTOR
Isa-SI2 145-480	CONTACTOR
Isa-D 310-690	CONTACTOR
Isa-SI2 350-480	CONTACTOR
Isa-SI3 170-600	CONTACTOR
Tse 58-690	POWER SUPPLY
Isa-SI3 105-600	CONTACTOR
Isa-SI3 590-600	CONTACTOR
Tse 820-690	POWER SUPPLY
Isa-SI3 230-480	CONTACTOR
Isa-D 460-600	CONTACTOR
Isa-D 105-600	CONTACTOR
Isa-SI2 145-600	CONTACTOR
Tse 460-400	POWER SUPPLY
Isa-A 85-220	CONTACTOR
Isa-D 1100-690	CONTACTOR
Isa-D 310-1200	CONTACTOR
Imb 390-600	BRAKE
Isa-D 72-400	CONTACTOR
Isa-D 1400-500	CONTACTOR
Tse 390-400	POWER SUPPLY
Isa-SI3 1100-480	CONTACTOR
Isa-D 460-500	CONTACTOR
Isa-D 85-690	CONTACTOR
Tse 105-690	POWER SUPPLY
Tse 820-400	POWER SUPPLY
Isa-D 460-1200	CONTACTOR
Isa-D 145-400	CONTACTOR
Tse 460-690	POWER SUPPLY
Isa-D 950-600	CONTACTOR

Isa-D 210-1200	CONTACTOR
Isa-SI3 590-690	CONTACTOR
Isa-SI3 690-690	CONTACTOR
Isa-SI3 85-480	CONTACTOR
Tse 31-600	POWER SUPPLY
Isa-D 145-600	CONTACTOR
Tse 17-690	POWER SUPPLY
Isa-SI3 960-480	CONTACTOR
Tse 390-500	POWER SUPPLY
Isa-D 85-500	CONTACTOR
Isa-D 170-1000	CONTACTOR
Tse 8-690	POWER SUPPLY
Isa-SI3 690-480	CONTACTOR
Tse 145-690	POWER SUPPLY
Tse 580-500	POWER SUPPLY
Isa-A 170-600	CONTACTOR
Isa-SI3 145-480	CONTACTOR
Isa-SI3 720-600	CONTACTOR
Tse 170-500	POWER SUPPLY
Isa-SI3 1100-600	CONTACTOR
Isa-A 145-600	CONTACTOR
Isa-SI2 430-480	CONTACTOR
Tse 85-690	POWER SUPPLY
Tse 85-400	POWER SUPPLY
Isa-A 145-400	CONTACTOR
Tse 580-400	POWER SUPPLY
Tse 105-400	POWER SUPPLY
Tse 145-600	POWER SUPPLY
Isa-D 17-500	CONTACTOR
Tse 390-600	POWER SUPPLY

Isa-D 31-690	CONTACTOR
Tse 72-690	POWER SUPPLY
Isa-A 145-500	CONTACTOR
Isa-SI3 170-480	CONTACTOR
Isa-SI2 850-690	CONTACTOR
Isa-D 58-600	CONTACTOR
Tse 44-600	POWER SUPPLY
Isa-D 1400-600	CONTACTOR
Tse 85-600	POWER SUPPLY
Isa-SI2 310-690	CONTACTOR
Tse 170-690	POWER SUPPLY
Tse 580-690	POWER SUPPLY
Isa-SI2 430-600	CONTACTOR
Isa-SI3 430-480	CONTACTOR
Tse 170-400	POWER SUPPLY
Isa-D 460-400	CONTACTOR
Isa-SI3 590-480	CONTACTOR
Tse 31-690	POWER SUPPLY
Isa-D 820-500	CONTACTOR
Isa-D 72-690	CONTACTOR
Isa-SI2 515-480	CONTACTOR
Isa-A 170-500	CONTACTOR
Tse 105-500	POWER SUPPLY
Tse 390-690	POWER SUPPLY
Isa-D 390-600	CONTACTOR
Imb 210-400	BRAKE
Isa-SI3 690-600	CONTACTOR
Isa-D 1400-400	CONTACTOR
Isa-D 460-1000	CONTACTOR
Isa-SI2 690-690	CONTACTOR

Isa-SI2 590-690	CONTACTOR
Tse 58-400	POWER SUPPLY
Isa-D 1100-600	CONTACTOR
Isa-SI3 960-600	CONTACTOR
Isa-D 31-600	CONTACTOR
Tse 310-600	POWER SUPPLY
Imb 310-400	BRAKE
Tse 820-600	POWER SUPPLY
Isa-D 950-400	CONTACTOR
Isa-SI2 1100-690	CONTACTOR
Isa-SI2 230-690	CONTACTOR
Isa-D 170-690	CONTACTOR
Tse 44-500	POWER SUPPLY
Isa-A 85-600	CONTACTOR
Isa-D 950-690	CONTACTOR
Isa-D 820-600	CONTACTOR
Isa-A 85-500	CONTACTOR
Isa-D 85-400	CONTACTOR
Isa-SI2 350-690	CONTACTOR
Tse 17-600	POWER SUPPLY
Isa-D 1400-690	CONTACTOR
Tse 17-500	POWER SUPPLY
Isa-SI3 350-480	CONTACTOR
Isa-SI2 1100-600	CONTACTOR
Isa-SI3 310-600	CONTACTOR
Tse 310-500	POWER SUPPLY
Isa-SI3 960-690	CONTACTOR
Isa-A 105-600	CONTACTOR
Isa-D 820-690	CONTACTOR
Isa-A 145-220	CONTACTOR
Tse 170-600	POWER SUPPLY

Imb 390-400	BRAKE
Isa-SI3 430-600	CONTACTOR
Isa-D 58-500	CONTACTOR
Isa-D 8-500	CONTACTOR
Isa-SI2 720-480	CONTACTOR
Isa-D 31-400	CONTACTOR
Isa-SI3 850-600	CONTACTOR
Isa-D 460-690	CONTACTOR
Isa-SI2 590-480	CONTACTOR
Imb 310-690	BRAKE
Tse 8-600	POWER SUPPLY
Isa-D 950-500	CONTACTOR
Isa-SI3 350-600	CONTACTOR
Imb 210-600	BRAKE
Isa-A 85-400	CONTACTOR
Isa-D 820-400	CONTACTOR
Imb 310-600	BRAKE
Isa-D 310-1000	CONTACTOR
Imb 460-400	BRAKE
Tse 72-600	POWER SUPPLY
Isa-SI3 850-480	CONTACTOR
Isa-A 72-500	CONTACTOR
Isa-SI3 430-690	CONTACTOR
Isa-D 145-500	CONTACTOR
Tse 210-600	POWER SUPPLY
Isa-SI3 720-480	CONTACTOR
Isa-D 105-400	CONTACTOR
Isa-D 170-1200	CONTACTOR
Isa-SI2 515-600	CONTACTOR
Imb 310-500	BRAKE

Isa-D 210-690	CONTACTOR
Isa-SI3 720-690	CONTACTOR
Isa-A 105-500	CONTACTOR
Isa-SI2 960-690	CONTACTOR
Isa-SI2 720-690	CONTACTOR
Isa-SI2 590-600	CONTACTOR
Imb 820-400	BRAKE
Isa-SI3 105-480	CONTACTOR
Isa-D 580-400	CONTACTOR
Isa-SI3 1100-690	CONTACTOR
Isa-A 105-400	CONTACTOR
Tse 210-690	POWER SUPPLY
Isa-A 170-400	CONTACTOR
Isa-SI2 720-600	CONTACTOR
Isa-SI3 310-690	CONTACTOR
Isa-SI3 310-480	CONTACTOR
Isa-SI3 850-690	CONTACTOR
Isa-SI3 515-690	CONTACTOR
Isa-SI2 170-480	CONTACTOR
Isa-SI2 850-480	CONTACTOR
Isa-D 1100-500	CONTACTOR
Tse 210-400	POWER SUPPLY
Isa-D 580-690	CONTACTOR
Isa-D 210-400	CONTACTOR
Isa-SI3 72-600	CONTACTOR
Isa-D 580-600	CONTACTOR
Isa-D 170-500	CONTACTOR
Tse 820-500	POWER SUPPLY
Isa-SI3 85-600	CONTACTOR
Tse 105-600	POWER SUPPLY
Tse 44-400	POWER SUPPLY

Tse 145-400	POWER SUPPLY
Isa-SI2 850-600	CONTACTOR
Tse 580-600	POWER SUPPLY
Isa-D 390-1200	CONTACTOR
Isa-SI2 310-480	CONTACTOR
Imb 105-600	BRAKE
Isa-SI3 350-690	CONTACTOR
Isa-A 105-220	CONTACTOR
Isa-SI2 350-600	CONTACTOR
Tse 310-690	POWER SUPPLY
Isa-D 210-600	CONTACTOR
Isa-D 8-600	CONTACTOR
Imb 210-500	BRAKE
Isa-D 310-400	CONTACTOR
Isa-D 17-690	CONTACTOR
Isa-D 820-1000	CONTACTOR
Isa-D 310-600	CONTACTOR
Tse 58-600	POWER SUPPLY
Isa-A 170-220	CONTACTOR
Isa-A 72-600	CONTACTOR
Isa-SI2 85-600	CONTACTOR
Isa-SI2 1100-480	CONTACTOR
Tse 44-690	POWER SUPPLY
Isa-SI3 230-600	CONTACTOR
Tse 460-500	POWER SUPPLY
Isa-D 390-400	CONTACTOR
Isa-D 210-500	CONTACTOR
Isa-SI2 310-600	CONTACTOR
Isa-SI2 515-690	CONTACTOR
Isa-D 390-1000	CONTACTOR

Isa-SI2 230-600	CONTACTOR
Isa-SI3 515-600	CONTACTOR
Isa-D 72-500	CONTACTOR
Isa-D 44-690	CONTACTOR
Isa-D 44-600	CONTACTOR
Isa-D 17-600	CONTACTOR
Isa-D 8-690	CONTACTOR
Isa-D 58-400	CONTACTOR