

## Matsushita

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Matsushita** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Matsushita T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



| ¼r¼n                        | A¼ıklama                                              |
|-----------------------------|-------------------------------------------------------|
| <a href="#">M9rc60gv4l</a>  | SERVO MOTOR AC GEARED 60W 4P 30MIN 25MF 100V          |
| <a href="#">Uzj261</a>      |                                                       |
| <a href="#">Anr1151</a>     |                                                       |
| <a href="#">Aigv5430012</a> | 10.4 TOUCH PANEL TFT LCD, SVGA, 24VDC, CE/UL          |
| <a href="#">Anr1182</a>     |                                                       |
| <a href="#">Mdddt5540</a>   | SERVO DRIVER MINAS A4 SERIES, 1/1.5KW, 1/3-PHASE 200V |
| <a href="#">Fpo-E16</a>     | Expansion Unit FPO-E16RS-A                            |
| <a href="#">Msm042a1e</a>   | SERVO MOTOR 3000R/MIN 2.5AMP 106V 200HZ 0.4KW         |
| <a href="#">Vf-6</a>        | DRIVE AC 3PH 460VAC 2HP TYPE 400                      |
| <a href="#">Fp2-Bp07</a>    | 7 Slot Base Plate                                     |
| <a href="#">AfpX-Efp0</a>   | Expansion Adapter Module                              |
| <a href="#">Afp15402ce</a>  | C-Net Adapter RS232C RS485 S2                         |

|                                           |                                                   |
|-------------------------------------------|---------------------------------------------------|
| <a href="#">Jw1fsn</a>                    |                                                   |
| <a href="#">M9rc90g4y</a>                 | SERVO MOTOR AC GEARED 90W 4P 7.5MF 200V 50HZ .95A |
| <a href="#">Fpo-Psa2</a>                  | Power Supply Unit                                 |
| <a href="#">5ps132dbb01</a>               |                                                   |
| <a href="#">Msda043a1a</a>                | SERVO DRIVE                                       |
| <a href="#">Msd011p1e</a>                 | SERVO AC DRIVE 100W                               |
| <a href="#">S2</a>                        |                                                   |
| <a href="#">Anr5132</a>                   |                                                   |
| <a href="#">Nf4eb-24-UI</a>               |                                                   |
| <a href="#">Fp10sh</a>                    | CPU Module                                        |
| <a href="#">Anma228</a>                   | IMAGE CHECKER A200                                |
| <a href="#">Afp3505ce</a>                 | NAiS FP3 Motherboard FP 3                         |
| <a href="#">Fp2-Y16r</a>                  | Output Unit AFP23103                              |
| <a href="#">Mqw70c1224emj</a>             |                                                   |
| <a href="#">Tb1bs/16290</a>               |                                                   |
| <a href="#">Fp2-Ad8x</a>                  | Analog Input Unit AFP2401                         |
| <a href="#">Am51610a53nat(Ex.Ah71507)</a> |                                                   |
| <a href="#">Fp0-C32t</a>                  | FP0 Control Unit AFP02543, FPO-C32T               |
| <a href="#">Mfda253a1a95</a>              | SERVO DRIVE                                       |
| <a href="#">Mfaoo3lc5ns</a>               | SERVO MOTOR 30W                                   |
| <a href="#">Uzl110</a>                    | PHOTOELECTRIC LASER SENSOR T                      |
| <a href="#">Mss011p1p</a>                 | POSITION DRIVER 100VAC 50/60                      |
| <a href="#">S1dxa2c-10s24c</a>            |                                                   |
| <a href="#">Anma218v2</a>                 | CONTROL MODULE VERSION 2 A218                     |
| <a href="#">Fp2-X64d2</a>                 | FP2 Input Unit AFP23067                           |
| <a href="#">Fpo-E8yp-A</a>                | Expansion Unit FPO-E8YP-A                         |
| <a href="#">Anr12151</a>                  | LM10 LASER 80-180MM, 12-240VDC POWER, IP67 HEAD   |
| <a href="#">Bfvce0154a</a>                | INVERTER VF-CE 3PHASE 5.5-4.4A 320-550VAC 1.5KW   |
| <a href="#">Mr3m100a1224vj</a>            |                                                   |
| <a href="#">Afp3638c</a>                  | MODULE                                            |

|                                                   |                                                    |
|---------------------------------------------------|----------------------------------------------------|
| <a href="#">S1dxa2c10s12v</a>                     |                                                    |
| <a href="#">Afp12313b</a>                         | Relay Control Unit FP1-C14                         |
| <a href="#">Fp2-Psa2</a>                          | FP2 Power Supply AFP2632                           |
| <a href="#">Dv47j075lfge</a>                      | MOTOR DRIVER PANADAC 1.2KVA 200VAC 50/60HZ         |
| <a href="#">Mfaoo6lc2nsa</a>                      | SERVO MOTOR 60W                                    |
| <a href="#">Fpo-C14</a>                           | Control Unit FPO-C14RS-A                           |
| <a href="#">Az8104cej</a>                         |                                                    |
| <a href="#">Fp2-Pp4</a>                           | FP2 POSITION UNIT, 4 AXIS MOTION UNIT              |
| <a href="#">Fp2-Psd2</a>                          | Power Unit AFP2634                                 |
| <a href="#">Meddt-7364p</a>                       | INDEX DRIVE THREE PHASE 200-230V                   |
| <a href="#">Jq1p-48</a>                           |                                                    |
| <a href="#">Pm4ha-H-Ac240j</a>                    |                                                    |
| <a href="#">Wv-1410</a>                           | CAMERA CCTV 120VAC 60HZ 9W VIDEO 1VP-P 75OHM       |
| <a href="#">Fp2-Bp12</a>                          | Backplane AFP25012                                 |
| <a href="#">Lm10-80-2</a>                         | MICRO LASER SENSOR                                 |
| <a href="#">Hc4-E-Hp</a>                          |                                                    |
| <a href="#">Uzf12015+uzfrp8</a>                   |                                                    |
| <a href="#">Fp2-Y64p</a>                          | FP2 Output Unit AFP23507                           |
| <a href="#">Az8112cej</a>                         |                                                    |
| <a href="#">Pm4hsh</a>                            |                                                    |
| <a href="#">Mmi125</a>                            |                                                    |
| <a href="#">Ap3147hch</a>                         |                                                    |
| <a href="#">Az5104j</a>                           |                                                    |
| <a href="#">Yc-001ub</a>                          | ROBOT INTERFACE BOX 120V 50/60HZ 1PH               |
| <a href="#">AfpX-E16r</a>                         | Expansion Module                                   |
| <a href="#">Anr12821</a>                          | 60-100 MM 4 UM 12-24VDC, IP67 HEAD                 |
| <a href="#">Adkb400bpfadh</a>                     | SERVO DRIVER AC 400WATT                            |
| <a href="#">Fp2-C1d</a>                           | FP2 CPU Unit AFP2212                               |
| <a href="#">Fp2-Ad8vi</a>                         | Analog Input Unit AFP2400L                         |
| <a href="#">Bkc3-125-9</a>                        | CIRCUIT BREAKER 3POLE 125AMP 200VAC 50/60HZ KC-225 |
| <a href="#">AfpXc60rj(Ex Fp-X-60r AfpX-C 60r)</a> |                                                    |

|                              |                                  |
|------------------------------|----------------------------------|
| <a href="#">Msd-A023a1a</a>  | SERVO DRIVE AC 200-230VAC 200W   |
| <a href="#">Az5106mfc921</a> |                                  |
| <a href="#">Fp2-Mw</a>       | FP2 Multi Wire Link Unit AFP2720 |