

## Micro Motion



Garanti: 12 ay  
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Micro Motion** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Micro Motion Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*

rn	Aıklama
<a href="#">3056555</a>	
<a href="#">MASS CORIOLIS FLOW METER.</a>	DENSITY:771(KG/M3)AT43C,LINE SIZE:6", CLASS150,FLOW RATE : (NOR/MAX):125,000/140,000(KG/H),PRESSURE:3BARG,TEMPERATURE:35~50 C,AMBIENT TEMP: -3.5~55 C ,MFR:MICROMOTION
<a href="#">F025S116CCBMEZZZ</a>	
<a href="#">1700r11afzgzz</a>	
<a href="#">162B0355</a>	HFVM11L729BAC3FJREZZZ Flow measurement, electronic Micro Motion Viscomaster Heavy Fuel Meter, 316L Stainless Steel HFVM Model: Heavy Fuel Viscosity Meter (HFVM) Viscomaster 1 Sensor Range And Performance: Viscosity accuracy $\pm 0.2$ cP (0-10 cP range) then $\pm 1\%$ of FS of calibrated range,, viscosity limit 20, 000 cP 1 Stem Length: S L Materials Of Wetted Parts: 316L Stainless, Diamond Like Carbon coated tines 729 Process Connection: 1 1/2-inch Cone Seat Compression fitting B Calibration Type: 2-inch schedule 40 boundary, (Viscosity limits = 200cSt (T piece), 1000cSt (782791 Flow Through A Transmitter Housing Option: Integral Aluminium Alloy C Output: Integral transmitter, Channel A=mA + HART, Channel B = mA output, Channel C = RS485 Modbus 3 Meter Type: No Display F Approvals: ATEX - Zone 1 IIC flameproof J Application Configuration: Line Viscosity ; [4mA = 0cSt, 20mA = 50cSt] R Calibration Range: 5 to 50cP (viscosity calibration only, no density calibration) E Language: English inst. manual and English config. manual Z Future Option 1: Reserved for future use Z Conduit Connections: Standard 1/2" NPT fittings (no adapters) Z Factory Options: Standard product

<a href="#">F200H544CCAZEZ1ZZ</a>	60T/H Max.
<a href="#">Mass flow meter-line size 4"</a>	FLUID:Final molasses, range:0-15TPH ,temperature:60 deg, process connection:flanged, power supply available at site:230 VAC 50 HZ, OUTPUT 4-20 Madc ,counter flanges included and nut bolt included. PUMP Capacity: 15m3/h
<a href="#">IFT9701R2M1B</a>	
<a href="#">R-SERIES CORIOLIS METER,</a>	1/4 INCH (DN6), 316L STAINLESS STEEL R025SB04NCAZEZZZZ
<a href="#">1700 FIELD AND INTEGRAL-MOUNT</a>	SINGLE VARIABLE FLOW TRANSMITTER 1700I12ABZEZZZ
<a href="#">R-SERIES CORIOLIS METER,</a>	1/2 INCH (DN15), 316L STAINLESS STEEL R050SB04NCAZEZZZZ
<a href="#">1700 FIELD AND INTEGRAL-MOUNT</a>	SINGLE VARIABLE FLOW TRANSMITTER 1700I12ABZEZZZ
<a href="#">1700I11ABZEZZZ</a>	
<a href="#">2500D3ABBMEZCZ</a>	
<a href="#">2700c12abfezzz</a>	9-WIRE REMOTE TRANSMITTER
<a href="#">2700r17bbmezzz</a>	FLOW TRANSMITTER 18-100DC 7W
<a href="#">F200s420cqfzezzz</a>	SENSOR
<a href="#">9739mvd63aaeazz</a>	CONTROLLER
<a href="#">Rft97121kn</a>	FLOW TRANSMITTER REMOTE 115VAC
<a href="#">Cmf300n357n2bmsz</a>	SENSOR
<a href="#">Cmf050m313nu</a>	MASS FLOW SENSOR 1/2INCH STD TEMP/PRESS ANSI150LB
<a href="#">Cmf050h523n3enez</a>	DRIVE
<a href="#">Puck</a>	ASSEMBLY-20000843
<a href="#">F100s128cqbczezaz</a>	F-SERIES METER F100S
<a href="#">1700r11abmezzz</a>	TRANSMITTER
<a href="#">Ds300-S157sc</a>	SENSOR MASS FLOW
<a href="#">2700r12bbaezzzpk</a>	TRANSMITTER
<a href="#">Cmf300m425nqbuezzz</a>	CORIOLIS METER SENSOR
<a href="#">3700a1a05daeezz</a>	FLOW TRANSMITTER CORIOLIS 85-265VAC
<a href="#">Cmf300h551nrauezzz</a>	CORIOLIS FLOW METER 3INCH NICKEL ALLOY C22 STD TEM
<a href="#">2700r11cbaszzz</a>	TRANSMITTER
<a href="#">Cmf400m999nmaueazx</a>	MASS FLOW SENSOR
<a href="#">Cmf100m330naeiezzr</a>	MASS FLOW SENSOR 17.3V 160MA INPUT
<a href="#">Cmf200h544pqbuez</a>	SENSOR
<a href="#">Ds300s156su</a>	FLOW METER 3INCH 316L SS STD TEMP/PRESS
<a href="#">F200s418scaaezzz</a>	MASS FLOW SENSOR TEMP RANGE -50-125 C
<a href="#">Dul-115-Aa</a>	MODEL D CONTROL
<a href="#">Rft9739e5eujez</a>	FLOW TRANSMIT
<a href="#">Cmf100m328nrave</a>	FLOW SENSOR

<a href="#">3600688</a>	REMOTE CORE PROCESSOR2003 17.3V 160MA T3A -4
<a href="#">DI100s223su</a>	MASS FLOW SENSOR 900PSIG 1INCH CORIOLIS STANDARD
<a href="#">F200s418ccaaezzzz</a>	SENSOR MASS FLOW STAINLESS STEEL
<a href="#">C.6a</a>	FLOW SENSOR 2000PSI
<a href="#">2700r11abuszzz</a>	TRANSMITTER
<a href="#">H100s138ncamszzz</a>	FLOW METER
<a href="#">D6s-Ss-Cajon/Npt</a>	FLOW SENSOR TUBE 2600PSIG -240-204C CONN 2600PSIG
<a href="#">9739mvd612aezzz</a>	TRANSMITTER
<a href="#">R050s113nqbaezzzz</a>	TRANSMITTER MASS FLOW ASSEMBLY 160MA 17.3V
<a href="#">1700r12afmezzz</a>	TRANSMITTER
<a href="#">9739mvd63ajezzz</a>	TRANSMITTER
<a href="#">Fms3-115-Rs-J</a>	FLOW MONITOR 115VAC 0.2AMP
<a href="#">Rft9712-1prc</a>	FLOW TRANSMITTER REMOTE
<a href="#">Ds150z142sb</a>	
<a href="#">Ds025s119su</a>	MASS FLOW SENSOR 1900PSIG
<a href="#">2700r11abfszzz</a>	TRANSMITTER
<a href="#">Ds150s141su</a>	FLOW METER
<a href="#">Rft9712-1pnc</a>	FLOW TRANSMITTER REMOTE 115VAC NEMA4X W/DISPRESET
<a href="#">Rft97121pn</a>	FLOW TRANSMITTER REMOTE
<a href="#">9739mvd61uaaezzx</a>	FLOW TRANSMITTER
<a href="#">2700r12bbaezzzz</a>	TRANSMITTER
<a href="#">2700i11eezezaz</a>	TRANSMITTER
<a href="#">3101la1frcg5st</a>	ULTRASONIC LEVEL TRANSMITTER, 1 TO 26 FT (0.3 TO 8 M) RANGE
<a href="#">F200s418cqbaezzzz</a>	FLOW METER 2INCH
<a href="#">3700a1a05daezaz</a>	TRANSMITTER
<a href="#">F025s319siauezzzz</a>	MASS FLOW SENSOR 1/2IN FEMALE NPT
<a href="#">Cmf025-H520maguezzz</a>	FLOW SENSOR CORIOLIS ELITE ALLOY C-22 190BAR
<a href="#">Dt100h130gu</a>	METER
<a href="#">Cmf025m319nrauezzz</a>	FLOW METER 2180 L/H 1/2IN-FEM. NPT 316L-SS
<a href="#">Cmf100h530nu</a>	SENSOR PRESSURE TEMPERATURE 9WIRE 1IN CONNECTOR
<a href="#">Rft9712-1knu</a>	REMOTE FLOW TRANSMITTER 115/230VAC
<a href="#">Cmf100m328nabmez</a>	SENSOR
<a href="#">Cmf025m-009-Nrhzfzzz</a>	FLOW SENSOR W/JUNCTION BOX AND CORE PROCESSOR
<a href="#">1700r13abuezzz</a>	TRANSMITTER
<a href="#">2700i11bbuezzz</a>	MULTIVARIABLE TRANSMITTER FIELD MOUNT

<a href="#">F200s352ccamezzz</a>	SENSOR
<a href="#">1700r12abzezzz</a>	FLOW TRANSMIT
<a href="#">Cmf200m419nqezez</a>	METER
<a href="#">2700-R11ecueزاز</a>	TRANSMITTER
<a href="#">0713605</a>	FLOW TRANSMITTER ELIT REMOTE FEILD-MOUNT 85-250VAC
<a href="#">1ft-9701r3n3u</a>	FLOW TRANSMITTER BASIS REMOTE 20-30VDC
<a href="#">000255119</a>	SENSOR
<a href="#">Ds040s113su</a>	MASS FLOW SENSOR -240 TO 177DEG C
<a href="#">2500d3abbmezzz</a>	PLC TRANSMITTER
<a href="#">D12s-Ss</a>	FLOW SENSOR FLUID FITTING NPTF .25 3000PSI
<a href="#">2700c11bbuezzz</a>	FLOW TRANSMITTER 85-265VAC 1/2NPT
<a href="#">2700r11bfzezzz</a>	TRANSMITTER
<a href="#">A1a03duezzz</a>	FLOW TRANSMITTER
<a href="#">Cmf200m418nrauez</a>	FLOW METER
<a href="#">1700i11aezezzz</a>	FLOW TRANSMIT
<a href="#">Cmf200m418nuaaezzz</a>	MASS FLOW SENSOR 2IN STD TEMP/PRESS ANSI150LB
<a href="#">S100s128</a>	FLOW METER
<a href="#">Cmf200m418nqbuez</a>	SENSOR
<a href="#">1700r12dbuezzz</a>	FLOW TRANSMITTER 1/2IN 11W 18-100VDC
<a href="#">Ds300-S155sc</a>	SENSOR MASS FLOW 3INCH SS
<a href="#">2700r13dbapzzz</a>	FLOW TRANSMITTER
<a href="#">2700r11dffezzz</a>	TRANSMITTER
<a href="#">Cmf-025m319nu</a>	SENSOR LIQUID FLOW 1/4INCH DIAMETER
<a href="#">Cmf100m329nqbzezzz</a>	1-INCH, 316L STAINLESS STEEL
<a href="#">DI200s227su</a>	MASS FLOW SENSOR 740PSIG 2INCH CORIOLIS SANITARY
<a href="#">Ds040s113</a>	MASS FLOW SENSOR -240 TO 177DEG C 1250PSI
<a href="#">F050s116crazezzz</a>	SENSOR
<a href="#">2700c11bbmszzz</a>	TRANSMITTER
<a href="#">1700m12abfpzczpk</a>	TRANSMITTER
<a href="#">3700a1a05duedzz</a>	TRANSMITTER
<a href="#">Ds150s218</a>	MASS FLOW METER
<a href="#">Fms3</a>	MONITOR
<a href="#">Cmf300m357nrauez</a>	SENSOR
<a href="#">F100s131crazezzz</a>	FLOW SENSOR
<a href="#">2700r12bbaexzx</a>	MASS FLOW TRANSMITTER
<a href="#">D-S300s156</a>	FLOW METER 740PSIG SS STD TEMP/PRESS

<a href="#">Rft9739-D4sma</a>	FLOW TRANSMITTER FEILD-MOUNT 85-250VAC W/DISPLAY
<a href="#">1700r12abaezcz</a>	FLOW TRANSMITTER 18-100VDC 4WIRE REMOTE MOUNT
<a href="#">To75tr613s1u</a>	FLOW SENSOR 3/4INCH STRAIGHT TUBE TITANIUM
<a href="#">3300p1a00b1uedzz</a>	CONTROLLER W/INTEGRATED TRANSMITTER 4-20MA
<a href="#">Cmf100m328nu</a>	MASS FLOW SENSOR 1450PSIG 1INCH CORIOLIS ELITE
<a href="#">R200s418ncaaezzzz</a>	MASS FLOW SENSOR R200S
<a href="#">1700c12abaszzz</a>	TRANSMITTER
<a href="#">L100s202</a>	FLOW SENSOR TUBE 900PSIG -40-120C CONN CLAMP FTG
<a href="#">3700a1a05daezzz</a>	CONTROLLER
<a href="#">Cmf010m323nu</a>	MASS FLOW SENSOR ELITE 425PSIG 1/10IN CORIOLIS
<a href="#">3700a1a03duezrz</a>	TRANSMITTER
<a href="#">1ft9701r3n3uezz</a>	FLOW SWITCH REMOTE TRANSMITTER 20-30VDC
<a href="#">7826adaaaclbba</a>	
<a href="#">Cmf300m356prauezzz</a>	CORIOLIS FLOW METER 3INCH 316L SS STD TEMP/PRESS
<a href="#">D100s-Ss</a>	MASS FLOW SENSOR 1IN FLANGED
<a href="#">2700i12ebaszcz</a>	TRANSMITTER
<a href="#">Cmf050m322nrauezzz</a>	MASS FLOW SENSOR
<a href="#">Ds040s113-1/2</a>	FLOW SENSOR
<a href="#">Cmf200h544nrauezzz</a>	SENSOR PRESSURE TEMPERATURE 9WIRE 2INCH CONNECTION
<a href="#">Cmf100h999n4baezzx-14317</a>	MASS FLOW SENSOR 1/2NPT STAND PRESSURE/TEMP ETO
<a href="#">1700r11abuezzz</a>	MASS FLOW TRANSMITTER ANALOG
<a href="#">Iftpoaac</a>	KIT
<a href="#">Cmf-100-M329nracezzz</a>	SENSOR MASS FLOW 1INCH
<a href="#">Cmf300m356nrauezzz</a>	CORIOLIS METER SENSOR 9WIRE CONNECTION
<a href="#">Cmf300m357n2bae3zz</a>	MASS FLOW SENSOR
<a href="#">D40s-Ss</a>	MASS FLOW SENSOR -240 TO 204DEG C
<a href="#">Cmf200-M352-Nrauezzz</a>	MASS FLOW SENSOR 2INCH SANITARY FITTING 316L SS
<a href="#">F100s138cqbmezzz</a>	SENSOR
<a href="#">9739mvd63ujezzz</a>	TRANSMITTER -45C TO 55C
<a href="#">Ds300-H203su</a>	PRESSURE SENSOR SYSTEM D-SERIES 3INCH
<a href="#">F200h544cqbmez1z</a>	SENSOR
<a href="#">Cmf300m355nrauezzz</a>	MASS FLOW SENSOR 3INCH STD TEMP/PRESS ANSI150LB
<a href="#">F050s113srauezzz</a>	FLOW METER
<a href="#">2700r11bbaezcz</a>	FLOW TRANSMITTER 85-265VAC 1/2NPT
<a href="#">9739mvd63maezcz</a>	TRANSMITTER REMOTE FLOW 18-30VDC 85-265VAC -30-55C

<a href="#">1700r11aefezzz</a>	TRANSMITTER
<a href="#">Cmf100m328n2basz</a>	SENSOR
<a href="#">Ds300-S-158-S-B-Ceq77751+ift9701-R-6-N-1wiz</a>	
<a href="#">Cmf300m356nqbzezzz</a>	316L STAINLESS STEEL
<a href="#">R100s128nqbaezzzz</a>	MASS FLOW TRANSMITTER
<a href="#">F200s419cqbaezzz</a>	FLOW METER
<a href="#">Ds065s113sb</a>	MASS FLOW SENSOR 0.65IN 2250PSI TUBE .5IN NPT FLNG
<a href="#">Rft9712-3kn</a>	FLOW TRANSMITTER REMOTE 115/230VAC
<a href="#">DI200s226</a>	MASS FLOW SENSOR 740PSIG 2INCH CORIOLIS SANITARY
<a href="#">1700c12abmezzz</a>	FLOW TRANSMIT
<a href="#">Cmf300h999nrauezzx</a>	MASS FLOW SENSOR
<a href="#">F050s113craeazzzz</a>	MASS FLOW TRANSMITTER
<a href="#">T075t-628-Sqbae-Zzzz</a>	METER MASS FLOW DENSITY 150LB SOCKET 720PSI
<a href="#">Cmf025m321nrauez</a>	SENSOR
<a href="#">1700i11abmszzz</a>	TRANSMITTER
<a href="#">Cmf025m315nqbamz</a>	SENSOR CMF025M 1/2INCH CL600 ASME 4WIRE
<a href="#">F100sr128su</a>	FLOW METER
<a href="#">9739mvd61uaezzz</a>	FLOW TRANSMITTER
<a href="#">F300h551crazezzzz</a>	3-INCH CL300 ASME B16.5 F304/F304L
<a href="#">Cmf200m352nu</a>	SENSOR
<a href="#">1700c12affezzz</a>	
<a href="#">3700a2a05azeznz</a>	CONTROLLER
<a href="#">3300p1a00b1aezzz</a>	MONITOR
<a href="#">Cmf200m352nqbuezz</a>	FLOW METER
<a href="#">F200h545crazezzzz</a>	2-INCH CL300 ASME B16.5 F304/F304L
<a href="#">2500d3abbaeazzz</a>	PLC TRANSMITTER MVD2500 DIN RAIL MOUNT 4WIRE
<a href="#">T622auzzzz</a>	STRAIGHT TUBE FULL-BORE CORIOLIS METER
<a href="#">100s-Hy</a>	FLOW SENSOR TUBE 2250PSI -240-204C CONN 230PSI
<a href="#">Dnoc0zezzz</a>	CONTROLLER
<a href="#">Rft-9739d4eua</a>	FLOW TRANSMITTER REMOTE FIELD-MOUNT 85-250VAC
<a href="#">2700i11admszzz</a>	TRANSMITTER
<a href="#">Cmf010m321nm</a>	MASS FLOW SENSOR
<a href="#">1700r11abcezzz</a>	MICROMOTION 1700 CORIOLIS MVD VARIABLE TRANSMITTER
<a href="#">2700c12bbaeazzz</a>	TRANSMITTER
<a href="#">Rft9739r</a>	LEVEL TRANS

<a href="#">2700r11bbaexzx9851a</a>	FLOW TRANSMITTER
<a href="#">1700c11abcezzz</a>	TRANSMITTER
<a href="#">Rft9739e4eff</a>	FLOW TRANSMITTER FIELD-MOUNT 85-205VAC NO DISPLAY
<a href="#">Cmf100m329n2baezrz</a>	MASS FLOW SENSOR 17.3V 160MA INPUT DUAL SEAL
<a href="#">R050s113n1azezzzz</a>	FLOW METER MASS R-SERIES 050 SIZE 316L STAINLESS
<a href="#">Ift9703ic6n3u</a>	FLOW METER 85-250VAC 3/4IN NPT
<a href="#">R200s418nqbaezzzz</a>	MASS FLOW SENSOR
<a href="#">F300s356ccacezzzz</a>	FLOW SENSOR W/TRANSMITTER 2700I11 BBCEZZZ
<a href="#">2700r12abfezzz</a>	POWER: 18 TO 100 VDC AND 85 TO 265 VAC
<a href="#">Dh006s100/Su</a>	MASS FLOW SENSOR TEMP RANGE -240DEG C-204DEG C
<a href="#">3700a1a03dzeznz</a>	TRANSMITTER
<a href="#">Ds040s113su-1/2</a>	FLOW SENSOR
<a href="#">Cfm010m323nu</a>	METER
<a href="#">Cmf010m321nraaezzz</a>	SENSOR ELITE METER 1/10INCH
<a href="#">2700r13dbaezzz</a>	FLOW TRANSMITTER
<a href="#">Cmf300m356naecez</a>	SENSOR
<a href="#">F200s418crauezzzz</a>	FLOW/DENSITY SENSOR 240-180C TEMP RANGE
<a href="#">7835baafd1c3a</a>	MODULE
<a href="#">Ift9703ic3n1wez</a>	FLOW TRANSMITTER 20-30VDC
<a href="#">2700i12abaezzz</a>	TRANSMITTER
<a href="#">3300p1a00b1aedzz</a>	BATCHER
<a href="#">Rft-9739-E1suj</a>	FLOW TRANSMITTER 100/115VAC
<a href="#">F300s356ccacezzzz/2700i</a>	FLOW SENSOR W/TRANSMITTER 1700I11 ABCE ZZZ
<a href="#">Rtf9739e5su</a>	TRANSMITTER
<a href="#">2700r12bbuezzz</a>	FLOW TRANSMITTER
<a href="#">Cmf-025n520nabaezzx</a>	MASS FLOW SENSOR 1/2INCH
<a href="#">1700c12abuezzz</a>	FLOW TRANSMITTER 1/2IN 11W 18-100VDC
<a href="#">Cmf025m313nc</a>	FLOW SENSOR 350PSIG -240-204DEG C
<a href="#">Cmf300h550nrauezzz</a>	CORIOLIS METER SENSOR 9WIRE CONNECTION
<a href="#">Startup1</a>	MANUAL
<a href="#">3350a2a00duedzz</a>	FLOW TRANSMITTER 18/30VDC
<a href="#">D150s936sb</a>	
<a href="#">2700r12bbaezcx</a>	MASS FLOW TRANSMITTER
<a href="#">F050s113cqbczezaz</a>	F-SERIES METER F050S
<a href="#">Enhcpassy</a>	CORE PROCESSOR ASSEMBLY ENHANCED
<a href="#">Cmf025m321n2baezzz</a>	FLOW SENSOR DUAL SEAL 17.3V 160MA

<a href="#">F100s128crauezzzz</a>	FLOW SENSOR 0.2
<a href="#">Ds300s156sm</a>	SENSOR
<a href="#">Cmf025m999pu</a>	FLOW SENSOR 1450PSI TEMP RANGE -240-204C
<a href="#">Cmf025m314nu</a>	SENSOR
<a href="#">Rft9739r1eus</a>	REMOTE FLOW TRANSMIT LCD 100/115VAC
<a href="#">T150t642scacezzzz</a>	FLOW SENSOR W/TRANSMITTER 2700I11 BBCEZZZ
<a href="#">Rft9739e4sua</a>	TRANSMITTER
<a href="#">3300pia00b1uezzz</a>	FLOW METER CONTROLLER MODEL 3300
<a href="#">R100ss128ncaasz</a>	MASS FLOW SENSOR 17.3V 160MA
<a href="#">Cmf200m419prauezzz</a>	COROLIS FLOW METER 2INCH 316L SS STD TEMP/PRESS
<a href="#">2700c12bbuezzz</a>	TRANSMITTER
<a href="#">Ift9703ic6n3uez</a>	FLOW TRANSMITTER 85-250VAC
<a href="#">F100h531crazezzzz</a>	1-INCH CL300 ASME B16.5 F304/F304L
<a href="#">1700r12abuezzz</a>	FLOW TRANSMITTER
<a href="#">Cmf200m419nqbzezzz</a>	2-INCH, 316L STAINLESS STEEL
<a href="#">Ds025h124</a>	FLOW SENSOR
<a href="#">Ds040h124</a>	FLOW SENSOR TUBE 1250PSIG -240-204C CONN 275PSIG
<a href="#">F300s425cqbaezzz</a>	METER
<a href="#">1700i11abaezzz</a>	TRANSMITTER MASS FLOW 85-265VAC 18-100VDC 7WATT
<a href="#">F100s128cqbaezzz</a>	SENSOR
<a href="#">Cmf050m313nrauezzz</a>	SENSOR PRESSURE TEMPERATURE 9WIRE .5INCH CONNECTOR
<a href="#">1700i11abmezzz</a>	TRANSMITTER
<a href="#">1700r11dbuezzz</a>	TRANSMITTER
<a href="#">Ift9701-R6n3u</a>	REMOTE FLOW TRANSMITTER 85-250VAC
<a href="#">1700c13abmezzz</a>	TRANSMITTER
<a href="#">Rmtcore9wirenn</a>	REMOTE CORE PROCESSOR2003 17.3V 160MA T3A -4
<a href="#">Ds300s155</a>	SENSOR FLOW METER 3IN -240-204DEG C 230PSIG
<a href="#">1700i-12abaezzz</a>	FLOW TRANSMITTER 1/2INCH NPT
<a href="#">3700a1b05dascnz</a>	TRANSMITTER
<a href="#">R025s113ncaaezzzz</a>	MASS FLOW SENSOR
<a href="#">2700c13bbmezzz</a>	TRANSMITTER
<a href="#">Cmf010m323nrauez</a>	CONTROLLER
<a href="#">Dn0c0zezzz</a>	COMPUTER
<a href="#">100sssa150</a>	FLOW SENSOR 1500PSI -240-204C CONN 230PSI
<a href="#">Cmf010p323nabuezzz</a>	MASS FLOW SENSOR 3005792



<a href="#">Ift970113n3u</a>	TRANSMITTER
<a href="#">Modldop3std</a>	MODULE
<a href="#">2700r11eezezaz</a>	TRANSMITTER
<a href="#">Cmf050m313nqbaezzz</a>	MASS FLOW SENSOR 0.5INCH ELITE
<a href="#">Rft9739d5sua</a>	FLOW ELITE REMOTE TRANSMITTER 85-250VAC
<a href="#">F200s420craaezzzz</a>	FLOW METER 2INCH
<a href="#">Cfm3000m356nrhze</a>	SENSOR
<a href="#">375uh60</a>	REDUCER 1750RPM 60:1RATIO
<a href="#">Cmf300m425nurft9739r2eus</a>	MASS FLOW METER
<a href="#">1700r11affszzz</a>	TRANSMITTER
<a href="#">Cmf100m328nrauezzz</a>	MASS FLOW SENSOR 1INCH STD TEMP/PRESS ANSI150LB
<a href="#">3700a2a04azezzz</a>	FLOW TRANSMITTER 18-30 VDC
<a href="#">Ds040s121-1/4</a>	SENSOR MASS FLOW
<a href="#">F025s113crjzezzzz</a>	FLOW METER F SERIES SIZE 025 316L STAINLESS STEEL
<a href="#">0713601</a>	FLOW TRANSMITTER ELIT REMOTE FEILD-MOUNT 85-250VAC
<a href="#">T100t628sqbaezzzz</a>	FLOW SENSOR
<a href="#">Cmf/100328nrauezzz</a>	METER SENSOR FLOW CORIOLIS 1IN 316L STAIN ST
<a href="#">Rft4739nodisplay</a>	CONTROL
<a href="#">Cmf025m-313nrauezzz</a>	FLOW METER 1/4-1/2IN STAINLESS STEEL
<a href="#">Fms1naoea</a>	MONITOR
<a href="#">1700i12abmezzz</a>	FLOW TRANSMITTER SINGLE FLOW VARIABLE CORIOLIS
<a href="#">Cmf200m419naecez</a>	SENSOR
<a href="#">Fms1naoe</a>	FLOW MONITOR FMS-3 100/115VAC
<a href="#">Cmf025m-321nabaezzz</a>	FLOW METER 1/4-1/2IN STAINLESS STEEL
<a href="#">2700r11bbuezzz</a>	FLOW TRANSMITTER
<a href="#">2700r13abaezzz</a>	FLOW TRANSMITTER
<a href="#">Cmf200m419nrauez</a>	SENSOR
<a href="#">Ds300-S161su</a>	MASS FLOWMETER 3IN
<a href="#">Rtf9739e4suj</a>	TRANSMITTER
<a href="#">Ds300s155su</a>	FLOW METER
<a href="#">Cmf-100m328nqbaezzx</a>	MASS FLOW SENSOR 1INCH
<a href="#">2700r11bffezzz</a>	TRANSMITTER
<a href="#">Rft9712ipdu</a>	MODULE
<a href="#">2700r11abuezzz</a>	FLOW TRANSMITTER
<a href="#">R200s420nvbnezzz</a>	SENSOR
<a href="#">3600734</a>	TRANSMITTER

<a href="#">3700a1a05duezbz</a>	FLOW TRANSMITTER
<a href="#">2700r12abaezzz</a>	FLOW TRANSMITTER 115V
<a href="#">F100a130crbaezzzz</a>	FLOW SENSOR 1INCH 316L
<a href="#">R100s128ncaaezzz</a>	SENSOR R100S
<a href="#">3700a1a05dzedzz</a>	FLOW TRANSMITTER FIELD MOUNT
<a href="#">Rft9739e5su</a>	TRANSMITTER
<a href="#">2700i13efzezaz</a>	EMERSON MICRO TRANSMITTER
<a href="#">1700r12afzezzz</a>	CORIOLIS MVD SINGLE VARIABLE FLOW TRANSMITTER
<a href="#">Ds100s128</a>	FLOW METER 2250PSIG FLUID -240-204DEG C 230PSIG
<a href="#">C-Af-UI-B</a>	REMOTE UNIT 100/115/220V 15WATT