

## Pixsys

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Pixsys** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Pixsys T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunulmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



¼r¼n	A¼ıklama
<a href="#">ATR227-11 ABC</a>	DATA SHEET Container 48x48 (front) x 90 mm Power supply 24..230V AC / DC ± 15% 50/60 Hz (galvanic isolation 2500V) Consumption 5.5VA Display Green display 4 digits 0.4 "+ red 4 digits 0.3" Environmental conditions Temperature 0-45 ° C, humidity 35..95 uR% (non condensing) Housing material: polycarbonate, Front: self-extinguishing ABS UL94V0 Weight Approx. 130 g Protection Front panel: IP54 (IP65 with gasket), Case and terminals: IP20 Quick configuration microUSB Memory Card, LabSoftView software, EASY-UP codes 6 + 6 extraction terminal blocks
<a href="#">ATR 244-12ABC</a>	TECHNICAL DATA SHEET Container 48 x 48 (front) x 105 mm Power supply 24..230 V AC / DC ± 15% 50/60 Hz - galvanic isolation 2,5KV Consumption 8 VA Display White display 4 digits 0.5 "+ red 4 digits 0.3" Environmental conditions Temperature 0-45 ° C, humidity 35..95 RH% Housing material: self-extinguishing UL94V2 PC, front: UL94V2 PC Weight Approx. 185 g Protection Front panel: IP65, Case and terminals: IP20 Quick configuration Memory Card, LABSOFTVIEW software, EASY-UP codes / Programming via APP (NFC) for Android devices

<a href="#">ATR 141-AD</a>
<a href="#">1300.20.099</a>
<a href="#">2000.35.014</a>
<a href="#">ATR 400</a>
<a href="#">ATR110-10B</a>
<a href="#">ATR121-AD</a>
<a href="#">ATR121-AT</a>
<a href="#">ATR170-2AB</a>
<a href="#">ATR226-12</a>
<a href="#">ATR313-1AD OEM!!</a>
<a href="#">ATR401-23ABC</a>
<a href="#">ATR401-24ABC</a>
<a href="#">ATR620</a>
<a href="#">ATR620-22ABC</a>
<a href="#">ATR621-14 ABC</a>
<a href="#">DRR245</a>
<a href="#">MCM260-*AD</a>
<a href="#">MCM260-3AD</a>
<a href="#">MCM260-5AD</a>
<a href="#">P-ATR121-B</a>
<a href="#">P-ATR243-20ABC</a>
<a href="#">PL250</a>
<a href="#">TCT100</a>
<a href="#">TCT101</a>
<a href="#">TCT101-1ABC</a>
<a href="#">atr243-31ABC</a>
<a href="#">Drr245-21abc-T</a>
<a href="#">Tct100 Obsolete, Alternativ Type Tct101</a>
<a href="#">Atr 313 Oem</a>
<a href="#">Tct101-3abc</a>
<a href="#">Atr131-1d</a>

<a href="#">Atr610</a>	
<a href="#">Atr131-3b</a>	
<a href="#">Type: PI250</a>	
<a href="#">Atr241-Ad</a>	
<a href="#">Tct101-2abc</a>	
<a href="#">Atr621</a>	
<a href="#">Atr226</a>	
<a href="#">Atr142-Abc</a>	
<a href="#">Atr227-12abc</a>	
<a href="#">Td240-11ad</a>	
<a href="#">Atr621-12abc</a>	1 Analogue input + 2 Relays 8 A + 1 SSR 12Vdc + 1 Digital input
<a href="#">2000.90.232</a>	
<a href="#">Certificat Ams2750e For Programmer Controller Atr621 Not Available</a>	
<a href="#">Atr121-A</a>	
<a href="#">Atr243-31abc-I</a>	
<a href="#">Atr131-1a</a>	
<a href="#">Atr121</a>	
<a href="#">Atr243-31abc</a>	
<a href="#">Atr243</a>	
<a href="#">PI250-11ad</a>	
<a href="#">Atr110-10b , Atr121-B</a>	
<a href="#">Atr227</a>	
<a href="#">Atr141-Adt</a>	
<a href="#">2000.35.013</a>	
<a href="#">Atr131-3a</a>	
<a href="#">Atr243-20abc</a>	
<a href="#">Atr243-21abc-T</a>	
<a href="#">Atr401-22abc-T</a>	
<a href="#">Tct101-4abc-T</a>	

[Atr142abc](#)

[Atr131-1b](#)

[Atr121c](#)

[Atr621-13abc-T](#)

[Atr227-11abc](#)

[Atr620-21abc](#)

[P-Atr121-Ad](#)

[Atr226-12 Abc](#)

[Atr621-14abc](#)