

## Pizzato

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Pizzato** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Pizzato T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



¼r¼n	A¼ıklama
<a href="#">Fd 535-2</a>	Position switch with swivel lever with adjustable roller 1NO + 1NC snap contact; IP67
<a href="#">Fd 541</a>	Bistable position switch with lever, one career 1NO + 1NC snap contact; IP67
<a href="#">Fd 2093-Ex7</a>	
<a href="#">400 Vac-3a\sol \ H14 Fd1-152823 \ Pizzato:FI 2083-</a>	
<a href="#">Fd 2083-M2t6</a>	Safety cable pull emergency switch with reset for emergency stop Metal case; 1NO + 2NC slow contact; IP67a, outgoing head left
<a href="#">FI 2084-M2t6</a>	Safety cable pull emergency switch with reset for emergency stop Metal case; 1NO + 2NC slow contact; IP67a, outgoing head right
<a href="#">AB24 D13 FR1-1000251 fr 1655 NC</a>	
<a href="#">FS 2096E024-F7M2</a>	1NO & 2NC Safety locking device, 24VAC / DC, with actuator VF KEYF7, fully insulated IP67, IMQ, c ULus, EAC, CCC, CE

<a href="#">Vfaf-1qigr03</a>
<a href="#">F12 Fs1 74396</a>
<a href="#">Nab112kp-Dn2</a>
<a href="#">Fr1651</a>
<a href="#">Fp931</a>
<a href="#">Fg 60 Pd1e0b</a>
<a href="#">Fs3096e024-F1</a>
<a href="#">Hcab</a>
<a href="#">El Ac27018</a>
<a href="#">Fr555-M2</a>
<a href="#">Fw2092m2</a>
<a href="#">Hpaa050f-Kam</a>
<a href="#">Cs At-22v024 Old Number, New Number</a> <a href="#">Cs At - 32 V024 Safety Relay</a>
<a href="#">Fr996</a>
<a href="#">C10 Fd1 21575</a>
<a href="#">Sm A01n</a>
<a href="#">Fd 1884 (Ex. Fd 684)</a>
<a href="#">Sma01n</a>
<a href="#">Fr3701-72</a>
<a href="#">Fg60-Cd1-D0c</a>
<a href="#">Fd979</a>
<a href="#">Vfkeyf3</a>
<a href="#">Fd 531 1m2</a>
<a href="#">B14fd1-129357 Fd 1878 Safety Switch</a>
<a href="#">Fr 515a</a>
<a href="#">Es 31000</a>
<a href="#">Head Tipe 96d</a>
<a href="#">Code 5 ,1no+1nc,</a>
<a href="#">Fr515a</a>
<a href="#">Fz515</a>

<a href="#">Fa4517-8dn</a>
<a href="#">Fd 631</a>
<a href="#">E13fr1-102671</a>
<a href="#">Fr693-D1k70</a>
<a href="#">Fr915</a>
<a href="#">Fk993-F</a>
<a href="#">Fr 569</a>
<a href="#">Fd2184</a>
<a href="#">Vfb501</a>
<a href="#">Fm515-M2</a>
<a href="#">Fr 631-R19m2</a>
<a href="#">Fd538</a>
<a href="#">Fd1879</a>
<a href="#">Fg60pd1e0a-F28</a>
<a href="#">Fd525</a>
<a href="#">Sr Ad40am0.1</a>
<a href="#">Cs Ar-02v024</a>
<a href="#">E2 Cp10g2v1 (1 Pack = 10 Pcs.)</a>
<a href="#">Fr E150-S1</a>
<a href="#">E2 1perz4531-T6</a>
<a href="#">E2 1pu2r4210-T6</a>
<a href="#">Fs1896e024-F</a>
<a href="#">Sral40am0.1</a>
<a href="#">Mkv11d03</a>
<a href="#">F10 Fr1-35636 Fr 530-M1j1</a>
<a href="#">.Head Tipe - 96d</a>
<a href="#">Fd535-2</a>
<a href="#">Nfb110bb-Dmk</a>
<a href="#">Mv15</a>
<a href="#">Vfap-S13ap-301</a>

<a href="#">Vfili024rp</a>
<a href="#">FI993</a>
<a href="#">E03 Fd1-4279 Safety Switch</a>
<a href="#">Sr-Al41an1-A01n</a>
<a href="#">Fd520</a>
<a href="#">Fk-302</a>
<a href="#">Cs Ar 01</a>
<a href="#">FI501</a>
<a href="#">Vfkeyf2</a>
<a href="#">Fd1880</a>
<a href="#">Srbd40alk-B02f</a>
<a href="#">Fa4501 1sh Ex5</a>
<a href="#">Csar-07 M024 Safety Relay</a>
<a href="#">Fa4101-2dn</a>
<a href="#">FI532</a>
<a href="#">Fd1878 (Fd1-7129 Fd678 Id4)</a>
<a href="#">Cs Ar 02v024</a>
<a href="#">Fr530-M1</a>
<a href="#">Vfkeyf7</a>
<a href="#">Fp1216</a>
<a href="#">Cs At-32v024</a>
<a href="#">Fs1896d024-F</a>
<a href="#">Cs Dm - 01v024</a>
<a href="#">E13fr1-102671 Limit Switch</a>
<a href="#">Fd532</a>
<a href="#">Fr993-D1</a>
<a href="#">Fs2096-D024-F7</a>
<a href="#">Pap13c6n</a>
<a href="#">2093-F</a>
<a href="#">Fd1878</a>
<a href="#">Fs2096d24</a>

<a href="#">Csat-32v024</a>
<a href="#">Csar-04v024</a>
<a href="#">Fd576</a>
<a href="#">Vfaf-Mr5</a>
<a href="#">Es 31001</a>
<a href="#">Fd531-1</a>
<a href="#">Cs At - 32 V024 Safety Relay</a>
<a href="#">Fd515</a>
<a href="#">C10 Fd1-21575</a>
<a href="#">Fg60bd1d0a</a>
<a href="#">Fg60ad1e0z</a>
<a href="#">Vf Keyf2</a>
<a href="#">I12fs1-79958</a>
<a href="#">Fm515</a>
<a href="#">Srad40am0.1</a>
<a href="#">Fk3393-D1m1</a>
<a href="#">Vfaf-Tr8</a>
<a href="#">Fd531</a>
<a href="#">Vfkeyd10</a>
<a href="#">Csar-08v024</a>
<a href="#">151123005-Pizzato</a>
<a href="#">Vfaf-Ifigr03</a>
<a href="#">Ms15</a>
<a href="#">Fd2195-Gm2</a>
<a href="#">Code 5 1no 1nc</a>
<a href="#">FI576-T6</a>
<a href="#">Fr 692-D1</a>
<a href="#">Fc 351 1</a>
<a href="#">D08fb1-2-3824 Fm915-M2 2nc</a>
<a href="#">Fr515</a>

<a href="#">Srbd40an2-B02f</a>
<a href="#">Fs2996d024-F</a>
<a href="#">Fg60gpid0a-F20</a>
<a href="#">Vfaf-Tr5</a>
<a href="#">Fr502-J1</a>
<a href="#">Fr655-M2r26</a>
<a href="#">Fr555-1</a>
<a href="#">Fb4103-6sn</a>
<a href="#">Fd535-1</a>
<a href="#">Nfb110ch-Smk</a>
<a href="#">Pz10110</a>