

## Quindar Electronics

Garanti: 12 ay  
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Quindar Electronics** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

*Firmamız Quindar Electronics Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.*



rn	Aıklama
<a href="#">Qst-1130</a>	SCAN XMTR
<a href="#">Qsr-1130</a>	SCAN RECEIVER
<a href="#">Qt-10-2600</a>	TONE TRANSMITTER 2600HZ
<a href="#">Qt-30-2800</a>	TONE TRANSMITTER 2800HZ
<a href="#">Qr-30-765</a>	TONE RECEIVER 765HZ
<a href="#">Qr-90-965</a>	TONE RECEIVER 965HZ
<a href="#">Qr-30-465</a>	TONE RECEIVER 465HZ
<a href="#">Qr-90-1775</a>	TONE RECEIVER 1775HZ
<a href="#">40-055958-003</a>	A-D CONVERTER
<a href="#">Qr-90-2700</a>	TONE RECEIVER 2700HZ
<a href="#">Cpr-041</a>	XCELL HARDWARE
<a href="#">Qr-90-1615</a>	TONE RECEIVER 1615HZ

<a href="#">Qt-90-2400</a>	TONE TRANSMITTER 2400HZ
<a href="#">Qr-30-1275</a>	TONE RECEIVER 1275HZ
<a href="#">Qr-30-2400</a>	TONE RECEIVER 2400HZ
<a href="#">Qt-10-3600</a>	TONE TRANSMITTER 3600HZ
<a href="#">30-056190-001</a>	STATUS INPUT BOARD
<a href="#">Qt-10-2400</a>	TONE TRANSMITTER 2400HZ
<a href="#">Qr-30-1875</a>	TONE RECEIVER 1875HZ
<a href="#">Qt-30-1675</a>	TONE TRANSMITTER 1675HZ
<a href="#">Qt-30-665</a>	TONE TRANSMITTER 665HZ
<a href="#">Qr-30-1475</a>	TONE RECEIVER 1475HZ
<a href="#">Qdtr20</a>	RECEIVER CARD
<a href="#">Qt-30-565</a>	TONE TRANSMITTER 565HZ
<a href="#">Qt-30-1175</a>	TONE TRANSMITTER 1175HZ
<a href="#">6cpp6</a>	CENTRAL PROCESSOR PANEL
<a href="#">Qr-90-365</a>	TONE RECEIVER 365HZ
<a href="#">Qr-30-965</a>	TONE RECEIVER 965HZ
<a href="#">Qdtt20</a>	TRANSMITTER DIGITAL DATA
<a href="#">Qt-30-1275</a>	TONE TRANSMITTER 1275HZ
<a href="#">Aot-020</a>	XCELL HARDWARE
<a href="#">Qr-90-2500</a>	TONE RECEIVER 2500HZ
<a href="#">Qt-30-1575</a>	TONE TRANSMITTER 1575HZ
<a href="#">40-055953-00</a>	CONVERTER BOARD DIGITAL TO ANALOG
<a href="#">Hdo-040</a>	XCELL HARDWARE
<a href="#">Qt-30-1375</a>	TONE TRANSMITTER 1375HZ
<a href="#">Qt-10-1675</a>	TONE TRANSMITTER 1675HZ
<a href="#">Qt-30-2100</a>	TONE TRANSMITTER 2100HZ
<a href="#">6ad1-3</a>	PC BOARD ANALOG TO DIGITAL CONVERTER
<a href="#">Qt-10-2100</a>	TONE TRANSMITTER 2100HZ
<a href="#">Qr-90-2200</a>	TONE RECEIVER 2200HZ
<a href="#">Qt-10-1775</a>	TONE TRANSMITTER 1775HZ

<a href="#">Qr-30-2500</a>	TONE RECEIVER 2500HZ
<a href="#">Qt-30-1875</a>	TONE TRANSMITTER 1875HZ
<a href="#">Qr-30-665</a>	TONE RECEIVER 665HZ
<a href="#">Qt-30-865</a>	TONE TRANSMITTER 865HZ
<a href="#">Qup-1</a>	BATTERY PACK 13.8V
<a href="#">Qt-90-2500</a>	TONE TRANSMITTER 2500HZ
<a href="#">Qr-10-1675</a>	TONE RECEIVER 1675HZ
<a href="#">Qt-30-3000</a>	TONE TRANSMITTER 3000HZ
<a href="#">Qr-30-865</a>	TONE RECEIVER 865HZ
<a href="#">Work Bench Licence</a>	XCELL HARDWARE
<a href="#">Qt-90-2200</a>	TONE TRANSMITTER 2200HZ
<a href="#">Qr-30-565</a>	TONE RECEIVER 565HZ
<a href="#">Qt-10-2900</a>	TONE TRANSMITTER 2900HZ
<a href="#">6cpp4</a>	PC BOARD PROCESSOR FOR RTU-4000
<a href="#">Qt-30-2500</a>	TONE TRANSMITTER 2500HZ
<a href="#">Qr-30-2300</a>	TONE RECEIVER 2300HZ
<a href="#">Qt-30-965</a>	TONE TRANSMITTER 965HZ
<a href="#">Qt-30-765</a>	TONE TRANSMITTER 765HZ
<a href="#">Qt-30-365</a>	TONE TRANSMITTER 365HZ
<a href="#">Qt-30-385</a>	TONE TRANSMITTER 385HZ
<a href="#">Qr-10-1775</a>	TONE RECEIVER 1775HZ
<a href="#">Opi-045</a>	XCELL HARDWARE
<a href="#">Qt-30-2000</a>	TONE TRANSMITTER 2000HZ
<a href="#">Qt-30-465</a>	TONE TRANSMITTER 465HZ
<a href="#">Qt-30-1075</a>	TONE TRANSMITTER 1075HZ
<a href="#">Qt-90-2100</a>	TONE TRANSMITTER 2100HZ
<a href="#">Qr-90-1075</a>	TONE RECEIVER 1075HZ
<a href="#">Qt-30-2600</a>	TONE TRANSMITTER 2600HZ
<a href="#">Qr-10-2100</a>	TONE RECEIVER 2100HZ
<a href="#">Qr-30-1375</a>	TONE RECEIVER 1375HZ
<a href="#">Qr-30-1675</a>	TONE RECEIVER 1675HZ

<a href="#">Qr-30-365</a>	TONE RECEIVER 365HZ
<a href="#">Qt-10-1075</a>	TONE TRANSMITTER 1075HZ
<a href="#">Qr-30-2700</a>	TONE RECEIVER 2700HZ
<a href="#">40-056180-001e</a>	MULTIPLEXER BD
<a href="#">Qt-30-2300</a>	TONE TRANSMITTER 2300HZ
<a href="#">Qr-90-Ttr-5</a>	TONE RECEIVER TTR-5 12V
<a href="#">Qup-2</a>	BATTERY PACK POWER MODULE
<a href="#">Qr-30-2800</a>	TONE RECEIVER 2800HZ
<a href="#">Qt-30-2400</a>	TONE TRANSMITTER 2400HZ
<a href="#">Rak-081</a>	XCELL HARDWARE
<a href="#">Qr-30-1575</a>	TONE RECEIVER 1575HZ
<a href="#">Qt-30-1475</a>	TONE TRANSMITTER 1475HZ
<a href="#">Qr-30-2000</a>	TONE RECEIVER 2000HZ
<a href="#">Hai-030</a>	XCELL HARDWARE
<a href="#">6da1</a>	PC BOARD DIGITAL TO ANALOG CONVERTER
<a href="#">Qr-30-1175</a>	TONE RECEIVER 1175HZ
<a href="#">Qr-30-1075</a>	TONE RECEIVER 1075HZ
<a href="#">40-057552-0000</a>	CENTRAL PROCESSOR PANEL