



## Rosemount Analytical

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Rosemount Analytical** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Rosemount Analytical T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen Özel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*

¼r¼n	A¼ıklama
<a href="#">24098-00 50FT</a>	Sensor extension cable for analyzer measuring water turbidity
<a href="#">Rosemount Analytical Clarity II, PN 8-0108-0003-İS</a>	
<a href="#">3051-Tg2a2b21ab4e5m5q8</a>	PRESSURE TRANSMITTER -14.7-150PSI 10.5-55VDC
<a href="#">8800cf030sa1n1d1i5m5</a>	FLOW METER VORTEX 3IN 4-20MA 10.8-42VDC
<a href="#">1151dp4s52b1m8</a>	PRESSURE SMART TRANSMITTER 1151
<a href="#">2051cd1a02a1ah2s</a>	TRANSMITTER
<a href="#">3900</a>	
<a href="#">F1c6b4m5</a>	TEMPERATURE TRANSMITTER
<a href="#">399-10(Obsolete Replaced By 3900)</a>	
<a href="#">300smvmra1ak5m5q4t1</a>	PRESSURE TRANSMITTER
<a href="#">2088g4s22a1c6q4</a>	PRESSURE TRANSMITTER 250BAR 10.5-36VDC

<a href="#">3900-01-10</a>	
<a href="#">3051cd3a02a1as5e5m5q4</a>	PRESSURE TRANSMITTER 10.5-55VDC
<a href="#">5303ha1s1v5ae01000rana</a>	TRANSMITTER LEVEL RADAR 16-42.4VDC
<a href="#">8712cr12n0</a>	TRANSMITTER SMART FAMILY MAGNETIC FLOW
<a href="#">P330</a>	PRESSURE VALIDATOR
<a href="#">8800-Df080sa1n1d1m5</a>	VORTEX FLOW METER 8800D SERIES
<a href="#">1056-03-22-32-An</a>	ANALYZER PH/ORP 85-265VAC
<a href="#">2088g3s22a1s1m7</a>	PRESSURE TRANSMITTER 800PSI 10.5-36VDC
<a href="#">2051cg3a02a1ah2s</a>	TRANSMITTER
<a href="#">1151dr2f12</a>	PRESSURE TRANSMITTER
<a href="#">8800df040sa1n1d1</a>	FLOW METER
<a href="#">3051cd1a22a1ae5</a>	PRESSURE TRANSMITTER
<a href="#">Idp10-T22b21f-L1</a>	FLOW TRANSMITTER 0-100 IN H2O 12.5-42VDC
<a href="#">3051tg1a2b21ab4m5</a>	PRESSURE TRANSMITTER 10.5-55VDC 30PSI
<a href="#">08712-0015-0002</a>	TRANSMITTER MAGNETIC FLOWMETER INTERFACE
<a href="#">3095fb2caba10ab000anc1</a>	FLOW TRANSMITTER 0-150DEG F 0-800PSI MODBUS
<a href="#">1152gp9e22t0280pb</a>	PRESSURE TRANSMITTER NUCLEAR 0-3000PSIG 45VDC
<a href="#">0225-03-54</a>	CONDUCTIVITY SENSOR 200PSIF 20FT CABLE
<a href="#">8732est1a1nam4</a>	MAGNETIC FLOW TRANSMITTER
<a href="#">Rtg40bll0p1a0a00</a>	TRANSMITTER
<a href="#">8705tsa010c1w0n0</a>	FLOW METER 1IN MAGNETIC 285PSI 40VDC
<a href="#">2051cd2a02a1ah2s</a>	TRANSMITTER
<a href="#">1151llt5e23c0m1i5</a>	PRESSURE TRANSMITTER 0-750IN H2O 4-20MA 45VDC
<a href="#">3095-Mfa6030cchps1t100t31ba1arlq4k5m5y1</a>	ANNUBAR FLOW METER 11-55VDC 785PSIG 32-500 DEG F
<a href="#">498cl-01</a>	
<a href="#">1151gp6e22</a>	PRESSURE TRANSMITTER 0-30PSI 4-20MA 45VDC 2000PSI
<a href="#">3144pd1a1e5m5xa</a>	TEMP TRANSMIT
<a href="#">3051-Cd1a02a1ae5s5</a>	PRESSURE TRANSMITTER 55VDC 2000PSI
<a href="#">1056-01-21-31-An-UI</a>	ANALYZER DUAL INPUT 10W 115/230VAC 2OUTPUT 4-20MA
<a href="#">1056-02-20-38-An</a>	ANALYZER DUAL INPUT 24VDC

<a href="#">08800-0250-0001</a>	TEMPERATURE VORTEX SENSOR SPARE PART FOR 8800
<a href="#">3051-D2a21s1i5</a>	PRESSURE TRANSMITTER
<a href="#">3051-D1a21s1i5d3</a>	PRESSURE TRANSMITTER 3626PSI
<a href="#">Pbr15s020ha2s0c0000mp2co1a1ak53k1q40</a>	FLOW TRANSMITTER 0-11.918 IN H2O 10.5-55VDC
<a href="#">3051s2ca1a2e12a1</a>	PRESSURE TRANS
<a href="#">1056-02-20-31-Ht</a>	OPERATOR INTERFACE 15W 24VDC
<a href="#">1151dp3s33m1b1</a>	PRESSURE TRANSMITTER 0-15IN H2O 12-45VDC 2000PSI
<a href="#">1056-03-22-38-An</a>	
<a href="#">3095fb3daba10ab000anc1</a>	FLOW TRANSMITTER 0-150DEG F 0-1500 PSI MODBUS
<a href="#">3051cg3a02a1as5e5m5q4</a>	PRESSURE TRANSMITTER 10.5-55VDC 36PSI
<a href="#">23311-01</a>	VALVE MANUAL RETRACTION/INSERTION ASSEMBLY
<a href="#">1056-02-21-38-An-UI</a>	ANALYZER LIQUID
<a href="#">3051cd3a02a1as5e55m5q4</a>	PRESSURE TRANSMITTER
<a href="#">8705tsa030s1</a>	FLOW METER 275 PSI 350DEG/F
<a href="#">5301ha1s1v4ae005</a>	LEVEL TRANS
<a href="#">Pwa01984-1460-0003</a>	PC BOARD CONTACT I/O
<a href="#">8712cr12n5</a>	FLOW METER MAGNETIC 115VAC
<a href="#">1151lt5ea0a12dm1</a>	PRESSURE TRANSMITTER 0-750 H2O 4-20MA 45VDC 285PSI
<a href="#">8705psa040c1w0n0q4</a>	MAGNETIC FLOW METER FLOWTUBE
<a href="#">Tf39601c08</a>	PH METER
<a href="#">3051cd1a02a1as5m5t1</a>	PRESSURE TRANSMITTER 4-20MA
<a href="#">396p-02-10-55</a>	
<a href="#">3051-Cg4a22a1as1m5b4e5</a>	TRANSMITTER 250PSI
<a href="#">498cl Replaced By 498cl-01</a>	
<a href="#">8712esr1a1n0m4q4</a>	MAGNETIC FLOW METER TRANSMITTER-REMOTE
<a href="#">1154dp5rg</a>	PRESSURE TRANSMITTER 24VDC 2000PSIG
<a href="#">3051cd1a02a1ah2b2</a>	PRESSURE TRANSMITTER 4-20MA 2000PSI
<a href="#">3051l2ab4gc11aae</a>	TRANSMITTER
<a href="#">3534b18g01</a>	DIFFUSER HUB ASSEMBLY
<a href="#">Model 1055 Obsolete, Replaced By 1056-03-22-38-An</a>	

<a href="#">1151lt5ec0c23dm1t5</a>	PRESSURE TRANSMITTER 0-750IN H2O 4-20MA 45VDC
<a href="#">1056-01-22-32-An</a>	PH/ORP ANALYZER 115/230V
<a href="#">2088q4s22a2m5n1b</a>	TRANSMITTER
<a href="#">3051s1cd2a2b12f1aa01b4m5ge</a>	PRESSURE TRANSMITTER
<a href="#">3051cd1a52a1a</a>	PRESSURE TRANSMITTER
<a href="#">3095-Mfag020cchps1t100t31ba1arlq4k5m5y1</a>	ANNUBAR FLOW METER 11-55VDC 785PSIG 4-20MA
<a href="#">3051s1ca2a2a11a1</a>	FLOW METER
<a href="#">3144-D1b4m5c6</a>	TEMPERATURE TRANSMITTER
<a href="#">1056-01-22-32-An-UI</a>	ANALYZER SOLUCOMP II 115/230VAC 50/60HZ
<a href="#">Tf39602</a>	PROBE
<a href="#">1151lt4sc0c33dm1i5</a>	PRESSURE TRANSMITTER 0-150IN H2O 4-20MA 45VDC
<a href="#">0081ph/Orp-01</a>	ANALYZER CONTROLLER PH/ORP 115/230V
<a href="#">3051-D1a21s1i5d3b1</a>	PRESSURE TRANSMITTER 12.5-55VDC
<a href="#">1151llt4e33c0m1i5</a>	PRESSURE TRANSMITTER 0-150IN H2O 4-20MA 45VDC
<a href="#">2051cg4a02a1ah2s</a>	TRANSMITTER
<a href="#">1151dp6e22b1i5</a>	PRESSURE TRANSMITTER 0-60PSID 45VDC 2000PSI
<a href="#">2051cd4a02a1ah2s</a>	TRANSMITTER
<a href="#">3051s2ca1a2e5l2m</a>	PRESSURE TRANS
<a href="#">5600</a>	TRANSMITTER 10W 240VAC 60HZ
<a href="#">3051s1cg4a2e12a1</a>	PRESSURE TRANS
<a href="#">3051c-D2a02a1ah2b7i5l4</a>	PRESSURE TRANSMITTER
<a href="#">3051-Tg4a2b21ae5m</a>	PRESSURE TRANSMITTER
<a href="#">1054bdc</a>	ANALYZER DUAL CELL CONDUCTIVITY 115/230VAC 50/60HZ
<a href="#">2051cg5a02a1ah2s</a>	TRANSMITTER
<a href="#">5081-P-Ht-20-60</a>	TRANSMITTER 4-20MA PH/ORP
<a href="#">3051cg2a22a1ab4l4df</a>	PRESSURE TRANSMITTER 9PSI .62BAR 10.5-55VDC
<a href="#">Xmt-P-Ht-10-73(Obsolete Replaced By 1066</a>	
<a href="#">8800cf005sa1n1d1e5m5</a>	FLOW METER 30/42VDC 4-20MA 10000HZ
<a href="#">3051cg5a02a1as5e5q4</a>	PRESSURE TRANSMITTER

<a href="#">3200hp</a>	PH SENSOR W/PHASER FLOWING JUNCTION
<a href="#">140-04</a>	CONDUCTIVITY SENSOR 100PSIG STAINLESS STEEL
<a href="#">1151dp5s2214</a>	PRESSURE TRANSMITTER 4-20MA 186.4KPA
<a href="#">Ma13a0011aa00nabs5</a>	FLOW TRANSMITTER 11-55VDC 0-25 IN H2O
<a href="#">Oxt4adr341112030</a>	PROBE
<a href="#">3051tg4a2b21ae5m5t1b4</a>	PRESSURE TRANSMITTER 0/4000PSI 10.5/55VDC 4/20MA
<a href="#">Pwa78894-01</a>	MONITOR EXTENDER
<a href="#">3051s2ta3a3a11a1ab4e5</a>	PRESSURE TRANSMITTER 10.5/42.4VDC 0/800PSI
<a href="#">Oxt4a-6515-121-1-00-01-00</a>	
<a href="#">1151dp6e12t0611b1m1</a>	PRESSURE TRANSMITTER ANALOG 100PSI 4-20MA
<a href="#">3051cd0a02a1ah2b1l4q4</a>	PRESSURE TRANSMITTER 4-20MA 10.5-55VDC 750PSI
<a href="#">1056-01-21-38-An</a>	PH/ORP ANALYZER 115-230VAC 50/60HZ 10W
<a href="#">1151gp7s2ab1p2</a>	FLOW TRANSMITTER 0-120PSI 45VDC
<a href="#">Model 880</a>	
<a href="#">Xmt-T-Ht-11</a>	TRANSMITTER
<a href="#">01984-0298-0001</a>	POWER SUPPLY IP:8A 115VAC 60HZ OP:22A 30VDC
<a href="#">3144d1e9b4m504</a>	SMART TEMPERATURE TRANSMITTER 12-42.4VDC
<a href="#">Oxt4a S/N F-11004337 O2 Cell</a>	
<a href="#">5301ha1s1v5ae008</a>	LEVEL TRANS
<a href="#">3051cd3a02a1am5dfe5h2p9q4</a>	PRESSURE TRANSMITTER LCD DISPLAY -1000-1000H2O PSI
<a href="#">1054blc</a>	ANALYZER 115-230VAC 50/60HZ 10W
<a href="#">248hanaa2xaf6</a>	TRANSMITTER/TEMP MONITORING ASSEMBLY 0-100DEG CEL
<a href="#">3051cg4a02a1as5e5q4</a>	PRESSURE TRANSMITTER 10.5-55VDC 300PSI
<a href="#">1066</a>	
<a href="#">8800-Df020sa1n1d1e5m5q4q8</a>	VORTEX FLOW METER 450F 232C
<a href="#">8712esr1a1nam4</a>	REMOTE MAGNETIC FLOWMETER TRANSMITTER
<a href="#">1056022030an</a>	ANALYZER
<a href="#">2051cg1a02a1ah2s</a>	TRANSMITTER
<a href="#">3095-Ma24bac14aa010aa</a>	FLOW TRANSMITTER 55VDC -40-1200F
<a href="#">5302ha2s1v4am00100rbe1q4q8</a>	TRANSMITTER GUIDED WAVE RADAR LEVEL 4-20MA 20-42V

<a href="#">1055-01-10-S1-Dm</a>	CONDUCTIVITY ANALYZER 115/230VAC 50/60HZ 8W
<a href="#">4847b61g16</a>	
<a href="#">3051tg3a2b21bi1m</a>	TRANSMITTER
<a href="#">3051cd3a22a1am5t1</a>	PRESSURE TRANSMITTER 250PSI 55VDC
<a href="#">3051s1tg3a2a11a1</a>	PRESSURE TRANS