

## Servostar

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Servostar** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Servostar T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunulmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



¼r¼n	A¼ıklama
<a href="#">Sr06000-2g405a</a>	SERVO DRIVE 140/340VDC 115/230VAC 6AMP
<a href="#">Mt304b1-R1c1</a>	SERVO MOTOR BRUSHLESS GOLDLINE
<a href="#">Ats-Servostar-603-As-Bv</a>	SERVO DRIVE 3AMP 2.0KVA 3X230-480VAC IP20
<a href="#">S30601ec</a>	SERVO DRIVE
<a href="#">Bds4a-206j-0001/205b2</a>	SERVO DRIVE 310VDC IN/6AMP 230VAC OUT
<a href="#">Bds4a-203j-0001-104a21p</a>	SERVO AMPLIFIER 310VDC/4.5AMP IN 230VAC/3AMP OUT
<a href="#">S67001</a>	SERVO DRIVE
<a href="#">Sr20200</a>	SERVO DRIVE
<a href="#">Bds4a220j3107c23</a>	SERVO DRIVE
<a href="#">Mt308b1-E2d1</a>	SERVO MOTOR 230V 3000RPM 5.16AMP-CONT 24.5AMP-PEAK
<a href="#">Cr06250</a>	SERVO DRIVE AMPLIFIER -INCOMPLETE PART NUMBER-
<a href="#">Prd-B040asib-62</a>	SERVO DRIVE 115/230VAC

<a href="#">Mt306b1-E2d1</a>	SERVO MOTOR BRUSHLESS GOLDLINE 3PH 230V 4600RPM
<a href="#">Ats-Servostar-603-As</a>	SERVO DRIVE 3AMP 2.0KVA 3X230-480VAC IP20
<a href="#">S62000</a>	SERVO DRIVE 20A 230-480V 14KVA
<a href="#">Sr10200-Y010</a>	SERVO DRIVE AMPLIFIER
<a href="#">S60600</a>	SERVO CONTROLLER W/O AS SAFETY RELAY
<a href="#">S61401</a>	SERVO DRIVE
<a href="#">Sc1e03260-000000</a>	DRIVE SERVOSTAR SC 3PHASE INPUT/OUTPUT 115/230VAC
<a href="#">Sr030002g202b</a>	DRIVE
<a href="#">Prd-B040asic-62</a>	SERVO DRIVE 115/230VAC
<a href="#">S67001-Na</a>	AMPLIFIER
<a href="#">Bds4a-206j-0014-206b8</a>	SERVO AMPLIFIER
<a href="#">S6031na</a>	SERVOSTAR603
<a href="#">Servostar303</a>	SERVO DRIVE
<a href="#">610-As</a>	SERVO DRIVE 10AMP 7KVA 3X230X480VAC IP20
<a href="#">Sr10200-2g406a</a>	AMPLIFIER
<a href="#">S31061-Na</a>	SERVO DRIVE 10AMP 110-230V 50/60HZ SERVOSTAR 310
<a href="#">Sr20200-Y036</a>	AMPLIFIER
<a href="#">Lr03260</a>	SERVO AMP 6.2/4AMP 115/230VAC
<a href="#">Bds4a-206j-001-206b21p</a>	SERVO DRIVE 310VDC 9ADC IN 230VAC
<a href="#">S62000-Pb</a>	SERVO DRIVE BRUSHLESS 20AMP 230/480VAC
<a href="#">Bds4a-220j-0001-402c3</a>	SERVO DRIVE 28ADC/310VDC IN 20AMP/230VAC OUT
<a href="#">Bds4a-203j-0096-102b2</a>	SERVO DRIVE
<a href="#">Mt302b1-E2d3</a>	SERVO MOTOR 3PM 230V 6000RPM CLASS F GOLDLINE
<a href="#">Bds4a-206h-204c2</a>	SERVO DRIVER
<a href="#">De86860</a>	MOTOR
<a href="#">Bds4a-206j-0001-Z04b2</a>	SERVO AMPLIFIER INPUT/310VDC 9A OUTPUT/ 230VAC 6A
<a href="#">S60300-Pb</a>	3A SERVO DRIVE
<a href="#">Mt328sa1-R9c1-001</a>	SERVO MOTOR 2500/3000RPM 1.94A/CONT 10.3A/PK 480V
<a href="#">S30301-Na</a>	SERVO DRIVE SERVOSTAR-300 3AMP 208-480V 2.5KVA
<a href="#">S74801-Na</a>	SERVVO AMPLIFIER

<a href="#">Cb10551</a>	SERVO DRIVE 10AMP 230VAC BRUSHLESS
<a href="#">614-As</a>	SERVO DRIVE 14AMP 10KVA 3X230-480
<a href="#">Mt308b1r2c2</a>	SERVO MOTOR
<a href="#">Se10000-000000</a>	SERVO DRIVE
<a href="#">S60300-590</a>	SERVO CONTROLLER 3X230-480V SERVOSTAR 603
<a href="#">S6031</a>	SERVOSTAR603
<a href="#">Sc1e06260</a>	SERVO DRIVE CONTROL SINGLE AXIS
<a href="#">Mt1506b1-R1d2</a>	SERVO MOTOR BRUSHLESS GOLDLINE XT
<a href="#">Bds4a220j3107c24</a>	SERVO DRIVE
<a href="#">Sr10000-000000</a>	SERVO DRIVE 14/10A 140/310VDC 115/230VAC
<a href="#">Bds4a-206j-0001-206b21p</a>	SERVO DRIVE 6AMP 230VAC 9AMP 310VDC
<a href="#">S60601</a>	SERVO DRIVE SERVOSTAR 600 MODEL 606-AS 3X230-480V
<a href="#">Bds4a-210j-0014-404b8</a>	SERVO AMPLIFIER
<a href="#">Z100-176116</a>	
<a href="#">Sr06200-2g404a</a>	AMPLIFIER
<a href="#">S61400-Na</a>	SERVO DRIVE
<a href="#">De-83211</a>	SERVO MOTOR
<a href="#">Sr-06000-000000</a>	SERVO DRIVE 6AMP 115/230VAC 1/2.3KW
<a href="#">403a-C</a>	SERVOSTAR DRIVE 3AMP 320VDC IP20 403A-C SERIES
<a href="#">Cr06250-2g1506b1</a>	SERVO DRIVE SERVO STAR SA4
<a href="#">Sr10000-2g415u</a>	SERVO DRIVE 115/230VAC 10AMP 1.6/3.6KW
<a href="#">S30661-Na</a>	SERVO DRIVE 6AMP 110-230VAC 3PHASE SERVOSTAR-306
<a href="#">Ce06200-000000</a>	SERVO DRIVE 115/230VAC
<a href="#">Sr06200-26404a</a>	SERVO AMPLIFIER
<a href="#">Bds4a-240j-001-605c21p</a>	SERVO DRIVE 310VDC 57A IN 230VAC 40A OUT
<a href="#">Mt302a1-E2c3</a>	SERVO MOTOR 4500RPM 230V 9AMP
<a href="#">Cr06561</a>	SERVO DRIVE 6AMP 24V
<a href="#">Mt1504a1-R2c1</a>	SERVO MOTOR BRUSHLESS GOLDLINE 230V 11A 6000RPM
<a href="#">Sc1r06260</a>	SERVO AMPLIFIER DRIVE 3PH
<a href="#">Ce06560</a>	SERVO DRIVE 6AMP 230VAC 1 PHASE
<a href="#">S62000-Na</a>	SERVO DRIVE 20A

[Mt308a1-R1c1](#)

SERVO MOTOR 12.2AMP 230V 1500RPM

[Bds4a206j0001405a2](#)

SERVO AMPLIFIER 230VAC 6-AMP OUTPUT