

## Spectrum Controls

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Spectrum Controls** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Spectrum Controls T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



¼r¼n	A¼ıklama
<a href="#">260a1402m</a>	OIT SWITCH BOARD DUAL SWITCH 9IN PRINT PORT 6CHAN
<a href="#">Soi-200-Ab-120a-16k-485-Pp</a>	OPERATOR INTERFACE 4X20LCD 16K MEMORY 120VAC
<a href="#">1769sc-Of4ih</a>	OUTPUT MODULE ANALOG 4PT W/HART PROTOCOL CURRENT
<a href="#">Wp41201</a>	MODULE
<a href="#">140-Avi-050-00-Sc</a>	MODULE
<a href="#">140-Aci-052-00sc</a>	32-CHANNEL ANALOG INPUT WITH TIME STAMP (CURRENT OR VOLTAGE)
<a href="#">Wp41207</a>	MODEM
<a href="#">1794sc-If8iu</a>	INPUT MODULE 8PT UNIVERSAL TC RTD USE W/1794-TB3G
<a href="#">Wp23207</a>	MODEM
<a href="#">1746-Sc-No8i</a>	OUTPUT MODULE 8POINT ANALOG CURRENT ONLY
<a href="#">140-Aui-040-00sc</a>	16-CHANNEL UNIVERSAL ANALOG INPUT (THERMOCOUPLE, RTD, CURRENT OR VOLTAGE)

<a href="#">1746sc-Ino4vi</a>	OUTPUT MODULE ANALOG 4POINT ISOLATED CURRENT/V
<a href="#">Gc817aj1</a>	POWER OUTLET STRIP 20A, 115VACGC817AJ1 REV H
<a href="#">2707-M232psc/E</a>	INTERFACE CONTROL PANEL
<a href="#">Wp21207</a>	MODEM
<a href="#">140-Aui-040-00</a>	INPUT MODULE 16POINT ANALOG
<a href="#">1746sc-Ni8u</a>	INPUT MODULE UNIVERSAL 8POINT TC RTD V OR C
<a href="#">Wp21204</a>	MODEM
<a href="#">Vw20003</a>	SOFTWARE
<a href="#">1794sc-Irt8i</a>	INPUT MODULE 8PT ANLG ISLTD RTD TC USE W/1794-TB3G
<a href="#">Wp26207</a>	MODEM WEBPORT 2005 CD/EDGE
<a href="#">Wp43204</a>	MODEM
<a href="#">Soi260al402x</a>	INTERFACE
<a href="#">Wp41204</a>	MODEM
<a href="#">Wp46207</a>	MODEM
<a href="#">2706-P92c-Sc</a>	INVIEW MESSAGE DISPLAY 1-5 LINES, 3 FT
<a href="#">8000-Roi-116</a>	16PT INPUT CARD
<a href="#">1771sc-Imi16</a>	16 Point Isolated Input Module
<a href="#">7630200-04</a>	CONTROL PANEL DISPLAY DTAM MICROVIEW 24VDC
<a href="#">Fpio-O8h-Eip</a>	8 CHANNEL VOLTAGE/CURRENT/CURRENT+HART OUTPUT MODULE MODBUS TCP AND ETHERNET IP PROTOCOL SUPPORT EXTERNAL SUPPLY +14 TO +48VDC OR POE
<a href="#">2706-P22r-Sc</a>	In-View Message Display Specifications Panel 91100001-02
<a href="#">8000-Smc-110</a>	MESSAGE CENTER DISPLAY
<a href="#">2050275-02</a>	INPUT MODULE 6POINT ISOLATED RTD
<a href="#">Wp43207</a>	MODEM
<a href="#">Soi-200-Ab-120a-16k-485</a>	OPERATOR INTERFACE LCD RS422 16K MEMORY
<a href="#">9060005-05</a>	ANALOG INPUT MODULE 4 POINT
<a href="#">8000rd0732</a>	OUTPUT MODULE
<a href="#">Soi-260-Av0-40p-P2m</a>	CONTROLLER
<a href="#">Fpio-I8h-Eip</a>	8 CHANNEL VOLTAGE/CURRENT/CURRENT+HART INPUT MODULE MODBUS TCP AND ETHERNET IP PROTOCOL SUPPORT EXTERNAL SUPPLY +14 TO +48VDC OR POE

<a href="#">1769sc0f4ih</a>	OUTPUT MODULE
<a href="#">8000-Rdo-564</a>	MODULE REED RELAY OUTPUT
<a href="#">8000-Stc-402</a>	INPUT MODULE ANALOG TC FOR SYMAX
<a href="#">Soi-200-Ab-120a-16k-485-Rtc</a>	OPERATOR INTERFACE LCD RS422 16K MEMORY
<a href="#">7630402-02</a>	OPERATOR INTERFACE DTAM
<a href="#">1746sc-Ib8i</a>	Isolated DC Input Module
<a href="#">Wp26204</a>	MODEM
<a href="#">Wp05201</a>	MODULE
<a href="#">8000-Rtd-212</a>	INPUT MODULE ANALOG RTD 12POINT
<a href="#">9060072-02</a>	INPUT MODULE 6POINT ISOLATED RTD
<a href="#">Scx-3000</a>	SPECTRUM CONTROLS CONNECTS, ASSET CONNECTIVITY SOFTWARE CONNECT YOUR HART AMS SOFTWARE TOOLS TO YOUR FIELDPORT HART I/O
<a href="#">Wp46201</a>	ETHERNET MOD
<a href="#">8000soi2000ab120</a>	INTERFACE
<a href="#">Wp46204</a>	MODEM
<a href="#">7630303-05</a>	OPERATOR INTERFACE 15-23VAC 47-440HZ 20-30VDC
<a href="#">Wp23204</a>	MODEM
<a href="#">22004000</a>	CONTROL BOARD
<a href="#">140-Aci-051-00-Sc</a>	INPUT MODULE 32POINT SELECTABLE CURRENT VOLTAGE
<a href="#">260av402x</a>	OPERATOR INTERFACE 85-230V
<a href="#">2706p72cn2sc</a>	DISPLAY
<a href="#">140-Ehc-208-00sc</a>	EIGHT CHANNEL MEDIUM SPEED COUNTER 50KHZ / TURBINE FLOWMETER
<a href="#">1769sc-Ir6i</a>	INPUT MODULE 6POINT ISOLATED RTD