

Spohn Burkhardt

Garanti: 12 ay
Bu rne ait Trkiye ii kapı teslim fiyat ve teslim sresi ieren teklifimizi almak iin info@yursat.com.tr e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi iin +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz. **Spohn Burkhardt** Markası, tedarik sresi iin ltfen bizimle iletiŐime geiniz.

Firmamız Spohn Burkhardt Trkiye Distribtr veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen rnlerde sadece Orjinal ve yeni rn teklifi sunmaktadır. Bu sitede gsterilen zel marka adları ve ticari markalar ilgili sahiplerinin mlkiyetindedir, talep durumunda kaldırılmaktadır.



rn	Aıklama
Joystick VNS0	VNS0 2 F A-Y 18 AK R G41 9P1 ENCODER OGRPP20I- 1 Steps in viewing direction: zero detent Switching direction of view: 9P1 Lever deflection in the direction of view: 36 ° Retreat or brake Direction of view: retreat Attachments Direction of view: ENCODER OGRPP20I- 1 Drive: A-Y Lever length: 180mm Attachment: front Rosette: transparent plastic rosette Engraving: Without engraving Setting: stop setting (symmetrical) Contact type: silver Cuff: rubber cuff Handle: G41 ENCODER OGRPP20I- 1 Encoder: OGRPP20I- Characteristic curve: 1: linear Extension cable encoder: 2m
313.110	
VNS0-PT916	
47182	Double contact element
54088	Rubber boot holder
VCS0.2100969	Drive : E-U Steps in line of sight :1-0-1 circuit line of sight :10 Lever deflection in line of sight :20° Type of operation Viewing direction : Retreat Grip : G41 T SS Lever length : 140mm
VCS0.2100968	Joystick VCS0 VCS0 96 14 AK E-U R G41 HD S 1
NS003FODR_30	24968 master switch with waterproof rosette, Ball grip and 3-0-3 positions -with engraving 3-2-1-0-1-2-3 Replacement for com. 2070878- 6

VCS0 MODEL 3+3 button Joystick	
BUTON JOYSTICK VNS0-PT1153	
VSN0 PT850	
NS3.2204081	joystick NS3 Drawing: NS3-A-47A NS3 G 11 AK V R NS3-A-47A Switch type NS3 Drive V Steps in the direction of the zero detent Circuit viewing direction MP1 Lever deflection in line of sight 26° Operating mode viewing direction withdrawal Actuating torque viewing direction ~1.4 Nm Attachments Viewing direction B55 Steps transverse direction zero detent Circuit transverse direction MP1 Lever deflection in transverse direction 26° Operating mode cross direction retraction Actuating torque transverse direction ~1.4 Nm Attachments transverse direction B55 Grip G4T DT Lever length 110mm Gauntlet Rubber Gauntlet V041N Engraving Without engraving Gate stop gate (symmetrical) Contact type silver Joystick Drawing NS3-A-47A B55 Ohm value 5k-0-5kΩ Type of connection Solder connection Potentiometer B55 G4T DT.1805844 Type P9 F S BK Deadman button 1S Connection cable 1m Connection handle wiring harness without plug
NS3.2300884	Joystick NS3 Drawing: NS3-A-47B NS3 11 AK V R NS3-A-47B Switch type NS3 Drive V Steps in the direction of the zero detent Circuit viewing direction MP1 Lever deflection in line of sight 26° Operating mode viewing direction withdrawal Actuating torque viewing direction ~1.4 Nm Attachments Viewing direction B55 Steps transverse direction zero detent Circuit transverse direction MP1 Lever deflection in transverse direction 26° Operating mode cross direction retraction Actuating torque transverse direction ~1.4 Nm Attachments transverse direction B55 Grip G4T DT Lever length 110mm Gauntlet Rubber Gauntlet V041N Engraving Without engraving Gate stop gate (symmetrical) Contact type silver Joystick Drawing NS3-A-47B B55 B55 Ohm value 5k-0-5kΩ Type of connection Solder connection Potentiometer B55 G4T DT.1805844 Type P9 F S BK Deadman button 1S Connection cable 1m Connection handle wiring harness without plug
PL 310-5K0-0-5K0/M ABS S256	
VNS044FU18VRBM199PRT	
2152261.11.7	VC80.PT879
VNS0- PT767 (SR A/B LEFT 2-WAY)	
VNS0- PT768 (SR A/B RIGHT 4-WAY)	
JOYSTICK; TYPE VNS0.PT978	
VNSO.PT898	
18698	
12869 Ess 080k	
Vnsb2.44.22 Ear 5d.5d	
Vnso3fu18akertu240	
Ns 223a Nr:11663	
2068205-1/4 Vns022.11kknear	
Ns 244 Vk No:13845	
Pd550 5k-5k S286 (12120)	
Vns044fu18vr H (4-0-4 Steps)	
Vns05fu 18sker Iz	

Cs071b
Diode Cooler For 400ur120d
Ns 245-1 No:13872
Vns011fu18akvrh 8p1.8p1+2xpq1010
Vns04fu18er Bm294
21163
G32-12
30495, Oer420-1 Encoder Mit Stromausgang
Vnso44fn18kk Vr Iz
17791
Wire For Sensor Ess080
1k5-0-1k5 S233
Typ: Cs1-Pb13-Z , Alternativ 47148
420-1
Vnso2fn11aker.Tu20
2068205-1/14 Vns022.11kknuear
Vnso 4fn(U) 18er, 4-0-4 Notch
Vns044fu18vrbm199prt
Fw1
Spohn-Burkhardt-Ess080a-Art-Nr-12958- Auswertelektronik-F3;R-Kapazitiven-Sensor- Ess080k-Xxx-Betriebsspannung-24-Vdc- Ess080a-Hs-Code-85389091-Istanbul-Turkiye
2 Nsfr / 10
Bm210
Ns 2 Es46vj295 Nr: 13945
Vnso 2 Fn18 Er Tss
12157 Ns053kb
2068205-1/4
21909
11700 V184k
2035875-1/13
Vns044fu18vrhbm235pq2x1010s
Vns044fu18akvr 50.50
Ns 244hk No:13899
Vns04fu18er H (4-0-4steps)
12120, Pq55

13116 Ns052	
Cs1s_11 Ak Vr M1.M1 + Ugal112-45 Hs-Code: 85365019	
Artikel 21912	
Vns0_4_4_F_V-U_18_Ak_R_G41	Steps in the direction of view / left lever: 4-0-4 Circuit viewing direction: special circuit 4 double contacts Lever deflection in line of sight: 30 ° Retreat or brake viewing direction: 4-0-4 Steps transverse direction / right lever special circuit: 4-0-4 Lever deflection in the transverse direction: 30 ° Retreat or brake cross direction: retreat
Ns 245-2/3 No : 13873	
15064 (Hs-Code: 85365080)	
15973	
Ns 221 B-O No:13974	
28897	
31419, Vns022fu14akvrzs9p1.9p1+2xoer8g-1	
Vns0s1v185klriz	
Ns 2 Es 81-O Nr:13947	
Joy Stick Cover For Qc2	
Ns 244v1k No:13871	
Ns3g-Pb83-B - Alternativ 47148	
13437 (Ns161-128)	
13285 Ns025-06	
Bm 150	
Bm244	
19769 Sensorkopf Komplett: Griff Mit Chromkappe (Ns0es41/42c)	
Ns 2 Es46vj275 Nr: 13944	
Ns 245-0 No:13868	
Vns05-Fu11-Sker1z	
400ur 120d	
47148	
Vnso2fu18akertu9p1	
Ns 2 Es 81-S Nr:13948	