

## Woerner

Garanti: 12 ay  
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim s¼resi ve teslim s¼resi i¼eren teklifimizi almak i¼in [info@yursat.com.tr](mailto:info@yursat.com.tr) e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.  
**Woerner** Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

*Firmamız Woerner T¼rkiye Distrib¼t¼r¼ veya temsilcisi deĐildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.*



¼r¼n	A¼ıklama
<a href="#">205.225.-65</a>	
<a href="#">KUI-B/25</a>	
<a href="#">wie Bild</a>	
<a href="#">476.557-60</a>	
<a href="#">GMF-B</a>	
<a href="#">GFZ-D/1.00/45/P Nr.:204133</a>	(motor and pump must be coupled)
<a href="#">310355.2513-6A</a>	pump unit installed in the control cabinet for II 2D Ex h IIIC T135°C Db X ----- Pump unit: GMF Container : 30l incl. el. Min./Max. (intrinsically safe circuit) Motor : 230/400V 50Hz, II 2D Ex tb IIIC T120°C Db Pressure outlet: 2x ø15mm Delivery volume: 2x 0.4 cm³/min delivery pressure : Pmax. 350 bar including DBV Flow monitoring: 2x KUO-A - without a heater -
<a href="#">310355.2514-6A (non ATEX)</a>	pump unit installed in the control cabinet ----- Pump unit: GMF Container : 30l incl. el. Min./Max. (intrinsically safe circuit) Motor : 230/400V 50Hz Pressure outlet: 2x ø15mm Delivery volume: 2x 0.4 cm³/min delivery pressure : Pmax. 350 bar including DBV Flow monitoring: 2x

	KUO-A - without a heater - with VAT
<a href="#">VPA-B6/P</a>	212386
<a href="#">SBD-B/5/1/0/S/V</a>	03280329 MYS SPRAY APPARATUS WOERNER 310334.1310-6A
<a href="#">DUA-B</a>	
<a href="#">KUI-B01/00/0/A/200/UX</a>	with 91340597 Kabeldose M12/4p/0' without block Volume Flow Indicator
<a href="#">91000003</a>	
<a href="#">165581</a>	
<a href="#">407866/3 Vpa-B6/P Mit 205.225-65</a>	
<a href="#">Hydraulic Distributor Vek 10/9 A1/50</a>	
<a href="#">1.45/P</a>	
<a href="#">Gmz-E.B/1/D/F</a>	
<a href="#">Dmf-A A/8/8/S/1/1/0</a>	
<a href="#">Hydraulic Distributor Vek 12/12 B1/50</a>	
<a href="#">95090011 S-Mav 6 Manometer-Verschraubung</a>	
<a href="#">91920341</a>	
<a href="#">Gmg-B.B/7/C/O/G/O/O8/261407 Pump</a>	
<a href="#">Vpi-C8 258651/0105 Progressive Zufuhr</a>	
<a href="#">Vpa-C.B/6/0/W/C/22/22/40/P</a> <a href="#">Progressivverteiler</a>	
<a href="#">Dbs-18</a>	
<a href="#">170822, Ktr-B/2/V300/T5/T5</a>	
<a href="#">230186</a>	
<a href="#">11002065</a>	
<a href="#">Deb-D/2/V Dosierelement</a>	
<a href="#">94500970</a>	
<a href="#">11014965</a>	
<a href="#">11004665</a>	
<a href="#">Kfh-F/A/0/X/220</a>	
<a href="#">Dbsu-270</a>	
<a href="#">11011465k</a>	

[10vpb-B/6/0/0/Rs/09/09/20/P; R:Ooo,  
Mzzz, L:Ooo; S/N 242891](#)

[171306](#)

[Pnd-65](#)

[100gmf-B.B. C/W 3 Phase Motor 0.18  
Kw](#)

[95270004](#)

[78500364495\\_2740.75051.4  
Progressivverteiler Vpa-Cvpa-  
C.B/Hm/6/0/W/C/22/22/40](#)

[100kui-A](#)

[171307](#)

[Hdb-A/10/3/S/E/70bar](#)

[207194 Verteiler](#)

[100vpb-G Progressivverteilervpb-  
G/2/R0/20](#)

[111.385-65](#)

[Dbs-410](#)

[Vpa-B/6/0/0/0/20/20/20/P  
Progressivverteilervorauftrag 206793](#)

[Dbs-3000](#)

[11245065](#)

[Eld-65-08-5](#)

[Dmf-A/6/0/S/1/1/0](#)

[47764060](#)

[100vpi-C Zufuhr Progressive](#)

[100kui-M Volumenstromanzeigerkui-  
M/1/A/50/N1](#)

[78500364495\\_2740.75051.4  
Progressivverteiler Vpa-C Vpa-  
C.B/6/0/W/C/22/22/40/P](#)

[Hydraulic Distributor Vek 6/3](#)

[Kpd-A/0/Rk Distributor Woerner Modell  
Kpd-A/0/Rk](#)

[Delq-20](#)

<a href="#">Kfi-E/B/W/W/137/67</a>	
<a href="#">Kpd-A/0/Rk Wegeventil</a>	
<a href="#">Kui-B/2/A/70/U/70/U</a> <a href="#">Volumenstromanzeiger</a>	
<a href="#">163887</a>	
<a href="#">310141.2073-6a</a>	
<a href="#">468.525-65 Schaltelelement Sp Rot</a> <a href="#">L= 1,5m</a>	
<a href="#">Hydraulic Distributor Vekk 6/6 L2/50</a>	
<a href="#">Dbs-240-R</a>	
<a href="#">170518 (Kfs-D/F/0/S/063/A/170/130/Z)</a>	
<a href="#">310140.1385-6a</a>	
<a href="#">Gma-C/5/F/K/D/6/8/0/0/0/0/4.5</a>	
<a href="#">Voe-B/2/2/7/7/V</a>	
<a href="#">100deb-D</a>	
<a href="#">310140.1384-6a</a>	
<a href="#">Dbss10</a>	
<a href="#">95090011 Manometer-Verschraubung S-</a> <a href="#">Mav 6</a>	
<a href="#">Gma-?.B/7/F/0/0/8/10/8/10/8/10 Pumpe</a>	
<a href="#">Vpa-B/6/0/W/0/09/20/20/P</a>	PROGRESSIVE DISTRIBUTOR WITH CONTROL UNIT PROJEKT NR:138.004-4E POZ:5 VERWENDUNGSORT: ROLLER PRESS CENTRAL FETTSCHMIERUNG
<a href="#">94501438</a>	
<a href="#">476.557 Filling Level Controller 60b, 2</a> <a href="#">Wechsler (Change-Over Contact);</a> <a href="#">Stecker 4pol. M12x1</a>	
<a href="#">Hydraulic Distributor Ube/259.060-30</a>	
<a href="#">W ru/Kui-B/2/A/70/U/70/U/13 Anzeige</a> <a href="#">Des Volumenstroms</a>	
<a href="#">Dbss1</a>	
<a href="#">Gmfb41250m001000</a>	PUMP
<a href="#">Dbs 20-08-Ew Dbs-20/60-08-Ew</a>	
<a href="#">91021106</a>	

<a href="#">84798970</a>
<a href="#">476.557-60 Level Switch48-301.5,10-230vv,2 Points,Screw</a>
<a href="#">Delq-20/60</a>
<a href="#">Gmf-B</a>
<a href="#">100kfa-A</a>
<a href="#">Dbs-300</a>
<a href="#">95270054e</a>
<a href="#">Vpa-C.B/6</a>
<a href="#">Kfi-E B/W/X/210</a>
<a href="#">100kui-B</a>
<a href="#">Ab31-14/2-1a2a Temperatur-Sensor</a>
<a href="#">Certificate Of Original</a>
<a href="#">Wru Pfh-E/0/0 Handpumpe Wru Pfh-E/0/0</a>
<a href="#">165269</a>
<a href="#">100kui-M (Kui-M/1/A/50/N1)</a>
<a href="#">Kui-B Wru/469.590/13</a>
<a href="#">75252393</a>
<a href="#">47764060 Schalter Kfw-Dx/C/50/S/S/Z4n/180/120/70</a>
<a href="#">476.557-60b Level Monitor 2 Wechsler (Changeover Contact) Complete With Stecker 4pol Plug. M12x1</a>
<a href="#">Kfa-A/F/0/N/080c/Z3/80</a>
<a href="#">Kui-B/1/0/70/0</a>
<a href="#">Dbs150-Dw-003</a>
<a href="#">Dmf-A/00/8/8/S/1/1/0</a>
<a href="#">Dbs-150-T4</a>
<a href="#">310381.1655-6a</a>
<a href="#">468.526-65 Schaltelement Sp Orange L=1,5m</a>
<a href="#">95090011</a>
<a href="#">47764060 Sensorkfw-</a>

<a href="#">Dx/C/50/S/S/Z4n/180/120/70</a>	
<a href="#">086917 Kui-E/5 0.4-1.2 L/Min</a>	
<a href="#">Dbss06</a>	
<a href="#">Vpa-C.B/10/0/0/0/10/90/90/90/90/P</a> <a href="#">Progressivverteiltervorauftrag 702703</a>	
<a href="#">Gmz D/D/0 Item No : 5 Spare Part :</a> <a href="#">331.113-Ca Part List : 331.432-6a</a>	
<a href="#">- Rohr Metall 8mm (Schnitte Auf Zwei</a> <a href="#">Meter)</a>	
<a href="#">Dbs-1150</a>	
<a href="#">94430095</a>	
<a href="#">Hydraulic Distributor Vek 18/17 D1/50s</a>	
<a href="#">Dbssi-20</a>	
<a href="#">11053</a>	
<a href="#">Deb-D/0/P</a>	
<a href="#">100kui-F</a>	
<a href="#">Dmf-A/6/8/S/1/1/0, 100dmf-A</a>	
<a href="#">Dbs-150</a>	
<a href="#">Gmfa42500m001000</a>	LUBRICATOR
<a href="#">Gfm-F/0,75/V</a>	
<a href="#">94502254</a>	
<a href="#">Gma-B/5/F/K/D/0/0/8 Schmieranlage</a>	
<a href="#">Vpa-C.B/00/6/0/W/C/22/22/40</a> <a href="#">Progressivverteiler</a>	
<a href="#">Kfa-A/F/0/N/N/Z3/105</a>	
<a href="#">100gmf-A</a>	
<a href="#">1123502s02</a>	PUMP
<a href="#">Dbs-450</a>	
<a href="#">100pmf-A.B Kolbenpumpe Pmf-</a> <a href="#">A.B/4v/1,33/R/0/0/0/0/0/2/0/0/0</a>	
<a href="#">94380233 Manometer Gb 0-160bar/100</a> <a href="#">Niro</a>	
<a href="#">476.557-60 Thick Lube Sensor</a>	
<a href="#">Type:Vpa-B/6/0/W/0/09/20/20/P</a>	

<a href="#">Kfa-A/0/0/200/160 Oelstandssensor</a>	
<a href="#">1.40/P</a>	
<a href="#">Hydraulic Distributor Vek 10/9 D1/50</a>	
<a href="#">11138565</a>	
<a href="#">507539/2 Hydraulic Distributor Vpb-B6/P</a>	
<a href="#">91021106 Zsm-C/4/800</a>	
<a href="#">Gmk - A/00/6/05/B</a> <a href="#">Kolbenpumpenaggregat</a>	
<a href="#">Gfz-D/0,06/60/V Zahnradpumpe</a>	
<a href="#">Dua-B Nr.230 159/2</a>	
<a href="#">1/D/0/0/0/9/A</a>	
<a href="#">Hydraulic Distributor Vekk 8/7 T3/50</a>	
<a href="#">11008065</a>	
<a href="#">Kf1-E/C/W/W/196/117</a>	Level Switch
<a href="#">Dmf-A/00/8/8/0/1/1/0</a>	
<a href="#">100vpb-B/12/6/0/Rs/</a> <a href="#">20/20/20/20/20/20/P</a>	
<a href="#">Repair Kit For Pump Type Vpa-B6/P Nr.</a> <a href="#">407866/3</a>	
<a href="#">Kfa-A/F/S/S/N/063c/Z6an/135/100</a>	
<a href="#">203067/2 Sprayer Typ: Sbd-B/5/1/V</a>	
<a href="#">Deb-D/5/V Dosierelement</a>	
<a href="#">Dbs-140</a>	
<a href="#">Hydraulic Distributor Vek 18/16 A1/50s</a>	
<a href="#">Dmf-A6/6/S/1/1/0 Pumpenelement</a>	
<a href="#">Dbs-20/60</a>	
<a href="#">94020428 Sicherheitsventil 400 Bar</a> <a href="#">Dbds 10 K1x/400</a> <a href="#">Vitonzeichnungsnummer: 310380.1040-</a> <a href="#">6a</a>	
<a href="#">Vpbb200006x90p</a>	HYDRAULIC MANIFOLD LUBRICATOR
<a href="#">10vpb-B6/0/0/Rs/09/09/20/P; R:Voo,</a> <a href="#">M:Kkz, L:Ovo; S/N242891</a>	

<a href="#">Kfi-F/C/W/W/196/117</a>
<a href="#">310381.1152-6a_Hm</a>
<a href="#">Vpa-B/6/0/W/*/09/09/20/P</a> <a href="#">Progressivverteilervorauftrag 206793</a>
<a href="#">Vpb-B/6/0/0/M3/14/20/20/V</a>
<a href="#">Gmf-C Nr 707442</a>
<a href="#">0 100gmg-B.B</a> <a href="#">Kolbenpumpenaggregatgmg-</a> <a href="#">B.B/4p/C/0/A/0/16/C1/3/P*--- Ohne</a> <a href="#">Verteiler ---</a>
<a href="#">100gma-C.B</a>
<a href="#">100kpd-A</a>
<a href="#">Vpa-B/00/6/0/R/0/09/09/20 R:Ooo</a> <a href="#">M:Kkz L:Vvo Verschlusschraube G1/8</a> <a href="#">Mit Dichtring</a>
<a href="#">Dbs-240</a>
<a href="#">Hdb-A/10/3/E/ 60bar</a>
<a href="#">Dbsst-35</a>
<a href="#">Dbsq-150</a>
<a href="#">100dpa-B Dosierplatte Dpa-</a> <a href="#">B/6/0/R/0/09/09/20/P</a>
<a href="#">Kud-A2 Flowmeter</a>
<a href="#">Vpb-B/6/0/0/M3/20/</a>
<a href="#">Dbsst-130</a>
<a href="#">100vpa-B</a>
<a href="#">75252366k Antrieb 24v/- Mit Al-</a> <a href="#">Schutzhaubeersatzteil</a>
<a href="#">100vpb-B/10/6/0/Rs/ 20/20/20/20/20/P</a>
<a href="#">751.769-43</a>
<a href="#">11009465</a>
<a href="#">94502253</a>
<a href="#">Verteiler Vpa-C/B/6/0/W/C/22/22/40/P</a> <a href="#">Code 78500364495 2740.75051.4</a>
<a href="#">928646 Zufuhr Progressive 100vpi-C</a>
<a href="#">Dbs-250</a>



<a href="#">Hydraulic Distributor Vemk 8/4</a>
<a href="#">Dbs-255</a>
<a href="#">Hdb-A/00</a>
<a href="#">B90346_W1</a>
<a href="#">Deb-D/2/P</a>
<a href="#">94380233</a>
<a href="#">Kud-A2 Durchflusskontrolle Kud-A2</a>
<a href="#">Luc-A/02/7045 Patrone</a>
<a href="#">310140.1386-6a</a>
<a href="#">913.900-21 Initiator Ind. M18x1 10-30vdc 8mm</a>
<a href="#">Dbsu-150</a>
<a href="#">Dmf-A/6/0/0/1/1/0 Pumpenelement</a>
<a href="#">Hydraulic Distributor Vekk12/115 2/50</a>
<a href="#">Kfh-F /A/ 0 / X / 220</a>
<a href="#">232419/02/11 Vpb-B6/P</a>
<a href="#">Kfe-A/E-C-Wx-70-X-N</a>
<a href="#">800819/34-Rc Progressivverteiler Vpb-B/Hm/10/6/0/Rs/20/20/20/20/V</a>
<a href="#">138004ct</a>
<a href="#">Dbs-170</a>
<a href="#">171170</a>
<a href="#">Set Dichtungen Einer Dosierpumpe Element Dpi-C-Zufuhr Vpi-C</a>
<a href="#">Hdb-A/10/3/60 Bar Item No : 200 Spare Part : 331.113-Ca Part List : 331.432-6a</a>
<a href="#">Dbs-15</a>
<a href="#">Gma-B/7/E/0/0/6/8/0/0/0/0/</a>
<a href="#">Function Control Nr. 205.225-65</a>
<a href="#">Del610</a>
<a href="#">Gmf-C.B/4v/60/M/0/0/0/16/0/0/B/3/0</a>
<a href="#">100gmf-B.B</a>

<a href="#">111.425-64 Satz Dichtungssatz Pumpe</a>	
<a href="#">Sn 260907/01 Volumenstromanzeiger</a> <a href="#">Kui-A Kui-A M/40/U</a>	
<a href="#">Gmg-B.B.2.C.0.A.08.0.0.3.0 Lubrication</a> <a href="#">Station</a>	
<a href="#">Kfw-D/110/C/S/N/N/Z3n/220/160</a>	
<a href="#">Gmfa42500</a>	PUMP
<a href="#">Ab 31-14/3-1a-2a-3a-W</a> <a href="#">Temperaturschalter Ktr/3/V 300 T 50 -</a> <a href="#">80c (120c) 250v Ac 4a</a>	
<a href="#">Gfz-D/0,5/60/V Pumpe</a>	
<a href="#">Kfh-E/G/M/O/X/200,Sn:607814 Level</a> <a href="#">Switch</a>	