


Wohner

Garanti: 12 ay
Bu ¼r¼ne ait T¼rkiye i¼i kapı teslim fiyat ve teslim s¼resi i¼eren teklifimizi almak i¼in info@yursat.com.tr e-posta adresine baŐvuru yapabilir ya da ayrıntılı bilgi i¼in +90 224 240 03 04 numaralı telefonumuzdan bizlere ulaŐabilirsiniz.
Wohner Markası, tedarik s¼resi i¼in l¼tfen bizimle iletiŐime ge¼iniz.

Firmamız Wohner T¼rkiye Distrib¼t¼r¼ veya temsilcisi deęildir. Firmamız sipariŐ durumunda, belirtilen ¼r¼nlerde sadece Orjinal ve yeni ¼r¼n teklifi sunmaktadır. Bu sitede g¼sterilen ¼zel marka adları ve ticari markalar ilgili sahiplerinin m¼lkiyetindedir, talep durumunda kaldırılmaktadır.



¼r¼n	A¼ıklama
32430 Bara Adap.3f 25a	
32454 Bara Adapt.3f 63a 54mm	
01563 / 80a	
1495	
1563	80A
1240	300A
1243	440A
32439	Anschlussadapter 25 A 45 x 260 Doppelschiene
32472	Anschlussadapter 80 A 54 x 260 Doppelschiene
32456	Anschlussadapter 63 A 63 x 200 Monorail
1245	
W 32486	BUS ADAPTER 32 A (32486) Single Adjustable Mounting with Terminals Rail 45x200

01601	Busbar support PE/N 1-pole, individually mountable ; Dimensions [mm]: 20x49.5x65 (WxDxH); PU is:1;
01245	busbar cover - for busbar 12-30x10 - 1m long
32156	Busbar adapter 250 A, 3-pole, adapted on switching devices for Schneider Electric NSX100- NSX250, GV7, J250 105x190, connect to system top / bottom; Dimensions [mm]:105x35x190 (WxDxH); PU is:1;
32430	Busbar adapter 25 A 1 sliding Mounting rail 45 x 200, with cables AWG 12 (4th mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4
31158	Secur Powerliner - Reiter-Lasttrennschalter mit Sicherungen - 3-polig, 3-polig schaltend - f¼r D1- und D2-Sicherungen - 63A / 400V AC
31574	Secur EasyLiner - Reiter-Lasttrennschalter mit Sicherungen - 3-polig, 3-polig schaltend - f¼r D01- und D02-Sicherungen - 63A / 400V AC
33732	terminal compartment cover - for 33 700, 33 770, 33 720, 33 771, 33 715, 33 772 - Size: Size 00, high version
33737--un	clamping bracket - for QUADRON®185Power - Size: Size 00
37217	Current transformer 800 A / 5 A - 2.5VA / Class 1 - When used on busbars or in adapters 630 A additionally 37900 necessary.
37900	Fastening clip for current transformer - for fixing on busbars and in adapters 630 A
37220	Current transformer 250 A / 5 A - 2.5VA / Class 0.5 - When used on busbars or in adapters 630 A additionally 37900 necessary.
33751	current transformer 150 A / 5 A, - 2.5VA / Class 0.5 - Size: Size 00
01625	Busbar E-Cu -tinned, length 2.40m, 30x10, Rated current 630 A
01356	PE/N busbar support - 2-pole, individually mountable - suitable for busbars 12-30x5/10
01430	Universal busbar support 185power
01431	Rail support cover set - 1x left, 1x right
01432	center cover for Rail support 01430 - when using the carrier as center beam
01434	System cover on the front - 100mm
01438	Connection strip for 185 mm system - 3-pin, screw connection - for 2 cable lugs 240mm ² - 800A - for round and flat conductors

32741	Busbar adapter 630 A - 185 Power System - universal version up to 630A, Phase pitch 43-46mm - Connection above, CrossLink- Terminal contacting - Size: 150x585x35,
01495	Universal busbar support with internal screw holes - 3-pole, suitable for busbars 12, 15, 20, 25, 30, x5 - 10
01573	end cover - to cover the busbar ends, - suitable for No.: 01495 and 01500, - is attached to the busbar support cover infected
01199	terminal board - for 12x5-30x10 & double T & triple T profile - 3-pin, with cover cap - Connection: round conductor 95-185mm ² , - can be used up to max. 460A - Dimensions WxH: 135x200 mm
33601 250A	
31158	Secur Powerliner - Rider switch disconnecter with Fuses - 3-pole, 3-pole switching - for D1 and D2 fuses - 63A / 400V AC
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4;detailed product data
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH);
33601	NH fuse switch disconnecter size 1, 250 A, bar, connection bottom / top screw M10 with CrossLink®Technology; dimensions [mm]: 184x129x243
32430	Busbar adapter 25 A 1 movable DIN rail 45 x 200, with cables AWG 12 (4 mm ²); Dimensions [mm]:45x63x200 (WxDxH); PU is:4
01136	Holding set for cover profiles, for 3-pole busbar systems Set consisting of left and right bracket, for covers 01554, 01555 and 01417; dimensions [mm]: 30x92x204
01759	Spreader clamp 32 x 20; dimensions [mm]: 41x86x51 (WxDxH); PU is: 3; detailed
33199	
1678	
31368	
33246	
1927	
31100	
3525	
Lts-3, 630a	
33317	

[35016](#)

[1670](#)

[33933](#)

[33203](#)

[31976](#)

[36220](#)

[33439](#)

[31941](#)

[33600](#)

[1059](#)

[32632](#)

[33153](#)

[01583](#)

[1135](#)

[32766](#)

[31308](#)

[1258](#)

[31235](#)

[33403](#)

[1129](#)

[35017](#)

[32-461](#)

[31208](#)

[3221](#)

[Lts-00](#)

[31191](#)

[5784](#)

[31028](#)

[31578](#)

[1495](#)

[33773](#)

[31543](#)

[33457](#)

[1070](#)

[33505](#)

[31029](#)

[33726](#)

[31924](#)

[1935](#)

[31388](#)

[32907](#)

[32984](#)

[33717](#)

[31194](#)

[1145](#)

[33151](#)

[5800](#)

[1274](#)

[1694](#)

[31351](#)

[33938](#)

[33036](#)

[3910](#)

[3913](#)

[32921](#)

[3384](#)

[1359](#)

[32785](#)

[33366](#)

[31117](#)

[32575](#)

[31973](#)

[31281](#)

[32374](#)

[32755](#)

[31122](#)

[32444](#)

[33502](#)

[32607](#)

[33449](#)

[33308](#)

[3502](#)

[33435](#)

[01518](#)

[31567](#)

[3217](#)

[33973](#)

[33917](#)

[3351](#)

[32914](#)

[3575](#)

[31925](#)

[33351](#)

[33219](#)

[31579](#)

[1990](#)

[31118](#)

[01508000a](#)

[32937](#)

[31299](#)

3213
3917
31950
33-306
31
3759
33929
36103
1484
1586
1132
32978
Nh3-3p-630a/690v
33-307
31934
32452
Wo01990
33464
1724
1687
31559
32601
33454
33346
1704
33451
33159
32511
33945
32402
3568

3757	
33447	
31939.01	
33341	
31572	
31914	Seitenmodul - für 31 574 und 31 575
36903	
31961	
33198	
1729	
1103	
1380	
31203	
33702	
1562	
Spl D0 Ac22	INSURANCE ADAPTER
32214	
1185	
33947	
33222	
31204	
33444	
1116	
31935	
Us31357	
31482	
1911	
1596	
3765	
3915	

[8824](#)

[35001](#)

[78139](#)

[31297000](#)

[1722](#)

[3582](#)

[78105](#)

[3570](#)

[3577](#)

[31570](#)

[1688](#)

[32-159](#)

[32915](#)

[3916](#)

[5801](#)

[3197](#)

[36100](#)

[33294](#)

[01539](#)

[33516](#)

[1424](#)

[33168](#)

[1601](#)

[31355](#)

[1355](#)

[33720](#)

[1369](#)

[31407](#)

[32974](#)

[489](#)

32651	
32637	
33433	
1512	
33167	
31901	
1026	
32448	
33746	
31544	
1587	
31910	
31364	
3300	
1518000	
31229	
3238	
33441	
1401	
31251	
1709	
31385	
32446	
1202	
33285	
3620	
3912	
03948	FUSE BASE 160AMP 3POLE 690V NH00 BUS-MOUNTING
32633	
31908	
31918	

33461
33432
2700430960
31390
1716
01573
32004
Pact Mcr-V2-6015-85 Fuse
3240
32018
33327
31215
1138
3654
31333
33740
31371
31525
1427
1538
1092
32431
33749
32609
3195
33437
31250
32425
1715
31349

Lts-3
1245
331980000
33946
33470
3767
33425
32469
78443
33774
1436
Us01243
33971
36108
33360
33347
1934
32640
1348
31199
31360
36105
1725
5782
01622
32439
33430
32655
1357
36102
31358

1760	
31956	
32756	
31246	
1625000	
33738	clamping bracket - for QUADRAON®185Power - Size: Size 1 - 3
1590	
32976	
36107	
1285	
1703	
33155	
33704	
1230	
1429	
79811	
1287	
33939	
33936	
D02-16a	
31911	
1193	
3524	
31158	
31515	
33452	
31406	
32590	
33331	
33292	

31396	
31970	
33912	
33715	
1364	
1555	
31366	
32581	
33163	
1120	
31361	
33735	
1413	
33338	
31547	
30894	
1426	
3762	
3942	
33161	
1363	
32757	
3215	
21-0157	
1907	
32661	
33257	
31564	
33283	
31563	80A

32956	
31968	
33700	NH in-line fuse switch disconnecter 160 A - M8 screw, 3-pole switchable - Size: Size 00
33462	
33350	
1756	
32-061.000	
5780	
33745	
1929	
33208	
33377	
31237	
33511	
32513	
31267	
33922	
1047	
33724	
31971	
1543	
33408	
33142	
33450	
32983	
5787	
31225	
32449	
31219	
32778	

[1128](#)

[33113](#)

[32455](#)

[33466](#)

[31303](#)

[31247](#)

[1251](#)

[31511](#)

[1547](#)

[3219](#)

[1675](#)

[33924](#)

[1228](#)

[33424](#)

[31955](#)

[1094](#)

[31284](#)

[32400](#)

[1718](#)

[3233](#)

[33272](#)

[1360](#)

[1199](#)

[1998](#)

[1218](#)

[31282](#)

[33974](#)

[1240](#)

[31296](#)

[1886](#)

[31313](#)

[31915](#)

[32215](#)

[6016](#)

[3561](#)

[3228](#)

[6025](#)

[31232](#)

[33926](#)

[01537](#)

[33510](#)

[33079](#)

[6080](#)

[31338](#)

[3587](#)

[32456](#)

[31512](#)

[32535](#)

[1430](#)

[1207](#)

[33928](#)

[31268](#)

[31-174](#)

[33162](#)

[Hb32963](#)

[31132](#)

[32662](#)

[3531](#)

[31005](#)

[1602](#)

[33194](#)

3553	
33334	
31200	
35005	
31011	
33393	
32466	
32-221	
31929000	
1356	
1127	
31-175	
33149	
5792	
31902	
33207	
33733	terminal compartment cover - Size: Size 1-3
3193	
31110	
01361	
1144	
35004	
31291	
32477	
33442	
1371	
31004	
1673	
31274	
31552	
1295	

[31903](#)

[33753](#)

[3569](#)

[33315](#)

[31202](#)

[31293](#)

[31964](#)

[1162](#)

[32-430](#)

[33909](#)

[3914](#)

[32471](#)

[32768](#)

[31909](#)

[33460](#)

[33204](#)

[32987](#)

[32585](#)

[1748](#)

[31217](#)

[32775](#)

[31374](#)

[3225](#)

[32579](#)

[33324](#)

[3794](#)

[1275](#)

[31244](#)

[32951](#)

[1243](#)

[1730](#)

[33456](#)

[33385](#)

[31102](#)

[1318](#)

[32660](#)

[31943](#)

[3919](#)

[32782](#)

[31280](#)

[1069](#)

[5781](#)

[1362](#)

[33927](#)

[33217](#)

[31195](#)

[31228](#)

[1827](#)

[1433](#)

[30322](#)

[33921](#)

[33143](#)

[33126](#)

[33550](#)

[1742](#)

[33330](#)

[31442](#)

[01025](#)

[5783](#)

[3572](#)

[1136](#)

31027	End cap for 2- and 3-pole comb bars 16 mm ² ; dimensions [mm]: 5x16x16 (WxDxH);
01-098	
1597	
31026	
33911	
33736	
31905	
3222	
3929	
33734	
33150	
33201	
1563	
30473	
33703	
1444	
1257	
33223	
1741	
1374	
3557	
1421	
1550	
33545	
1482	
1325	
1542	
33235	
32592	
78447	

33384
31209
31024
31323
31226
32156
3231
32973
01141
31133
1068
32975
36909
1719
1753
3768
33906
3793
32580
3550
33234
31278
33908
33931
1119
31370
33206
32758
33349
33398

31441	
33540	
31243	
1932	
31148	
31241	
1139	
32457	
01508	
Eec 32 A, 2	Adapter EEC 32 A, 2 Adjustable Mounting Rails EEC 32 A, 2
1690	
01203	
33373	
1693	
6063	
36114	
5788	
31192	
31325	
33972	
01026	
33748	
33552	
32641	
33440	
6032	
33365	
31561	
4025	
32-460	
1121	

31072
31073
3552
31929
31140
31123
1489
32549000
31314
33445
3290
Lts-000
33943
32964
33418
32472
32982
31922
1544
525
32-159.000
33051
32595
33152
31398
3792
33280
33428
1754
31554

[32440](#)

[1238](#)

[1728](#)

[31221](#)

[31946](#)

[36109](#)

[33173](#)

[32438](#)

[1100](#)

[31972](#)

[33164](#)

[32465](#)

[1823](#)

[32441](#)

[1292](#)

[33718](#)

[1071](#)

[3226](#)

[1518](#)

[1440](#)

[3527](#)

[1008](#)

[3359](#)

[33361](#)

[33513](#)

[32072](#)

[31193](#)

[35007](#)

[01289](#)

[78893](#)

5789
33555
33356
33343
Aes10*38 Fuse
33419
1689
1420
32610
31070
32420
33458
33742
33944
31399
33325
3234
3558
33507
1361
1996
3224
31039
1702
1147
33316
31173
31010
36902
33434
32140

[1749](#)

[31227](#)

[31017](#)

[1573000](#)

[33602](#)

[31086](#)

[1676](#)

[32582](#)

[1540](#)

[33467](#)

[32570](#)

[31211](#)

[31974](#)

[3930](#)

[33913](#)

[79859](#)

[32426](#)

[33446](#)

[31386](#)

[32023](#)

[32763](#)

[3239](#)

[32168](#)

[3301](#)

[33363](#)

[1573](#)

[32408](#)

[31157](#)

[31275](#)

[8825](#)

32594	
31372	
36112	
3316	
33701	NH in-line fuse switch disconnecter 250 A - M12 screw, 3-pin switchable - Size: Size 1
33732	
3299	
31182	
3173	
1541	
01625	
1701	
1025	
1759	
32486	
33544	
76490	
1647	
32963	
31216	
3574	
31302	
32001	
31514	
33394	
33362	
1236	
3766	
1890	
31345	

33455
33180
31939
1671
1203
33-200
31085
33193
31963
33775
33603
31394
33541
1936
36219
31184
1222
36912
3181
1165
33225
Vde-0660
31189
3370
1417
31238
31252
33770
33463
3795

[1367](#)

[33216](#)

[1284](#)

[32584](#)

[31057](#)